




1336 FORCE™ PLC® Communications Adapter

Cat. No. 1336T-GT1EN

User Manual (Series A)



Important User Information

Because of the variety of uses for this equipment and because of the differences between this solid-state equipment and electromechanical equipment, the user of and those responsible for applying this equipment must satisfy themselves as to the acceptability of each application and use of the equipment. In no event will Allen-Bradley Company be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The illustrations shown in this manual are intended solely to illustrate the text of this manual. Because of the many variables and requirements associated with any particular installation, the Allen-Bradley Company cannot assume responsibility or liability for actual use based upon the illustrative uses and applications.

No patent liability is assumed by Allen-Bradley Company with respect to use of information, circuits or equipment described in this text.

Reproduction of the content of this manual, in whole or in part, without written permission of the Allen-Bradley Company is prohibited.

The information in this manual is organized in numbered chapters. Read each chapter in sequence and perform procedures when you are instructed to do so. Do not proceed to the next chapter until you have completed all procedures.

Throughout this manual we use notes to make you aware of safety considerations:



ATTENTION: Identifies information about practices or circumstances that can lead to personal injury or death, property damage or economic loss.

Attentions help you:

- Identify a hazard.
- Avoid the hazard.
- Recognize the consequences.

Important: Identifies information that is especially important for successful application and understanding of the product.



Shock Hazard labels may be located on or inside the drive to alert people that dangerous voltage may be present.

Information and Precautions

Chapter 1

efesotomasyon.com

Manual Objectives	1-1
Chapter Objectives	1-1
Who Should Use This Manual	1-1
Terminology	1-1
General Precautions	1-2
Catalog Number Explanation	1-2

Installation and Wiring

Chapter 2

Chapter Objectives	2-1
Mounting	2-1
Discrete I/O Jumpers	2-2
BRAM Jumper	2-2
Analog I/O Connections	2-4
RIO and DH+ [®] Configuration	2-6
Port Wiring	2-6
Communication Configuration	2-7
RIO Configuration	2-7
DH+ [®] Configuration	2-8

Start-Up

Chapter 3

Chapter Objectives	3-1
Start-Up Procedure	3-1
RIO Communications	3-6
Discrete PLC [®] Controller I/O Data Transfer	3-6
Discrete PLC [®] Programming	3-9
Discrete I/O Program	3-10
Logic Command Bit Mapping	3-12

Programming

Chapter 4

Chapter Objectives	4-1
Terminology	4-1
BRAM Functions	4-2
RIO Redundant Mode	4-3
Analog I/O Parameter Set-Up Description	4-5
Parameter Groups	4-9
Parameter Descriptions	4-10
Group 1 — Adapter Info	4-10
Group 2 — Adapter Diag	4-12
Group 3 — SCANport™ I/O	4-16
Group 4 — Masks	4-18
Group 5 — Owners	4-20
Group 6 — Analog I/O	4-23
Group 7 — Channel A	4-25
Group 8 — Channel B	4-27

Advanced Programming

Chapter 5

Chapter Objectives	5-1
Block Transfer	5-1
Remote I/O Status Word	5-1
Data Storage	5-2
PLC-5® Block Transfer Rung Example	5-4
DH+® Communications	5-7
DH+® Command Set	5-7
Block Transfer Descriptions	5-11
Block Transfer Status Word	5-11
Table 5-12 — Block Transfer Message Word 2 Code Definitions	5-12

Troubleshooting

Chapter 6

Chapter Objectives	6-1
Fault and Status LEDs	6-1
Domino Processor Status — D1 and D2	6-2
Application Processor Status — D3 and D5	6-2
Channel A Status — D4, D6 and D7	
Channel B Status — D8, D9 and D10	6-2
PLC® Comm Adapter Board Status — D11-D13, D18 and D21	6-3
Faults and Fault Queues	6-4
Fault Code Descriptions	6-5
Fault Displays	6-5
Fault Codes	6-6

efesotomasyon.com

Specifications and Supplemental Information

Chapter 7

Chapter Objectives	7-1
Specifications	7-1
Software Block Diagram	7-2
Hardware Block Diagram	7-4
Parameter Cross Reference — By Number	7-5
Parameter Cross Reference — By Name	7-6
PLC® Comm Adapter Board DIP Switch Settings	7-7

Information and Precautions

Manual Objectives

The purpose of this manual is to provide the necessary information to apply the 1336 FORCE PLC Communication Adapter. Included in this manual are methods for installing, wiring, starting up, programming and troubleshooting the PLC Comm Adapter.

Chapter Objectives

Chapter 1 provides precautions and information on the general intent of this manual, gives an overall description of the PLC Communications Adapter Board, and provides a listing of key adapter features.

Who Should Use This Manual

This publication provides planning, installation, wiring and diagnostic information for the PLC Communications Adapter Board. It is intended to be used by qualified service personnel responsible for the set up and servicing of solid state equipment. To assure successful installation and operation, become familiar with tasks that must be performed in a sequence for successful completion. Particular attention should be directed to the Attention and Important statements contained within the material. To make efficient use of the PLC Comm Adapter, personnel must be able to program and operate an Allen-Bradley PLC and/or Drive Tools. In particular, personnel must be familiar with remote I/O concepts & configuration, and be able to program block transfer instructions.

Terminology

Detailed definitions of industrial automation and technical terms used throughout this manual may be found in the **INDUSTRIAL AUTOMATION GLOSSARY — a guide to Allen-Bradley technical terms**, Publication AG-7.1.

General Precautions



ATTENTION: This board contains ESD (electrostatic Discharge) sensitive parts and assemblies. Static control precautions are required when installing, testing, servicing or repairing this assembly. Component damage may result if ESD control precautions are not followed. If you are not familiar with static control procedures reference **Guarding Against Electrostatic Damage**, A-B Publication 8000-4.5.2, or any other applicable ESD protection handbook.



ATTENTION: Only personnel familiar with SCANbus devices and associated machinery should plan or implement the installation, start-up, or subsequent troubleshooting of this board. Failure to comply may result in personnel injury and/or equipment damage.

Catalog Number Explanation

Catalog Number Description

Located on each PLC Communications Adapter Board is a **Language Module**. Catalog numbers identifying the language modules are listed below.


1336T	—	GT1EN
1336T = Field Installed		GT1EN = English Version
(Blank)= Factory Installed		GT1EN = English Version

Installation and Wiring

Chapter Objectives

Chapter 2 provides information on mounting the PLC Comm Adapter Board as well as configuring and connecting communications.

Mounting



efesotomasyon.com

Figure 2-1 — PLC Comm Adapter Board Mounting

The PLC Comm Board plugs into the Main Control Board at connector J1. (2) Keyed Mounting Slots along with the (2) Phillips-Head Screws provided with the kit secure the board to the 1336 FORCE Mounting Plate.





Figure 2-2 — PLC Comm Adapter Board Terminal Blocks and Discrete I/O Jumpers


Discrete I/O Jumpers



ATTENTION: To avoid damage to the PLC Comm Adapter Board, discrete Input Jumpers J8, J9, J10 and J11 must be set to the same input voltage applied to the PLC Comm Adapter Board — Either 24V DC or 120V AC.

- J8** Sets the Drive Enable input for either 24V DC or 120V AC.
- J9** Sets the Motor Thermoguard input for either 24V DC or 120V AC.
- J10** Sets the Norm Stop input for either 24V DC or 120V AC.
- J11** Sets the External Fault input for either 24V DC or 120V AC.

BRAM Jumper



Jumper J3 on the PLC Comm Adapter Board enables or disables the write to BRAM function as follows.

- EN** = Enabled — Write to BRAM is allowed.
- DIS** = Disabled — Write to BRAM is not allowed.


Terminal Block Locations

Two separate terminal blocks are provided at the bottom of the PLC Comm Adapter Board for discrete and analog I/O wiring. To aid in making connections, terminal blocks may be pulled apart when connecting cable.

The maximum and minimum wire size accepted by both TB20 and TB21 is 3.3 & 0.60 mm² (12 & 30 AWG). Maximum torque is 0.79 N-m (7 lb-in). Recommended control signal wire is:

- Belden 8760 or equiv. — 0.750 mm² (18 AWG), Twisted Pair, Shielded
- Belden 8770 or equiv. — 0.750 mm² (18 AWG), 3-Conductor, Shielded
- Belden 9460 or equiv. — 0.750 mm² (18 AWG), Twisted Pair, Shielded

Discrete I/O



Discrete Outputs

Fault outputs from the 1336 FORCE are supplied at terminal block TB20 on the PLC Comm Board. Fault outputs provide warning or fault signals based on drive programming.

FAULT NC

FAULT COM

FAULT NO — A Form C, N.O./N.C. relay contact on the PLC Comm Board programmed to provide external warning or fault change-of-state signals.

Resistive Rating = 115V AC/30V DC, 5.0 A

Inductive Rating = 115V AC/30V DC, 5.0 A




Figure 2-3 — Typical Digital Output Connections

Discrete Inputs

Discrete Inputs to the 1336 FORCE are supplied through the PLC Comm Adapter Board at terminal block TB20. Discrete inputs serve to enable and stop the drive as well as provide checks on drive and motor operation.

efesotomasyon.com




Figure 2-4 — Typical Digital Input Connections Using an External Power Source

DRIVE ENABLE — A drive enable signal must be present before the drive will acknowledge a start command. If LED D21 Drive Enable on the PLC Comm Board is illuminated, the drive has received an enable signal allowing drive logic to accept a start command.

MOTOR THERMO — Allows the user to connect a N.C. motor thermal switch to the 1336 FORCE. Motor Thermo LED D18 on the PLC Comm Adapter will illuminate if a motor over temperature condition occurs. The drive will issue a warning or trip on a fault as configured by Parameter 88 (VP Flt/Warn Cfg) and Parameter 89 (VP Warn/None Cfg).


NORM STOP — A N.C. maintained stop input that will stop the drive according to the user specified stop mode (Parameter 59). The drive responds the same way it would if the stop bit were set in any logic command. When a stop signal is present, the Norm Stop LED D13 on the PLC Board will be illuminated, and the drive will not be allowed to run until the stop signal is removed.



ATTENTION: The drive start/stop control circuitry includes solid-state components. If hazards due to accidental contact with moving machinery or unintentional flow of liquid, gas or solids exist, an additional hardwired stop circuit is required to remove AC line power to the drive. When AC input power is removed, there will be loss of inherent regenerative braking effect and the motor will coast to a stop. An auxiliary braking method may be required.

EXT FAULT — Allows the user to wire an external signal into the 1336 FORCE. If external fault input voltage is removed, the External Fault LED D12 on the PLC Board will light. The drive will then issue a fault or warning based on the fault configuration defined by Parameters 88 and 89. When input voltage is applied, D12 will not be lit.

Analog I/O Connections



Analog Inputs

There are (4) analog inputs to the PLC Comm Adapter Board that have a range of $\pm 10V$ and a digital resolution of 12 bits. These inputs are differential inputs with noise rejection filtering.

Each input has a gain and offset adjustment. The A/D converter is a 12 bit device where an input value of $+10V$ will result in a digital value of 2048. Likewise, an input value of $-10V$ will result in a digital output value of -2048 . Chapter 4 describes the parameters associated with scaling analog values.

Note: Analog input parameters must be linked to a velocity reference parameter as well as a scaling and offset parameter for an analog input to function.

Analog Outputs

There are (4) analog outputs from the PLC Comm Adapter Board that have a range of $\pm 10V$ and a digital resolution of 12 bits. Chapter 4 describes the parameters associated with scaling analog values.




Figure 2-5 — Typical Analog Input Connections for Unidirectional Operation




Figure 2-6 — Typical Analog Input Connections for Bidirectional Operation




Figure 2-7 — Typical Analog Output Connections

RIO and DH+ Configuration





Figure 2-8 — PLC Comm Adapter Board DIP Switches and Communication Connections

Port Wiring



Twinaxial cable is used to connect Channel A or B of the PLC Comm Adapter Board to RIO and DH+ communications systems as shown in Figures 2-9 and 2-10.

CABLE TYPE

Belden 9463 — Consult Allen-Bradley if any other type cable is used.

CABLE LENGTH

A minimum of 10 feet for all connections. Shorter lengths may cause signal reflections.

CABLE CONNECTIONS

All (3) conductors — Blue, Shield and Clear — should be connected at each wiring point. No additional ground connections should be made to the shield.

Important: Do not use star type connections. Only (2) cables may be connected at any wiring point on a series connected application.

CABLE TERMINATIONS

(2) 1770-XT or 150Ω (82Ω for 230 kbaud) resistors are used for cable termination. Use (1) at each end of the cable.

Communication Configuration

Connections to Allen-Bradley's RIO or DH+ networks are made via (2) channels (Channel A or Channel B) on the PLC Comm Adapter Board. Each channel allows the 1336 FORCE to communicate directly with a PLC and is independently programmable. Dip switch settings on the PLC Comm Adapter Board are used to configure one or both channels for DH+ or RIO communication. Switches U2 and U3 are used to configure Channel A, switches U4 and U5 are used to configure Channel B. A detailed explanation of DIP switch settings is provided in Chapter 3 — Start-Up.

RIO Configuration

When a communication channel is configured for RIO connection, the PLC Comm Adapter Board will look like a remote I/O rack to an Allen-Bradley PLC.

The PLC Adapter can:

- Support 57.6K, 115K or 230K baud communication rates.
- Be configured as a 1/4, 1/2, 3/4 or full I/O rack.
- Be configured to ignore PLC fault conditions and continue operating.
- Support transfer of multiple drive parameter read or writes in a single Block Transfer.
- Allow the 1336 FORCE to be directly connected to (2) PLCs. PLC parameter control allows drive control to be switched between the two PLCs and specifies which PLC is currently in control.
- Allow the Block Transfer feature to be disabled via DIP switch setting and provide an extra word of discrete data.




Figure 2-9 — RIO Wiring Configuration

DH+ Configuration

When a communication channel is configured for DH+ communication, the PLC Adapter Board becomes a station on the DH+ link. Information can be passed to and from the drive using the DH+ protocol.

The PLC Adapter can:

- Support 57.6K, 115K or 230K baud communication rates.
- Support read or write messages for blocks of parameters.
- Allow the PLC to issue 1336 FORCE messages using a method similar to RIO Block Transfer.




Figure 2-10 — DH+ Wiring Configuration

Start-Up

Chapter Objectives

The first part of Chapter 3 provides a Start-Up Procedure detailing DIP switch settings for configuring Channels A and B. The remainder of the chapter provides an explanation of discrete data transfer between the PLC and PLC Comm Adapter Board.

Start-Up Procedure

The PLC Comm Adapter contains (4) switches which select the communications options for each channel. Switches U2 and U3 are used to configure Channel A. Switches U4 and U5 perform the same function for Channel B. The standard configuration is for Channel A to be configured for DH+ and Channel B to be configured for RIO Protocol. Changes to switch settings will not take effect until power is reapplied.




ATTENTION: Use a blunt, pointed instrument (such as a ball point pen) to set DIP switches. Do not use a pencil. Pencil lead (graphite) may damage switch assemblies.




ATTENTION: The PLC Comm Adapter utilizes both input and output image table words for drive control and is not compatible with complementary I/O configurations. Failure to check connections and switch settings for application compatibility when configuring the PLC Comm Adapter Board could result in personal injury and /or equipment damage due to unintended or undesirable drive or process equipment operation.

The following Start-Up Procedure provides PLC Comm Board switch settings for board protocol, Baud Rate, RIO rack size, redundancy, starting group and address. Should you encounter any operating faults once switch settings have been applied, refer to Chapter 6 — Troubleshooting.


Step 1 — Protocol — U2 or U4



Step 2 — BAUD Rate — U2 or U4




Step 3 — RIO Rack Size — U2 or U4




U2 or U4

Switches 5 and 6 OFF = ON =




RIO RACK SIZE	SW5	SW6
1/4	OFF	OFF
1/2	OFF	ON
3/4	ON	OFF
FULL	ON	ON

Step 4 — Not Last/Last — U2 or U4




U2 or U4

Switch 7 OFF = ON =




	SW7
LAST	ON
NOT LAST	OFF

Step 5 — Redundant — U2 or U4




U2 or U4

Switch 8 OFF = ON =



REDUNDANT RIO	SW8
YES	ON
NO	OFF


Step 6 — RIO Starting Group — U3 or U5



U3 and U5

Switches 1 or 2

OFF =  ON = 





STARTING MODULE GROUP	SW1	SW2
0	OFF	OFF
2	OFF	ON
4	ON	OFF
6	ON	ON

Step 7 — RIO Rack Address or DH+ Station Address

U3 or U5

Switches 3 thru 8

OFF =  ON = 



00	OFF	OFF	OFF	OFF	OFF	OFF
01	OFF	OFF	OFF	OFF	OFF	ON
02	OFF	OFF	OFF	OFF	ON	OFF
03	OFF	OFF	OFF	OFF	ON	ON
04	OFF	OFF	OFF	ON	OFF	OFF
05	OFF	OFF	OFF	ON	OFF	ON
06	OFF	OFF	OFF	ON	ON	OFF
07	OFF	OFF	OFF	ON	ON	ON

10	OFF	OFF	ON	OFF	OFF	OFF
11	OFF	OFF	ON	OFF	OFF	ON
12	OFF	OFF	ON	OFF	ON	OFF
13	OFF	OFF	ON	OFF	ON	ON
14	OFF	OFF	ON	ON	OFF	OFF
15	OFF	OFF	ON	ON	OFF	ON
16	OFF	OFF	ON	ON	ON	OFF
17	OFF	OFF	ON	ON	ON	ON

20	OFF	ON	OFF	OFF	OFF	OFF
21	OFF	ON	OFF	OFF	OFF	ON
22	OFF	ON	OFF	OFF	ON	OFF
23	OFF	ON	OFF	OFF	ON	ON
24	OFF	ON	OFF	ON	OFF	OFF
25	OFF	ON	OFF	ON	OFF	ON
26	OFF	ON	OFF	ON	ON	OFF
27	OFF	ON	OFF	ON	ON	ON

30	OFF	ON	ON	OFF	OFF	OFF
31	OFF	ON	ON	OFF	OFF	ON
32	OFF	ON	ON	OFF	ON	OFF
33	OFF	ON	ON	OFF	ON	ON
34	OFF	ON	ON	ON	OFF	OFF
35	OFF	ON	ON	ON	OFF	ON
36	OFF	ON	ON	ON	ON	OFF
37	OFF	ON	ON	ON	ON	ON

40	ON	OFF	OFF	OFF	OFF	OFF
41	ON	OFF	OFF	OFF	OFF	ON
42	ON	OFF	OFF	OFF	ON	OFF
43	ON	OFF	OFF	OFF	ON	ON
44	ON	OFF	OFF	ON	OFF	OFF
45	ON	OFF	OFF	ON	OFF	ON
46	ON	OFF	OFF	ON	ON	OFF
47	ON	OFF	OFF	ON	ON	ON

50	ON	OFF	ON	OFF	OFF	OFF
51	ON	OFF	ON	OFF	OFF	ON
52	ON	OFF	ON	OFF	ON	OFF
53	ON	OFF	ON	OFF	ON	ON
54	ON	OFF	ON	ON	OFF	OFF
55	ON	OFF	ON	ON	OFF	ON
56	ON	OFF	ON	ON	ON	OFF
57	ON	OFF	ON	ON	ON	ON

60	ON	ON	OFF	OFF	OFF	OFF
61	ON	ON	OFF	OFF	OFF	ON
62	ON	ON	OFF	OFF	ON	OFF
63	ON	ON	OFF	OFF	ON	ON
64	ON	ON	OFF	ON	OFF	OFF
65	ON	ON	OFF	ON	OFF	ON
66	ON	ON	OFF	ON	ON	OFF
67	ON	ON	OFF	ON	ON	ON

70	ON	ON	ON	OFF	OFF	OFF
71	ON	ON	ON	OFF	OFF	ON
72	ON	ON	ON	OFF	ON	OFF
73	ON	ON	ON	OFF	ON	ON
74	ON	ON	ON	ON	OFF	OFF
75	ON	ON	ON	ON	OFF	ON
76	ON	ON	ON	ON	ON	OFF
77	ON	ON	ON	ON	ON	ON

① Address 00 Only Valid for DH+ Configuration

RIO Communications

Each channel of the PLC Comm Adapter Board can be configured for Allen-Bradley Remote I/O (RIO) communications. Configuration as a RIO device allows the drive to look like a remote I/O chassis to a PLC.

GENERAL

Verify that values sent to the drive parameters are scaled to the appropriate units. Most drive parameters operate based on drive units. Values should be scaled in the PLC Controller or by using a function block program in the drive. Refer to the Function Block Programming User Manual for additional information.

To control drive parameters, the parameters are linked to the drive by using source and sink parameters (source parameters, sink parameters and linking information is defined on pages 4-1 & 2.). The selected rack size and the channel selected determine which parameters in the drive are used for transfer of data between the drive and PLC Controller. Because there are two channels on the PLC Comm Adapter Board, the channel configuration (RIO or DH+) also determines which adapter board parameters are used and what they are used for. The standard configuration is for Channel A to be DH+ communication and channel B to be RIO communication. This can be changed using switches U2 (Channel A HIGH) and U4 (Channel B HIGH).

Discrete PLC Controller I/O Data Transfer

Data required by the drive on a continuously updated basis is transferred using the I/O image table of the PLC Controller. The data transfer rate can be determined using the standard conventions for I/O rack updates of discrete I/O. Refer to your PLC Controller manual for details.

DATA TRANSFER EXAMPLES

Figures 3-1 — 3-4 indicate how data is transferred between the PLC Comm Adapter Board and a PLC Controller for the rack size selected. The first group number associated with a rack is reserved for the Block Transfer function if it is selected with the RIO Protocol. The remaining group numbers —

- 1-7 for Full Racks
- 1-5 or 3-7 for 3/4 Racks
- 1, 3, 5 or 7 for 1/4 Racks

— are used for the transfer of discrete data. Each group number reserves a single 16 bit word in both the input and output image table of the PLC Controller for the rack number assigned. In the Drive these words are directly linked to internal drive parameters using source and sink parameters as shown in Figures 3-5 and 3-6.




Figure 3-1 — RIO Full Rack Configuration




Figure 3-2 — RIO 3/4 Rack Configuration




Figure 3-3 — RIO 1/2 Rack Configuration




Figure 3-4 — RIO 1/4 Rack Configuration




Figure 3-5 — PLC Comm Adapter Configuration Example – RIO with Block Transfer




Figure 3-6 — PLC Comm Adapter Configuration Example – RIO without Block Transfer

Discrete PLC Programming

Figure 3-7 illustrates an application where the PLC Comm Adapter Board has been set-up for a full rack (numbered rack 2) and the 16 bit words for Groups 1 and 2 are being used by the PLC Controller program for data transfer with the 1336 FORCE. In this example, the drive has been configured so that the data coming into source Parameter 330 is sent to Parameter 367 — Port 6 Logic Command In. Information sent to the 1336 FORCE using the 16 bit output word for Group 1 of rack 2 must be a 16 bit word where the bits are defined by the description of Parameter 367.

Parameter 101 — Velocity Ref 1 HI has been linked to source Parameter 331. The 16 bit output word for Group 2 of rack 2 must be a 16 bit signed integer whose value is within the allowable range of values in drive units for Parameter 101.

Information from the 1336 FORCE consists of Parameter 56 — Logic Status LOW, and Parameter 146 — Velocity Feedback. Based on the links shown, the 16 bit input word for Group 1, rack 2 in the PLC Controller is a 16 bit logic status word. The bits in this 16 bit word are defined by the description for Parameter 56. In addition, the 16 bit input for Group 2, rack 2 in the PLC Controller is a 16 bit signed integer whose value corresponds to the allowable values in drive units for Parameter 146.




Figure 3-7 — Discrete PLC Programming Example for RIO with Block Transfer

If the data transferred between the 1336 FORCE and the PLC Controller is to be manipulated by the PLC Controller in units other than drive units, the data must be appropriately scaled when it is transferred to a drive parameter. Scaling can be done at the PLC Controller or by using drive function blocks. The scaled information must be based on drive unit definitions for parameters in the 1336 FORCE. Parameter 101 — Velocity Reference 1 HI shown in **Figure 3-7** is in drive units, where 4096 is defined as base speed. If the PLC Controller program is written in terms of feet-per-minute (FPM), then FPM must be converted to drive units before being sent to Parameter 101.

Discrete I/O Program

Figure 3-8 is a PLC Controller program which could be used to control the 1336 FORCE. Based on the configuration shown in **Figure 3-7** the PLC Controller program will be transferring information to Parameters 367 and 101 in the 1336 FORCE. Logic bits in File B3 of the PLC Controller are used to set the drive logic control bits and integer File N10 Word 01 is used to store the drive speed reference. To control the logic operation of the drive, the PLC program must control the bits in the output image table which correspond to the desired operation. Because Parameter 322 in **Figure 3-7** has been linked to Parameter 367 and Parameter 322 is associated with Group 1 in the output image table, the PLC Controller program will be controlling bits in Word 0:21.




Figure 3-8 — Discrete PLC Controller Program

Logic Command Bit Mapping

Bit numbering in the PLC Controller is octal as opposed to the decimal numbering used by drive Parameter 367 — Port 6 Logic Command In. **Figure 3-9** shows the correlation between the output image table bits and the bits used by Parameter 52. In order to set the ramp disable bit in Parameter 352 (bit 9 decimal), bit 0:21/11 must be set as shown in Rung 3 of **Figure 3-8**.




Figure 3-9 — Bit Mapping for Parameter 52 – Logic Command

If the external speed reference is selected, the PLC Controller must send a 16 bit word to Parameter 101 — Velocity Reference 1 HI, in the drive. Because the speed reference is a complete 16 bit word, the PLC Controller must send the data as a complete word rather than as individual bits as was the case for logic command bits.

In this example, Word 1 of integer file N10 is used to store the speed reference for the drive. The MOV block in Rung 6 of **Figure 3-8** transfers the 16 bit Word N10:01 to Word 2 of the output image table. Because Word 2 of the output image table is sent to Parameter 323, which in turn is linked to Parameter 101, the 16 bit Word N10:01 is the speed reference input to drive Parameter 101.

Information transferred back to the PLC Controller from the drive is handled much as it was in the previous example, with the exception that data is transferred into the input image table of the PLC Controller. Again, note that bit coded words such as Parameter 56 — Logic Status LOW, are bit numbered in octal in the PLC Controller, while the drive is in decimal.

End of Chapter

Programming

Chapter Objectives

Chapter 4 provides the following information.

- Parameter Terminology and Definitions
- Analog I/O Configuration Examples
- Block Transfer Explanation
- Block Transfer Message Structures
- DH+ Message Structures

Terminology

PARAMETER

Memory location used to store drive set-up data or to monitor real time input or output information. Each parameter is assigned a name and number which does not change.


SET-UP PARAMETER

A parameter whose value does not change during normal operation of the drive. Set-up parameters are used for scaling and calibration of specific drive functions which are application and/or hardware dependent.


CONFIGURATION PARAMETER

A parameter whose values may be changed during normal operation of the drive. Configuration parameters are used to input reference and feedback information to the drive and to provide monitoring points for control signals. Configuration parameters are one of two types, either **SOURCE** or **SINK PARAMETERS**. Refer to the 1336 FORCE User Manual for a detailed description of source or sink parameters

SOURCE PARAMETERS (Read Only Parameters)

Source parameters contain real time information that is available for use by other devices. These devices can include PLC Controllers, operator interface devices, programming terminals, etc. Source parameters are indicated by the symbol  throughout his manual.

SINK PARAMETERS (Read and Write Parameters)

Sink parameters accept data from other parameters which are then used by the drive to perform the desired functions. An example of a sink parameter is the external velocity reference parameter which accepts a speed reference from a device such as a PLC. Sink parameters are indicated by the symbol  throughout his manual.

LINKS

A link is a software connection between a sink and a source parameter that allows the transfer of data from the source parameter to the sink parameter.

The PLC Comm Adapter Board allows up to (50) links. Links can be programmed only when the drive is not running. Links are stored in BRAM and established at power up, BRAM recall, and/or system reset.

User Link — A software connection that must be established by the user. These links can be changed as needed according to the application.

Permanent Link — A software connection that is a permanent part of the drive firmware. These links cannot be modified or deleted by the user.

OWNER PARAMETERS

The PLC Comm Adapter Board allows start, jog, direction and other control functions to be owned by one or more control devices or adapters. To avoid conflict, some owners are exclusive. For example, only one device can issue a forward direction speed command. Others have multiple control. For example, all devices can jog the drive in the forward direction, but only at a set speed.

MASK PARAMETERS

When the multicomms port is interfaced to the PLC Comm Adapter Board, up to (5) different SCANport adapters and (2) different RIO devices can control the 1336 FORCE. With this flexibility, conflicts are inherent. The PLC Comm Adapter Board allows functional masks to be made. Functions such as start, jog and drive direction as well as many fault interlocks can be selectively locked out at each port by using mask parameters to select the allowable functions for each port.

BRAM Functions

User parameters, link fault information, reference stamp, process display information and password are all stored in BRAM. The (3) BRAM functions available to the user are:

BRAM Store — Stores current parameter value and links to BRAM.

BRAM Recall — Updates the current values and links with parameter values and links stored in BRAM.

BRAM Initialize — Updates the current values and links with the default values and links and clears any values out of BRAM.

RIO Redundant Mode

The RIO redundant mode is a special mode that allows the drive to be connected to the RIO channel of (2) separate PLC Controllers. A parameter in the drive specifies which PLC Controller has control of the drive. Output image table data from the non-controlling PLC is discarded. **Figure 4-1** shows a typical redundant mode configuration. The redundant RIO mode is only available when the following (3) conditions are met.

1. Both Channel A and Channel B are configured for RIO protocol.
2. The dip switch for Channel A is set for the redundant mode.
3. Both Channel A and Channel B are the same size — Both must be configured for full, 3/4, 1/2, or 1/4 rack.

The redundant mode operates as follows.

1. Data from the output image table of each PLC Controller is transferred to the PLC Comm Adapter Board by the respective PLC Controller.
2. The RIO redundant channel number parameter (Parameter 427) determines which PLC Controller's output will be made available to the drive via Parameters 322-328.
3. Each PLC Controller input image table receives data from the drive via Parameters 351-358.
4. Block Transfer messages from both drives are processed as normal. Only PLC output image table data is discarded.




Figure 4-1 — Redundant RIO Communications

Analog I/O
Parameter Set-Up Description

After hard wiring the analog I/O to the PLC Comm Board terminals, you must set-up parameters in the drive to allow for data flow between the PLC Comm Board and the drive. Each terminal has parameters associated with it as shown in **Figure 4-2**. Set-Up parameters are used to program the PLC Comm Board functions, and consist of Parameters 392-399, and 400-407. Configuration parameters allow the PLC Comm Board to communicate with the drive, and must be linked to parameters in the drive — Parameters 339-342 and 387-390 — The analog input and output configuration parameters.

Each analog input and output is associated with a scaling and offset set-up parameter. These parameters must be adjusted for each analog device.

The drive works with internal drive units. Each parameter is a 16 bit word, which allows a range of ± 32767 internal units. The drive is scaled so that 4096 is equal to one unit of the quantity being regulated. A $\pm 10V$ DC signal applied to an analog input is converted to a digital value of ± 2048 , providing a total range of 4096. When calibrating analog inputs, a scale factor is applied to this value, to provide an effective range of ± 32767 16×2048 . The offset parameter determines the offset in volts, applied to the raw analog value before the scale factor is applied. This allows you to shift the range of the analog input by ± 4096 drive units (± 20 volts).




Figure 4-2 — Analog I/O Block Diagram

Analog Input 1 and Analog Input 2 will be used in detailing the scaling and offset parameters. At Analog Input 1, between TB21 terminals 9 and 10, a potentiometer with a range of $\pm 10V$ DC has been connected. Parameter 339 has been linked to Parameter 101 (Velocity Reference) in the drive, which gives the potentiometer control of the external velocity reference. To calibrate the pot to control 100% base speed in both directions, the scaling parameter must be adjusted. The default value of the scale parameters allows a total range of 4096, -2048 to $+2048$. This allows only 50% base speed in each direction. By setting a scale factor of 2 in Parameter 393 (An In 1 Scale) the digital input is multiplied by 2, providing a range of -4096 to $+4096$, or 100% base speed in both directions. If the user wanted a range of ± 2 times base speed, the scale factor would have to be 4 (Base Speed = 4096, 2 times Base Speed = 8192, 2048 times 4 = 8192). Parameter 392 (An In 1 Offset) will remain at the default value of zero, allowing the input range to be $-10V$ to $+10V$. The range of the offset parameter is $\pm 20V$ DC as shown in **Figure 4-3**.




Figure 4-3 — Potentiometer with +10V Range to Control 0 to +100% Base Speed

For Analog Input 2, a 0 to 10 volt potentiometer will be used to adjust the Torque Reference from -100% to $+100\%$. To accomplish this, both the scale and offset parameters will need to be adjusted. By linking Parameter 340 to Parameter 162, Torque Reference, the potentiometer connected to Analog Input 2 becomes the Torque Reference Signal. This signal must be scaled and offset in order to get the entire $\pm 100\%$ in the 0-10 volt range. A digital range of 8192 (± 4096) must now be scaled for an analog range of 10 volts, and must be offset so 5 volts on the potentiometer will indicate 0% Torque.

As seen in Figure 4-4, the offset voltage adds the corresponding digital value to the range. In this case, an offset of -5 volts adds a digital value of -1024 to the range. This causes 0 volts on the potentiometer to register as -1024 digital internal to the drive and 10 volts on the potentiometer will be $+1024$ to the drive. This can then be scaled by a factor of 4 (8192 drive units) so that 0 volts sends a digital value of -4096 for -100% torque, and 10 volts sends a digital value of $+4096$ for $+100\%$ torque.




Figure 4-4 — Potentiometer 0-10V Range to Control $\pm 100\%$ Torque Reference

Analog outputs are set up similar to analog inputs. Each output has a scale and offset parameter, along with a specific variable parameter used for linking. Differences occur because of the direction of information flow. The drive sends a digital value in drive units, which must be matched to the voltage of the monitoring device. Similar to analog inputs, the analog output converts a ± 2048 to $\pm 10V$ DC. Thus, when the drive sends $\pm 100\%$ Base Speed (equal to ± 4096) it must be scaled by 0.5 to be in the proper range ($\pm 4096 \times 0.5 = \pm 2048$). Offset can be $\pm 20V$ DC, even though the physical limit is $\pm 10V$ DC. This allows you to offset the signal anywhere within the entire range.

In **Figure 4-5** Parameter 387 (Analog Output 1) is used as an example to detail the scaling and offset parameters. At Analog Output 1 a meter with a range of 0-10 V DC has been connected. Parameter 387 has been linked to Parameter 146 (Velocity Feedback). In order for the meter to indicate speed in both directions, the scale and offset parameters must be adjusted as shown in **Figure 4-5**. Working in the opposite direction as the analog inputs, apply the scale factor first. The drive sends a ± 4096 digital value to indicate $\pm 100\%$ velocity feedback for a total digital range of 8192. The meter, having an analog range of 0-10V DC, requires a digital range of 2048. This is accomplished by applying a scale factor of 0.25 ($8192 \times 0.25 = 2048$). In order to have the 0-10V DC meter indicate $\pm 100\%$ feedback, an offset must be applied. Offset parameters for analog outputs will again add the corresponding digital value to the range. In this case, an offset of 5 volts adds a digital value of 1024 to the range. This will allow full range deflection on the 0 to 10 volt meter, with 5 volts indicating zero speed.




Figure 4-4 — Analog Output 1 $\pm 100\%$ Speed Indication

Parameter Groups

Parameters from 300 to 500 are dedicated to the PLC Comm Adapter Board. PLC Comm Adapter Parameters are divided into (8) groups based on functionality. Grouping is an option in addition to the sequential numbered parameter list provided in Chapter 7. Functional groups increase efficiency while helping to reduce programming time.

GROUP 1 ADAPTER INFO		GROUP 2 ADAPTER DIAG		GROUP 3 SCANport I/O		GROUP 4 MASKS	
300	PLC Comm Adpt ID	425	ChA RIO Fit Sel	314	Data In A1	408	Port Enable
301	PLC Comm Version	426	ChA RIO Warn Sel	315	Data In A2	409	Direction Mask
302	PLC Comm Config	430	ChB RIO Fit Sel	316	Data In B1	410	Start Mask
309	Language Select	431	ChB RIO Warn Sel	317	Data In B2	411	Jog Mask
310	Adv/Basic Select	435	DIP Fault Setup	318	Data In C1	412	Reference Mask
		436	ChA Fault Sts	319	Data In C2	413	Clear Fault Mask
		437	ChA Warn Sts	320	Data In D1	414	Reset Drive Mask
		438	ChB Fault Sts	321	Data In D2	415	Local Mask
		439	ChB Warn Sts	338	SB Analog In		
		440	SB Fault Sel	343	Data Out A1		
		441	SB Warn Sel	344	Data Out A2		
		442	SB Fault Sts	345	Data Out B1		
		443	SB Warn Sts	346	Data Out B2		
				347	Data Out C1		
				348	Data Out C2		
				349	Data Out D1		
				350	Data Out D2		
				367	Pt6 Logic Cmd In		
				368	Pt7 Logic Cmd In		
				386	SB Analog Out		
				391	SB Analog Sel		
				416	SB Default Ref		

GROUP 5 OWNERS		GROUP 6 ANALOG I/O		GROUP 7 ① CHANNEL A		GROUP 8 ① CHANNEL B	
369	Stop Owner	339	Analog In 1	303	ChA DIP Switch	304	ChB DIP Switch
370	Dir Owner	340	Analog In 2	305	ChA LED State	306	ChB LED State
371	Start Owner	341	Analog In 3				
372	Jog 1 Owner	342	Analog In 4	322	ChA RIO In 1	330	ChB RIO In 1
373	Jog 2 Owner	387	Analog Out 1	323	ChA RIO In 2	331	ChB RIO In 2
374	Set Ref Owner	388	Analog Out 2	324	ChA RIO In 3	332	ChB RIO In 3
375	Local Owner	389	Analog Out 3	325	ChA RIO In 4	333	ChB RIO In 4
376	Flux Owner	390	Analog Out 4	326	ChA RIO In 5	334	ChB RIO In 5
377	Trim Owner	392	Analog In 1 Offset	327	ChA RIO In 6	335	ChB RIO In 6
378	Ramp Owner	393	Analog In 1 Scale	328	ChA RIO In 7	336	ChB RIO In 7
379	Cirflt Owner	394	Analog In 2 Offset	329	ChA RIO In 8	337	ChB RIO In 8
		395	Analog In 2 Scale	351	ChA RIO Out 1	359	ChB RIO Out 1
		396	Analog In 3 Offset	352	ChA RIO Out 2	360	ChB RIO Out 2
		397	Analog In 3 Scale	353	ChA RIO Out 3	361	ChB RIO Out 3
		398	Analog In 4 Offset	354	ChA RIO Out 4	362	ChB RIO Out 4
		399	Analog In 4 Scale	355	ChA RIO Out 5	363	ChB RIO Out 5
		400	Analog Out 1 Offset	356	ChA RIO Out 6	364	ChB RIO Out 6
		401	Analog Out 1 Scale	357	ChA RIO Out 7	365	ChB RIO Out 7
		402	Analog Out 2 Offset	358	ChA RIO Out 8	366	ChB RIO Out 8
		403	Analog Out 2 Scale	427	Redund Chan No		
		404	Analog Out 3 Offset				
		405	Analog Out 3 Scale				
		406	Analog Out 4 Offset				
		407	Analog Out 4 Scale				

① Parameters included in GROUPS 7 and 8 will vary depending upon the selected communication protocol

② Shaded Parameters do not exist when Df+ protocol is selected. Inputs are variable and dependent on rack size and whether Block Transfer is enabled.

③ ChB RIO parameters do not exist when redundant RIO protocol is selected.

Parameter Descriptions

All parameters used by the PLC Comm Adapter card will contain the following information.

PARAMETER TYPE — (2) types of parameters are available.

Read Only The Value is changed only by the drive and is used to monitor values.

Read and Write The Value is changed through programming and can also be used to monitor values.

PARAMETER ACCESS — (2) types of parameter access are available.

Basic Parameters that are always available to the user.

Enhanced Additional parameters that are only available in the enhanced mode.

MINIMUM VALUE — The lowest parameter setting possible.

MAXIMUM VALUE — The highest parameter setting possible.

FACTORY DEFAULT — The value the parameter will default to when the drive is initialized.

DRIVE UNITS — The actual value of the parameter stored in the 1336 FORCE parameter table.

DISPLAY UNITS — Engineering units that are used to display the parameter value on at a programming terminal (volts, etc.).

**GROUP 1
Adapter Info**

This group of parameters provides basic PLC Comm Adapter configuration data.

PLC Comm Adapter ID

The identifier for the PLC Comm Adapter Board.

PARAMETER NUMBER	300
PARAMETER TYPE	Read Only
MINIMUM VALUE	1
MAXIMUM VALUE	1
FACTORY DEFAULT	1
DRIVE UNITS	None
PARAMETER ACCESS	Basic

GROUP 1
Adapter Info

PLC Comm Version

The current firmware version of the PLC Comm Adapter Board.

PARAMETER NUMBER 301
PARAMETER TYPE Read Only
MINIMUM VALUE 0.00
MAXIMUM VALUE 9.99
FACTORY DEFAULT .10
DRIVE UNITS .100
PARAMETER ACCESS Basic

PLC Comm Config

The encoded value for the current DIP switch configuration of the PLC Comm Adapter Board. This stored value is used in determining if key dip switch values have changed. If they have, a fault will be displayed.

PARAMETER NUMBER 302
PARAMETER TYPE Read Only
MINIMUM VALUE 1
MAXIMUM VALUE 65535
FACTORY DEFAULT 1
DRIVE UNITS None
PARAMETER ACCESS Basic

Language Select

This parameter indicates whether English or an alternate language will be used for parameter and fault display text.

PARAMETER NUMBER 309
PARAMETER TYPE Read and Write
MINIMUM VALUE 0
MAXIMUM VALUE 1
FACTORY DEFAULT 0
DRIVE UNITS None
PARAMETER ACCESS Basic

0 = English
 1 = Alternate Language

Adv/Basic Select

This parameter determines whether the basic list of parameters will be available (limited parameters will be displayed), or the advanced list will be available (all parameters will be displayed).

PARAMETER NUMBER 310
PARAMETER TYPE Read and Write
MINIMUM VALUE 0
MAXIMUM VALUE 1
FACTORY DEFAULT 0
DRIVE UNITS None
PARAMETER ACCESS Basic

0 = Basic — Limited Parameter List Will Be Accessible
 1 = Advanced — All Parameters Will Be Accessible

GROUP 2
Adapter Diag


This group of parameters configures the fault and warning diagnostics used by the PLC Comm Adapter Board.

ChA RIO Fit Sel

This parameter specifies what action the PLC Comm Adapter Board will take when a PLC Controller RIO communications fault occurs at Channel A.

PARAMETER NUMBER 425
PARAMETER TYPE Read and Write
MINIMUM VALUE 0
MAXIMUM VALUE 15
FACTORY DEFAULT 15
DRIVE UNITS Bits
PARAMETER ACCESS Basic

0 0 0 0 0 0 0 0 0 0 0 0




ChA RIO Warn Sel

This parameter specifies what action the PLC Comm Adapter Board will take when a PLC Controller RIO communications warning occurs at Channel A.

PARAMETER NUMBER 426
PARAMETER TYPE Read and Write
MINIMUM VALUE 0
MAXIMUM VALUE 15
FACTORY DEFAULT 0
DRIVE UNITS Bits
PARAMETER ACCESS Basic

0 0 0 0 0 0 0 0 0 0 0 0




GROUP 2
Adapter Diag

ChB RIO Fit Sel

This parameter specifies what action the PLC Comm Adapter Board will take when a PLC Controller RIO communications fault occurs at Channel B.

PARAMETER NUMBER 430
PARAMETER TYPE Read and Write
MINIMUM VALUE 0
MAXIMUM VALUE 15
FACTORY DEFAULT 15
DRIVE UNITS Bits
PARAMETER ACCESS Basic

0 0 0 0 0 0 0 0 0 0 0 0




ChB RIO Warn Sel

This parameter specifies what action the PLC Comm Adapter Board will take when a PLC Controller RIO communications warning occurs at Channel B.

PARAMETER NUMBER 431
PARAMETER TYPE Read and Write
MINIMUM VALUE 0
MAXIMUM VALUE 15
FACTORY DEFAULT 0
DRIVE UNITS Bits
PARAMETER ACCESS Basic

0 0 0 0 0 0 0 0 0 0 0 0



GROUP 2
Adapter Diag

DIP Fault Setup

This parameter indicates which DIP switch faults the PLC Comm Adapter Board has encountered.

PARAMETER NUMBER	435			
PARAMETER TYPE	Read Only			
MINIMUM VALUE	0000	0000	0000	0000
MAXIMUM VALUE	1111	1111	1111	1111
FACTORY DEFAULT	0000	0000	0000	0000
DRIVE UNITS	Bits			
PARAMETER ACCESS	Basic			
BIT 0 = CHANNEL A BAUD Rate Fault				BIT 8 = CHANNEL B BAUD Rate Fault
BIT 1 = CHANNEL A Illegal Rack Size Fault				BIT 9 = CHANNEL B Illegal Rack Size Fault
BIT 2 = CHANNEL A Redundancy – Both Channels Not RIO				
BIT 3 = CHANNEL A Bad Module Group				BIT 11 = CHANNEL B Bad Module Group
BIT 4 = CHANNEL A Bad Protocol				BIT 12 = CHANNEL B Bad Protocol

ChA Fault Sts

This parameter lists the current fault conditions at Channel A of the PLC Comm Adapter Board.

PARAMETER NUMBER	436
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	7
FACTORY DEFAULT	0
DRIVE UNITS	Bits
PARAMETER ACCESS	Basic

ChA Warn Sts

This parameter lists the current warning conditions at Channel A of the PLC Comm Adapter Board.

PARAMETER NUMBER	437
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	7
FACTORY DEFAULT	0
DRIVE UNITS	Bits
PARAMETER ACCESS	Basic

ChB Fault Sts

This parameter lists the current fault conditions at Channel B of the PLC Comm Adapter Board.

PARAMETER NUMBER	438
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	7
FACTORY DEFAULT	0
DRIVE UNITS	Bits
PARAMETER ACCESS	Basic

ChB Warn Sts

This parameter lists the current warning conditions at Channel B of the PLC Comm Adapter Board.

PARAMETER NUMBER	439
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	7
FACTORY DEFAULT	0
DRIVE UNITS	Bits
PARAMETER ACCESS	Basic

GROUP 2
Adapter Diag

SB Fault Sel

This parameter indicates which SCANport ports will cause a drive soft fault on loss of communications.

PARAMETER NUMBER	440			
PARAMETER TYPE	Read Only			
MINIMUM VALUE	0000	0000	0000	0000
MAXIMUM VALUE	0000	0000	0011	1110
FACTORY DEFAULT	0000	0000	0011	1110
DRIVE UNITS	Bits			
PARAMETER ACCESS	Basic			
BIT 1 = Port 1	BIT 2 = Port 2	BIT 3 = Port 3	BIT 4 = Port 4	BIT 5 = Port 5

SB Warn Sel

This parameter indicates which SCANport ports will cause a drive warning on loss of communications.

PARAMETER NUMBER	441			
PARAMETER TYPE	Read Only			
MINIMUM VALUE	0000	0000	0000	0000
MAXIMUM VALUE	0000	0000	0011	1110
FACTORY DEFAULT	0000	0000	0011	1110
DRIVE UNITS	Bits			
PARAMETER ACCESS	Basic			
BIT 1 = Port 1	BIT 2 = Port 2	BIT 3 = Port 3	BIT 4 = Port 4	BIT 5 = Port 5

SB Fault Sts

This parameter indicates which communications soft faults the drive has encountered at the SCANport ports.

PARAMETER NUMBER	442			
PARAMETER TYPE	Read Only			
MINIMUM VALUE	0000	0000	0000	0000
MAXIMUM VALUE	0000	0000	0011	1110
FACTORY DEFAULT	0000	0000	0011	1110
DRIVE UNITS	Bits			
PARAMETER ACCESS	Basic			
BIT 1 = Port 1	BIT 2 = Port 2	BIT 3 = Port 3	BIT 4 = Port 4	BIT 5 = Port 5

SB Warn Sts

This parameter indicates which communications warnings the drive has encountered at the SCANport ports.

PARAMETER NUMBER	443			
PARAMETER TYPE	Read Only			
MINIMUM VALUE	0000	0000	0000	0000
MAXIMUM VALUE	0000	0000	0011	1110
FACTORY DEFAULT	0000	0000	0011	1110
DRIVE UNITS	Bits			
PARAMETER ACCESS	Basic			
BIT 1 = Port 1	BIT 2 = Port 2	BIT 3 = Port 3	BIT 4 = Port 4	BIT 5 = Port 5

GROUP 3
SCANport I/O

This group of parameters is used to configure I/O communications through the PLC Comm Adapter SCANport ports.

Data In A1-D2

These parameters contain image words 1-8 from the SCANport output image table.

PARAMETER NUMBER	314-321
PARAMETER TYPE	Read and Write
MINIMUM VALUE	-32767
MAXIMUM VALUE	+32767
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Basic

SB Analog In

This parameter is a source used to convert a +10V analog input value to a +32767 value. This digital value can then be linked to one of the 1336 FORCE input parameters.

PARAMETER NUMBER	338
PARAMETER TYPE	Read and write
MINIMUM VALUE	-32767
MAXIMUM VALUE	+32767
FACTORY DEFAULT	None
DRIVE UNITS	None
PARAMETER ACCESS	Basic

Data Out A1-D2

These parameters contain image words 1-8 from the SCANport input image table.

PARAMETER NUMBER	343-350
PARAMETER TYPE	Read Only
MINIMUM VALUE	-32767
MAXIMUM VALUE	+32767
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Basic

Pt6 Logic Cmd In

This logic command parameter is for Port 6. This parameter is permanently linked to Parameter 52 — Logic Command Word.

PARAMETER NUMBER	367
PARAMETER TYPE	Read and Write
MINIMUM VALUE	0 Hex
MAXIMUM VALUE	FFFF Hex
FACTORY DEFAULT	0 Hex
DRIVE UNITS	Bits
PARAMETER ACCESS	Basic
BIT 0 = Ramp Stop	BIT 7 = Current Limit Stop
BIT 1 = Start	BIT 8 = Coast Stop
BIT 2 = Jog 1	BIT 9 = Ramp Disable
BIT 3 = Clear Fault	BIT 10 = Flux Enable
BIT 4 = Forward	BIT 11 = Process Trim Enable
BIT 5 = Reverse	BIT 12 = Velocity Ref Select A
BIT 6 = Jog 2	BIT 13 = Velocity Ref Select B
	BIT 14 = Velocity Ref Select C
	BIT 15 = Reset Drive

C	B	A	
0	0	0	— ZERO
0	0	1	— EXTERNAL REF 1 (Par 101, 100)
0	1	0	— PRESET SPEED 1 (Par 119)
0	1	1	— PRESET SPEED 2 (Par 120)
1	0	0	— PRESET SPEED 3 (Par 121)
1	0	1	— PRESET SPEED 4 (Par 122)
1	1	0	— PRESET SPEED 5 (Par 123)
1	1	1	— EXTERNAL REF 2 (Par 104, 103)

GROUP 3
SCANport I/O

Pt7 Logic Cmd In

This logic command parameter is for Port 7. This parameter is permanently linked to Parameter 52 — Logic Command Word.

PARAMETER NUMBER	368
PARAMETER TYPE	Read and Write
MINIMUM VALUE	0 Hex
MAXIMUM VALUE	FFFF Hex
FACTORY DEFAULT	0 Hex
DRIVE UNITS	Bits
PARAMETER ACCESS	Basic
BIT 0 = Ramp Stop	BIT 7 = Current Limit Stop
BIT 1 = Start	BIT 8 = Coast Stop
BIT 2 = Jog 1	BIT 9 = Ramp Disable
BIT 3 = Clear Fault	BIT 10 = Flux Enable
BIT 4 = Forward	BIT 11 = Process Trim Enable
BIT 5 = Reverse	BIT 12 = Velocity Ref Select A
BIT 6 = Jog 2	BIT 13 = Velocity Ref Select B
	BIT 14 = Velocity Ref Select C
	BIT 15 = Reset Drive

C	B	A	
0	0	0	— ZERO
0	0	1	— EXTERNAL REF 1 (Par 101, 100)
0	1	0	— PRESET SPEED 1 (Par 119)
0	1	1	— PRESET SPEED 2 (Par 120)
1	0	0	— PRESET SPEED 3 (Par 121)
1	0	1	— PRESET SPEED 4 (Par 122)
1	1	0	— PRESET SPEED 5 (Par 123)
1	1	1	— EXTERNAL REF 2 (Par 104, 103)

SB Analog Out

This parameter provides the analog output value sent over the SCANport to Ports 1-5.

PARAMETER NUMBER	386
PARAMETER TYPE	Read and Write
MINIMUM VALUE	-32767
MAXIMUM VALUE	+32767
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Basic

SB Analog Sel

This parameter indicates which port (1-5) to get the SCANport analog input value that appears in Parameter 338 — SB Analog In.

PARAMETER NUMBER	391			
PARAMETER TYPE	Read and Write			
MINIMUM VALUE	1			
MAXIMUM VALUE	5			
FACTORY DEFAULT	1			
DRIVE UNITS	None			
PARAMETER ACCESS	Basic			
1 = Port 1	2 = Port 2	3 = Port 3	4 = Port 4	5 = Port 5


SB Default Ref

This parameter indicates what the default reference SCANport uses if no reference is requested from a SCANport port. This value is read on power up only. This parameter's value will change when a system reset/power cycle occurs.

PARAMETER NUMBER	416	
PARAMETER TYPE	Read and Write	
MINIMUM VALUE	0	
MAXIMUM VALUE	5	
FACTORY DEFAULT	2	
DRIVE UNITS	None	
PARAMETER ACCESS	Basic	
0 = External Reference	2 = Preset Speed 2	4 = Preset Speed 4
1 = Preset Speed 1	3 = Preset Speed 3	5 = Preset Speed 5

**GROUP 4
Masks**

This group of parameters contains binary masks for all control functions. The masks control which ports can issue control commands. Each mask contains a bit for each SCANport port. Individual bits can be set to 0 to deny control or 1 to allow control.



Port Enable

This parameter indicates which SCANport ports have the ability to accept commands listed in Parameters 409-415.

PARAMETER NUMBER 408
 PARAMETER TYPE Read and Write
 MINIMUM VALUE 0
 MAXIMUM VALUE 0FE Hex
 FACTORY DEFAULT 0
 DRIVE UNITS None
 PARAMETER ACCESS Bits
 0 = Deny Control 1 = Permit Control

Dir Mask

This parameter controls which SCANport ports can issue forward/reverse commands.

PARAMETER NUMBER 409
 PARAMETER TYPE Read and Write
 MINIMUM VALUE 0
 MAXIMUM VALUE 0FE Hex
 FACTORY DEFAULT 0
 DRIVE UNITS None
 PARAMETER ACCESS Bits
 0 = Deny Control 1 = Permit Control

Start Mask

This parameter controls which SCANport ports can issue start commands.

PARAMETER NUMBER 410
 PARAMETER TYPE Read and Write
 MINIMUM VALUE 0
 MAXIMUM VALUE 0FE Hex
 FACTORY DEFAULT 0
 DRIVE UNITS None
 PARAMETER ACCESS Bits
 0 = Deny Control 1 = Permit Control

Jog Mask

This parameter controls which SCANport ports can issue jog commands.

PARAMETER NUMBER 411
 PARAMETER TYPE Read and Write
 MINIMUM VALUE 0
 MAXIMUM VALUE 0FE Hex
 FACTORY DEFAULT 0
 DRIVE UNITS None
 PARAMETER ACCESS Bits
 0 = Deny Control 1 = Permit Control

**GROUP 4
Masks**

Ref Mask

This parameter controls which SCANport ports can select an alternate reference or preset speed.

PARAMETER NUMBER	412
PARAMETER TYPE	Read and Write
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Deny Control	1 = Permit Control

Clr Fault Command

This parameter controls which SCANport ports can generate an auxiliary fault.

PARAMETER NUMBER	413
PARAMETER TYPE	Read and Write
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Deny Control	1 = Permit Control

Reset Drive Mask

This parameter controls which SCANport ports can reset a fault.

PARAMETER NUMBER	414
PARAMETER TYPE	Read and Write
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Deny Control	1 = Permit Control


Local Mask

This parameter controls which SCANport ports are allowed to take exclusive control of drive logic commands except Stop (Stop will be accepted from any device regardless of who has control). Exclusive local control can only be taken while the drive is stopped.

PARAMETER NUMBER	415
PARAMETER TYPE	Read and Write
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Deny Control	1 = Permit Control

**GROUP 5
Owners**

This group of parameters contains binary information to display which group of parameters are issuing control commands. Each owner parameter has a bit for each SCANport port.



Stop Owner

This parameter displays which SCANport ports are presently issuing a valid Stop command.

PARAMETER NUMBER	369
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

Dir Owner

This parameter displays which SCANport port currently has exclusive control of direction changes

PARAMETER NUMBER	370
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

Start Owner

This parameter displays which SCANport ports are presently issuing a valid Start command.

PARAMETER NUMBER	371
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

Jog1 Owner

This parameter displays which SCANport ports are presently issuing a valid Jog1 command.

PARAMETER NUMBER	372
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

GROUP 5
Owners

Jog2 Owner

This parameter displays which SCANport ports are presently issuing a valid Jog2 command.

PARAMETER NUMBER	373
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

Set Ref Owner

This parameter displays which SCANport port currently has exclusive control in selecting the command frequency source.

PARAMETER NUMBER	374
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

Local Owner

This parameter displays which SCANport port has requested exclusive control of all drive logic functions. If a SCANport port is in local lockout, all other functions (except stop) on all other SCANport ports are locked out and non-functional.

PARAMETER NUMBER	375
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

Flux Owner

This parameter displays which SCANport ports are presently issuing a valid Flux Enable command.

PARAMETER NUMBER	376
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

GROUP 5
Owners

Trim Owner

This parameter displays which SCANbus port is presently issuing a Trim Enable command.

PARAMETER NUMBER	377
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

Ramp Owner

This parameter displays which SCANbus port is presently issuing a Ramp command.

PARAMETER NUMBER	378
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

Clr Fault Owner

This parameter indicates which SCANbus port is presently issuing a Clear Fault command.

PARAMETER NUMBER	379
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	0FE Hex
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Bits
0 = Stop Input Not Present 1 = Stop Input Present	

GROUP 6
Analog I/O

This function group contains the parameters needed to configure analog I/O signals (offset, scale, etc.).

Analog In 1-4

These parameters are source parameters that are the result of converting $\pm 10V$ signals to ± 32767 values using associated scale and offset parameters. Each digital value can then be linked to other 1336 FORCE parameters.

PARAMETER NUMBER	339-342
PARAMETER TYPE	Read Only
MINIMUM VALUE	-32767
MAXIMUM VALUE	+32767
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Basic

Analog In 1-4 Offset

These parameters determine the offset applied to the raw Analog In 1-4 values before the scale factor is applied. This allows the user to shift the range of the analog input.

PARAMETER NUMBER	392, 394, 396, 398
PARAMETER TYPE	Read and Write
MINIMUM VALUE	-20 Volts
MAXIMUM VALUE	+20 Volts
FACTORY DEFAULT	0
DRIVE UNITS	± 4100
PARAMETER ACCESS	Basic

Analog In 1-4 Scale

These parameters determine the scale factor or gain for Analog In 1-4 values. A +10V DC signal applied to Analog In 1-4 at TB21 is converted to a +2048 digital value used by the 1336 FORCE. Before the digital value is displayed or transferred to the drive, the scale factor is applied allowing an effective digital range of ± 32767 (16×2048). The absolute digital value is clamped at 32767.

PARAMETER NUMBER	393, 395, 397, 399
PARAMETER TYPE	Read and Write
MINIMUM VALUE	-16
MAXIMUM VALUE	+16
FACTORY DEFAULT	+1
DRIVE UNITS	± 32767
PARAMETER ACCESS	Basic

Scale Factor	Drive Units
1	2048
2	4096
4	8192
16	32767

GROUP 6
Analog I/O

Analog Out 1-4

These parameters are sink parameters used to convert ± 32767 values to a $\pm 10V$ signal. Each digital value is linked to a 1336 FORCE source parameter which provides a value that will be scaled and offset. The results of these operations are converted to a voltage signal where ± 2048 results in a $\pm 10V$ output.

PARAMETER NUMBER	387-390
PARAMETER TYPE	Read and Write
MINIMUM VALUE	-32767
MAXIMUM VALUE	+32767
FACTORY DEFAULT	0
DRIVE UNITS	± 32767
PARAMETER ACCESS	Basic

Analog Out 1-4 Offset

These parameters determine the offset applied to the Analog Out 1-4 values after the scale factor is applied. This allows the user to shift the range of the analog output.

PARAMETER NUMBER	400, 402, 404, 406
PARAMETER TYPE	Read and Write
MINIMUM VALUE	-20 Volts
MAXIMUM VALUE	+20 Volts
FACTORY DEFAULT	0
DRIVE UNITS	± 4096
PARAMETER ACCESS	Basic

Analog Out 1-4 Scale

These parameters determine the scale factor or gain for Analog In 1-4 values. A +2048 value corresponds to a +10V output signal at TB21. The value sent (linked) to Analog Out 1-4 is scaled by the corresponding scale parameter before it is offset and converted to an analog signal.

PARAMETER NUMBER	401, 403, 405, 407
PARAMETER TYPE	Read and Write
MINIMUM VALUE	-1
MAXIMUM VALUE	+1
FACTORY DEFAULT	+1
DRIVE UNITS	± 32767
PARAMETER ACCESS	Basic

Scale Factor	Drive Units
1	32767
1/2	16383
1/4	8192
1/16	2048

GROUP 7
Channel A

This function group contains the parameters needed to configure Channel A communications for the PLC Comm Adapter Board. Parameters 322-427 will not exist if the PLC Comm Adapter Board is configured for DH+ protocol.

ChA DIP Switch

This source parameter indicates the DIP switch settings used for Channel A of the PLC Comm Adapter Board.

PARAMETER NUMBER	303			
PARAMETER TYPE	Read Only			
MINIMUM VALUE	0000	0000	0000	0000
MAXIMUM VALUE	1111	1111	1111	1111
FACTORY DEFAULT	0000	0000	0000	0000
DRIVE UNITS	Bits			
PARAMETER ACCESS	Basic			

ChA LED State

This parameters contain the current LED state for Channel A as displayed by LEDs D4, D6 and D7 on the PLC Comm Adapter Board.

PARAMETER NUMBER	305
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	6
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Basic

ChA RIO In 1-8

These parameters are source parameters that contain the first eight words or groups of data from the PLC Controller output image table. The data is transferred to the drive by the RiO scanner every rack scan. The value can be used by the PLC Comm Board directly or by other drive functions through a configuration link. The available parameters depend on rack size and protocol selection.

NOTE: Parameter 329 is not used when Block Transfer Protocol is enabled.

PARAMETER NUMBER	322-329		
PARAMETER TYPE	Read and Write		
MINIMUM VALUE	-32767		
MAXIMUM VALUE	+32767		
FACTORY DEFAULT	None		
DRIVE UNITS	None		
PARAMETER ACCESS	Basic		
PAR 322 = First Word	PAR 323 = Second Word	PAR 324 = Third Word	
PAR 325 = Fourth Word	PAR 326 = Fifth Word	PAR 327 = Sixth Word	
PAR 328 = Seventh Word	PAR 329 = Eighth Word		

GROUP 7
Channel A

ChA RIO Out 1-8

These parameters are sink parameters that contain the first eight words or groups of data to the PLC Controller input image table. The data is transferred to the PLC Controller every rack scan. The value can be provided by the PLC Comm Board directly or by other drive functions through a configuration link. The available parameters depend on rack size and protocol selection.

NOTE: Parameter 358 is not used when Block Transfer Protocol is enabled.

PARAMETER NUMBER	351-358		
PARAMETER TYPE	Read and Write		
MINIMUM VALUE	-32767		
MAXIMUM VALUE	+32767		
FACTORY DEFAULT	None		
DRIVE UNITS	None		
PARAMETER ACCESS	Basic		
PAR 351 = First Word	PAR 352 = Second Word	PAR 353 = Third Word	
PAR 354 = Fourth Word	PAR 355 = Fifth Word	PAR 356 = Sixth Word	
PAR 357 = Seventh Word	PAR 358 = Eighth Word		

Redund Chan No

This parameter determines which channel number will be used by the 1336 FORCE for control purposes. Data and messages from the selected channel will be passes to the drive, while data and messages from the other channel will be discarded. The choices are 0 = Channel A and 1 = Channel B. This parameter is only active when both channels are set-up for RIO and the redundant mode is selected on the DIP switches. Image from the 1336 FORCE will go to both PLCs regardless of parameter setting.

PARAMETER NUMBER	427
PARAMETER TYPE	Read and Write
MINIMUM VALUE	0
MAXIMUM VALUE	1
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Basic

GROUP 8
Channel B

This function group contains the parameters needed to configure Channel B communications for the PLC Comm Adapter Board. Parameters 330-366 will not exist if the PLC Comm Adapter Board is configured for DH+ protocol.

ChB DIP Switch

This source parameter indicates the DIP switch settings used for Channel B of the PLC Comm Adapter Board.

PARAMETER NUMBER	304			
PARAMETER TYPE	Read Only			
MINIMUM VALUE	0000	0000	0000	0000
MAXIMUM VALUE	1111	1111	1111	1111
FACTORY DEFAULT	0000	0000	0000	0000
DRIVE UNITS	Bits			
PARAMETER ACCESS	Basic			

ChB LED State

This parameters contain the current LED state for Channel B as displayed by LEDs D4, D6 and D7 on the PLC Comm Adapter Board.

PARAMETER NUMBER	306
PARAMETER TYPE	Read Only
MINIMUM VALUE	0
MAXIMUM VALUE	6
FACTORY DEFAULT	0
DRIVE UNITS	None
PARAMETER ACCESS	Basic

ChB RIO In 1-8

These parameters are source parameters that contain the first eight words or groups of data from the PLC Controller output image table. The data is transferred to the drive by the RIO scanner every rack scan. The value can be used by the PLC Comm Board directly or by other drive functions through a configuration link. The available parameters depend on rack size and protocol selection.

NOTE: Parameter 337 is not used when Block Transfer Protocol is enabled.

PARAMETER NUMBER	330-337		
PARAMETER TYPE	Read and Write		
MINIMUM VALUE	-32767		
MAXIMUM VALUE	+32767		
FACTORY DEFAULT	None		
DRIVE UNITS	None		
PARAMETER ACCESS	Basic		
PAR 330 = First Word	PAR 331 = Second Word	PAR 332 = Third Word	
PAR 333 = Fourth Word	PAR 334 = Fifth Word	PAR 335 = Sixth Word	
PAR 336 = Seventh Word	PAR 337 = Eighth Word		

GROUP 8
Channel B

ChB RIO Out 1-8

These parameters are sink parameters that contain the first eight words or groups of data to the PLC Controller input image table. The data is transferred to the PLC Controller every rack scan. The value can be provided by the PLC Comm Board directly or by other drive functions through a configuration link. The available parameters depend on rack size and protocol selection.

NOTE: Parameter 366 is not used when Block Transfer Protocol is enabled.

PARAMETER NUMBER	359-366				
PARAMETER TYPE	Read and Write				
MINIMUM VALUE	-32767				
MAXIMUM VALUE	+32767				
FACTORY DEFAULT	None				
DRIVE UNITS	None				
PARAMETER ACCESS	Basic				
PAR 359	= First Word	PAR 360	= Second Word	PAR 361	= Third Word
PAR 362	= Fourth Word	PAR 363	= Fifth Word	PAR 364	= Sixth Word
PAR 365	= Seventh Word	PAR 366	= Eighth Word		

Advanced Programming

Chapter Objectives

Chapter 5 provides the following information.

- Block Transfer Explanation
- Block Transfer Message Structures
- DH+ Message Structures

Block Transfer

Discrete Transfer is the method used by a PLC Controller to transfer data to and from the PLC Comm Board during every rack scan. The PLC Comm Adapter Board transfers this data to and from the SCANport device.

Block Transfer is the method used by a PLC Controller to transfer data that does not require continuous updates. To perform this function, the PLC Comm Board provides a status word to the PLC during the normal discrete transfer scan. This status word occupies the first module group in the PLC I/O image table for the designated rack. The status word is then used by the PLC program to control the BTW and BTR functions of the PLC Controller.

Remote I/O Module Status Word

The **Remote I/O Status Word** is returned from the PLC Comm Board in addition to the Block Transfer Status Word. The Remote I/O Status is the first word associated with the rack in the PLC input image table. This status word indicates the condition of the PLC Comm Board and is not part of the standard Block Transfer Instructions in the PLC program. **Figures 5-1** and **5-2** detail the information contained in this word. Individual bits from this word are used in the PLC program to control the Block Transfer Functions as shown in the Block Transfer Examples in this chapter.




Figure 5-1 — PLC Comm Board Status Word

Block Transfer Ready — Indicates that the Scanbus Device and PLC Comm Board are communicating and are ready to process Block Transfers.

Block Transfer Write In Progress — Indicates a Block Transfer Write is in progress between the PLC Controller and PLC Comm Board. This bit is cleared when the data transfer to the PLC Comm Board is complete.

Block Transfer Read Data Available — Indicates the PLC Comm Board has data available for the PLC Controller to read.

Block Transfer Wait — Indicates that the PLC Comm Board is communicating with the SCANport device. This bit is cleared when the data transfer between the PLC Comm Board and SCANport device is complete.

Block Transfer Error — indicates that an error has occurred during communications with the SCANport device or the BTW data table is invalid.

Block Transfer Write Available — Indicates the PLC Comm Board is ready to receive a Block Transfer Write.

These bits are used in the PLC **Block Transfer Example** program on the following pages.




Figure 5-3 — Bit Timing

Data Storage

In order to use the Block Transfer Instructions in the PLC program, it is necessary to reserve several words for data storage. Some of these words are required for internal use by the Block Transfer Function and some contain the Block Transfer Message Information. In the PLC-5, the BTW and BTR blocks require the use of (2) sets of words. **Figures 5-5** and **5-6** illustrate the BTW and BTR blocks used for Block Transfer in the PLC-5 along with example information associated with these blocks. A brief description of the information contained in these blocks specifically for the PLC-5 follows. For more detailed information on the PLC-5 and the PLC-3 refer to your PLC Control Manual.




Figure 5-5 — PLC 5/15, 5/25 Block Transfer Instructions




Figure 5-6 — PLC 5/40, 5/60 Block Transfer Instructions

Rack — The rack number is determined by the RIO switch settings on the PLC Comm Board.

Group — The group number of the first group in the rack associated with the PLC Comm Board. In **Figure 5-5**, the rack has been set up as a full 8 group rack, therefore, the first group is 0. If 1/2 rack is selected the first group in the rack is 0 or 4. If 1/4 rack is selected, the first group in the rack is 0, 2, 4, or 6.

Module — The module number associated with the Block Transfer in the associated slot. In all cases this will be 0.

Control Block — A predefined set of words which contain bit information associated with the PLC Block Transfer Function. In the PLC-5/15 and 5/25, the control block requires (5) contiguous words. In **Figure 5-5**, Words N111:0 through N111:4 have been reserved for the bit array in the BTW block and Words N111:90 through N111:94 have been reserved for the BTR block. In the PLC-5/40 and 5/60 the control block may be either an integer type, and would require (5) contiguous words, or a Block Transfer Type and would require (1) element, as shown in **Figure 5-6**.

Data File — The address of the message sent by the BTW or received by the BTR block and contains both header and data information. The number of words required for the data file is dependent on the type of message being sent. In **Figure 5-5**, N111:5 is the first word in the data file for the BTW block and N111:50 is the first word for the BTR block. Refer to the message description section in this chapter for the header and data that must be included in the data file.

Length — The length of the Block Transfer Message in words. This will vary depending on the message being sent. The BTW and BTR instruction lengths may be different. Refer to the message examples in this section for the minimum lengths required for each message.

Continuous — Specifies whether the Block Transfer Block is to be executed continuously or only when the rung is true. This should always be set to N.

PLC-5 Block Transfer Rung Example The programs shown in **Figures 5-7** and **5-8** are examples of Block Transfer Programming for the PLC Comm Board. **Figure 5-7** is for a PLC5/15 or 5/25. **Figure 5-8** is used for PLC 5/20, 5/40, 5/60 or 5/80. The BTW AVAIL, BTR AVAIL, and BT ERROR bits from the module status word (I:020 in these examples) are used in these examples. The examples also show how user logic can be used to enable or disable the Block Transfer Operations.




Figure 5-7 — Block Transfer Example PLC 5/15, 5/25

The first rung causes a Block Transfer Write to the PLC Comm Board when the user logic bit is true. There is no data available from the drive for the PLC to read when the drive is ready to accept a Block Transfer Write.

The second rung causes a Block Transfer Read from the PLC Comm Board whenever there is data available from the drive for the PLC to read. The BTR rung is not conditioned with any user logic since a Block Transfer Read should occur whenever there is data available for the PLC to read from the PLC Comm Board.

The third rung causes a counter to increment each time the BT ERROR bit (I:020/14) goes true. This bit can be used to detect problems with the link from the PLC Controller to the SCANport device.




Figure 5-8 — Block Transfer Example PLC 5/20, 5/40, 5/60, 5/80

ADDITIONAL NOTES REGARDING BLOCK TRANSFER PROGRAMMING

1. A Block Transfer Subroutine can be used to transfer more data than can be moved in a single Block Transfer. If this is done, the Block Transfers must be carefully sequenced so that one Block Transfer Write and one Block Transfer Read occur for each portion of the sequence. One method of doing this is to set a latch bit to enable the Block Transfer Write and unlatch this bit when the Block Transfer Write is completed. When the Block Transfer Read completes, the program can then set up the data for the next transfer.
2. The status bits from the BTW and BTR Control files (EN, DN, ER) may change at any time during a program scan. If they are used by the program they should be copied to a file and the program should use the copied versions.

DH+ Communications

Each channel of the PLC Comm Adapter Board can be configured for DH+ communications. Configuration as a DH+ device allows the drive to look like a station on the DH+ link. DH+ features include:

- 57.6K, 115K and 230Kbaud communication rates.
- Parameter read and write messages for block of parameters.
- A method similar to RIO Block Transfer that allows the PLC Controller to issue drive messages via DH+.

DH+ Command Set

The PLC Comm Adapter Board supports a limited set of PC commands by emulating a section of PLC-5 memory. The memory area emulated determines what specific request or action the PLC Comm Board will take. Below is a list of the supported commands.

WHO ACTIVE The station number of the PLC Comm Adapter Board as defined by its DIP switch settings will be displayed on the WHO ACTIVE screen of the PLC software. It will read PLC-5/15 1336T next to the selected station number.

PLC 5 TYPED READ (N10:1-497) Memory area N10:0-497 translates into a read parameter value from the 1336 FORCE. Any attempts to read outside of this range will result in an error response. The values 0-497 are interpreted by the 1336 FORCE as parameter numbers. For example, to read the value of Parameter 133 the MSG instruction would request N10:133 with a size of one element. A size of 10 would read parameters 133-142.

PLC 5 TYPED WRITE (N10:1-497) Memory area N10:0-497 translates into one or more write parameter values to the 1336 FORCE. Any attempts to write outside of this range will result in an error response. The values 0-497 are interpreted by the Drive as parameter numbers. For example, to write a value to Parameter 119 — Preset Speed 1, the MSG instruction would specify N10:119 with a size of one element. A size of 10 will write to parameters 119-128.

PLC TYPED READ (N30:0-497) This request translates into a read parameter full message in the 1336 FORCE. Each parameter specified will result in 20 words of data (actual value, minimum value, maximum value, descriptor and parameter text. The maximum number of parameters that can be read using this service is (50).

PLC 5 TYPED READ (N40:1-39) This message emulates the RIO Block Transfer Functions available on the PLC Comm Adapter Board with the exception of the multiple parameter read. Refer to the message structure section that follows for details on the available messages and their use.

PLC 5 TYPED WRITE (N40:0-39) This message emulates the RIO Block Transfer Functions available on the PLC Comm Adapter Board with the exception of the multiple parameter write. Refer to the message structure section that follows for details on the available messages and their use.




Figure 5-9 — PLC5/15 Sample Program — RUNG 2:0


Rung 2:0

This rung will read parameters 100-109 on a continuous basis by using the Message Block enable bit to toggle the next message. The parameter information is stored in N20: 0-9 in the PLC. The drive DH+ station ID is 11.

Message Enable Bit
Drive 1
N7:0



Drive 1
Parameter Read



MESSAGE INSTRUCTION DATA MONITOR FOR CONTROL BLOCK N7:0

Communication Command:	PLC-5 TYPED READ	Ignore if timed-out:	0 TO
PLC-5 Data Table Address:	N20:0	to be retried:	0 NR
Size in Elements:	10	awaiting execution:	0 EW
Local/Remote:	LOCAL	continuous:	0 CO
Remote Station:	N/A	error:	0 ER
Link ID:	N/A	message done:	0 DN
Remote Link Type:	N/A	message transmitting:	0 ST
Local Node Address:	11	message enabled:	0 EN
Destination Data Table Address:	N10:100		

control bit addr: N7:0/15

ERROR CODE: 0 (DEC)


BLOCK SIZE = 9 WORDS

Press a function key to change a value.

>[

Rem Prog Forces: None	Data: Formatted	5/10 File Temp
Size in Elements		Toggle Bit

Figure 5-10 — PLC5/15 Sample Program — RUNG 2:1



MESSAGE INSTRUCTION DATA MONITOR FOR CONTROL BLOCK N7:0

Communication Command:	PLC-5 TYPED READ	Ignore if timed-out:	0 TO
PLC-5 Data Table Address:	N30:0	to be retried:	0 NR
Size in Elements:	30	awaiting execution:	0 EW
Local/Remote:	LOCAL	continuous:	0 CO
Remote Station:	N/A	error:	0 ER
Link ID:	N/A	message done:	0 DN
Remote Link Type:	N/A	message transmitting:	0 ST
Local Node Address:	11	message enabled:	0 EN
Destination Data Table Address:	N10:100		
		control bit addr:	N7:20/15
ERROR CODE:	0 (DEC)		
BLOCK SIZE =	10 WORDS		
Press a function key to change a value.			
>[
Rem Prog Forces:	None	Data: Formatted	5/10 File Temp
	Size in		Toggle
	Elements		Bit

Figure 5-11 — PLC5/15 Sample Program — RUNG 2:2

Block Transfer Descriptions

The descriptions provided in the remainder of this chapter contain the header and data configurations necessary to setup the data files in the Block Transfer Instructions. Header and data values will vary depending on the operation to be performed. Also included is a description of the status word that is returned from the drive and appears in the Block Transfer Read Header information.

Block Transfer Status Word

In most cases, Header Word 2 of the drive response will contain a negative value (bit 15 = 1) when a Block Transfer operation is unsuccessful. In most cases a Status Word is also returned and will indicate the reason for the Block Transfer failure. The location of the Status Word is typically Header Word 4 in the drive response, but will vary depending on the message. Shown below is an explanation of the Status Word codes.

STATUS WORD CODES

VALUE	DESCRIPTION
0	NO ERROR
1	SERVICE FAILED DUE TO AN INTERNAL REASON AND THE DRIVE COUNLD NOT PEFORM THE REQUEST — SOME MESSAGES ARE READ ONLY OR WRITE ONLY
2	SERVICE NOT SUPPORTED
3	INVALID VALUE IN BLOCK TRANSFER REQUEST HEADER WORD 2
4	INVALID VALUE IN BLOCK TRANSFER REQUEST HEADER WORD 3
5	INVALID VALUE IN BLOCK TRANSFER REQUEST HEADER WORD 4
6	DATA VALUE OUT OF RANGE
7	DRIVE STATE CONFLICT — THE DRIVE IS IN AN INCORRECT STATE TO PERFORM THE FUNCTION — THE DRIVE CANNOT BE RUNNING IN ORDER TO PERFORM CERTAIN FUNCTIONS

Table 5-12 below summarizes the valid command code which will appear in word 2 of the Block Transfer write Header Message. A complete description of the Block Transfer write Header Message is provided on the specified page.

CLASS	FUNCTION	PLC DECIMAL VALUE	PAGE
PARAMETER READ	Parameter Value Read	769	5-13
	Continuous Parameter Value Read	1	5-14
	Scattered Parameter Value Read	3	5-16
	Parameter Read Full	768	5-18
PARAMETER WRITE	Parameter Value Write	-31999	5-21
	Continuous Parameter Value Write	-32767	5-22
	Scattered Parameter Value Write	-32765	5-24
FAULT QUEUE	Fault Clear/Reset	-30976	5-26
	Trip Fault Queue Number	1793	5-27
	Fault Entry Read Full	1792	5-28
WARNING QUEUE	Warning Clear	-30720	5-30
	Warning Queue Read Full	2048	5-31
EE MEMORY REQUEST	Save/Recall/Initialize	-31988	5-33
LINK READ	Link Parameter Read	2304	5-34
	Continuous Parameter Link Read	4	5-35
	Scattered Parameter Link Read	5	5-37
LINK WRITE	Link Parameter Write	-30464	5-39
	Continuous Parameter Link Write	-32764	5-40
	Scattered Parameter Link Write	-32763	5-42
	Parameter Link Clear	-30464	5-44
USER TEST STRING	User Text String Read	261	5-45
	User Text String Write	-32507	5-47
CLOCK DATA	Real Time Clock Data Read	2816	5-49
	Real Time Clock Data Write	2816	5-51
RUN TIME ACCUMULATOR	Run Time Accumulator Data Read	2817	5-53
	Clear Run Time Accumulator	-29950	5-54
TIME STAMP	Reference Time Stamp Data Read	2816	5-55
	Reference Time Stamp Data Write	-29952	5-57
	Load Clock Into Reference Stamp	0	5-59

Table 5-12 — Block Transfer Message Word 2 Code Definitions

PARAMETER READ

Parameter Value Read

MESSAGE DESCRIPTION

This message is sent by the PLC Comm Board and will read the 16 bit parameter data value for the parameter number selected.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 4 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 3	HEADER WORD 1
PLC DECIMAL VALUE 769	HEADER WORD 2
PARAMETER NUMBER (Refer to Parameter List in Chapter 7)	DATA WORD 3

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 769 — MESSAGE OK -31999 — MESSAGE ERROR	HEADER WORD 2
PARAMETER NUMBER	HEADER WORD 3
PARAMETER VALUE OR STATUS WORD	HEADER WORD 4

MESSAGE OPERATION

The Parameter Value Read function specified in the BTW will read parameter values from the drive and place that value (or an error code) in Word 4 of the BTR Data File. The value shown will be in device units. If an error has occurred, Word 2 of the BTR will return a value of -31999 and Word 4 will contain the status code.

EXAMPLE

In this example the value of Parameter 20 was requested from a 1336 FORCE and a value of 4096 was returned. 4096 is the internal drive unit value for the Maximum Rated Voltage Parameter. This corresponds to a value of 100% drive rated volts in display units.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	769	20							
BTR DATA FILE	N10:90	0	769	20	4096						

● These values vary depending on parameters and products.

PARAMETER READ

Continuous Parameter Value Read

MESSAGE DESCRIPTION

This function reads a continuous list of parameters beginning with the starting parameter number. The number of parameters to be read is defined by the user.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 4 Words

BTR Instruction Length: 5-64 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 4	HEADER WORD 1
PLC DECIMAL VALUE 1	HEADER WORD 2
NUMBER OF PARAMETER VALUES TO READ	DATA WORD 3
STARTING PARAMETER NUMBER	DATA WORD 4

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 1 — MESSAGE OK -32767 — MESSAGE ERROR	HEADER WORD 2
NUMBER OF PARAMETER VALUES TO READ	DATA WORD 3
STARTING PARAMETER NUMBER	DATA WORD 4
VALUE NUMBER 1 OR STATUS WORD	DATA WORD 5
VALUE NUMBER 2 OR STATUS WORD	DATA WORD 6
VALUE NUMBER 3 OR STATUS WORD	DATA WORD 7
•	•
•	•
VALUE NUMBER 60 OR STATUS WORD	DATA WORD 64

MESSAGE OPERATION

The Continuous Parameter Value Read function specified in the BTW will read a consecutive group of parameter values from the device, beginning with the starting parameter number defined in Word 4 of the BTW message. The number of parameters to be read is defined in Word 3 of the BTW message. The values will return in the BTR response, beginning with Word 5 of the message. If an error has occurred in reading any of the values, the response will return a status word with a negative value instead of the parameter value.

Continuous Parameter Value Read
(continued)

EXAMPLE

In this example, 60 parameters were read from a 1336 FORCE, beginning with Parameter 10. The values of these parameters are returned in the BTR Data File, beginning at N10:94. The values are in drive units.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	4	1	60	10						
	N10:90	0	1	60	10	0	0	0	0	0	100
BTR DATA FILE	N10:100	0	50	4096	60	4096	1	6	0	1000	0
	N10:110	0	0	0	0	1000	1000	400	400	400	0
	N10:120	6144	2	4710	1	1	0	0	0	0	2
	N10:130	64	0	0	15	1024	0	0	5811	0	18
	N10:140	0	0	0	3597	0	12808	6	0	0	17952
	N10:150	0	0	0	0	0					

● These values vary depending on parameters and products.

PARAMETER READ

Scattered Parameter Value Read

MESSAGE DESCRIPTION

This function reads a scattered list of parameters with each parameter defined by the user. The number of parameters to be read must also be defined.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 5-63 Words

BTR Instruction Length: 5-63 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 5-63	HEADER WORD 1
PLC DECIMAL VALUE 3	HEADER WORD 2
NUMBER OF PARAMETER VALUES TO READ	DATA WORD 3
PARAMETER NUMBER 1	DATA WORD 4
0	DATA WORD 5
PARAMETER NUMBER 2	DATA WORD 6
0	DATA WORD 7
PARAMETER NUMBER 3	DATA WORD 8
0	DATA WORD 9
•	•
•	•
PARAMETER NUMBER 30	DATA WORD 62
0	DATA WORD 63

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 3 — MESSAGE OK -32765 — MESSAGE ERROR	HEADER WORD 2
NUMBER OF PARAMETER VALUES TO READ	DATA WORD 3
BIT 15 PARAMETER NUMBER 1	DATA WORD 4
PARAMETER VALUE OR STATUS WORD 1	DATA WORD 5
BIT 15 PARAMETER NUMBER 2	DATA WORD 6
PARAMETER VALUE OR STATUS WORD 2	DATA WORD 7
BIT 15 PARAMETER NUMBER 3	DATA WORD 8
PARAMETER VALUE OR STATUS WORD 3	DATA WORD 9
•	•
•	•
BIT 15 PARAMETER NUMBER 30	WORD 62 DATA
PARAMETER VALUE OR STATUS WORD 30	WORD 63 DATA

Scattered Parameter Value Read
(continued)

MESSAGE OPERATION

The Scattered Parameter Value Read function specified in the BTW will read a predefined group of parameter values, in any order, from the device. The number of parameters to be read is defined in Word 3 of the BTW Data File. The parameters to be read and their order is defined starting with Word 4. An unused word is left between each parameter request, so the BTR can respond with the parameter value as shown. If an error has occurred in reading any of the values, the response will return a Status Word with a negative value instead of the parameter value.

EXAMPLE

In this example, (8) parameters were read from a 1336 FORCE, as defined in Word 3 of the BTW Data File. The parameter numbers requested were 5, 7, 8, 20, 18, 17, 19 and 36. The BTR response returned the values of these parameters into the BTR Data File. These values are in drive units.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	19	3	●	●	0	●	0	●	0	●
	N10:20	0	●	●	●	0	●	0	●	0	
BTR DATA FILE	N10:90	0	3	●	●	●	●	●	●	●	●
	N10:100	●	●	●	●	●	●	●	●	●	
		4096	18	4096	17	51	19	60	36	6144	

● These values vary depending on parameters and products.

PARAMETER READ

Parameter Read Full

MESSAGE DESCRIPTION


This message request provides the requesting Remote I/O source with all known attributes for the parameters requested. This information includes the parameter's current value, descriptor, multiply and divide value, base value, offset value, text string, group element reference, minimum value, maximum value, default value, and unit text string.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 23 Words

MESSAGE STRUCTURE



Parameter Read Full
(continued)

BLOCK TRANSFER READ (CONTINUED)

PARAMETER TEXT CHARACTER 12 CHARACTER 11	HEADER WORD 15
PARAMETER TEXT CHARACTER 14 CHARACTER 13	HEADER WORD 16
PARAMETER TEXT CHARACTER 16 CHARACTER 15	HEADER WORD 17
FILE, GROUP, ELEMENT	HEADER WORD 18
MINIMUM VALUE	HEADER WORD 19
MAXIMUM VALUE	HEADER WORD 20
DEFAULT VALUE	HEADER WORD 21
UNIT TEXT CHARACTER 2 CHARACTER 1	HEADER WORD 22
UNIT TEXT CHARACTER 3 CHARACTER 4	HEADER WORD 23

MESSAGE OPERATION

The Parameter Read Full function specified in the BTW will retrieve the attributes of the parameter requested. The attributes for each parameter include the data, minimum and maximum values and the parameter text. The response message will return this information, beginning with Data Word 4. The parameter text will be returned with each data word containing (2) ASCII characters per word. This data will return with the first and second characters in opposite order as shown in the following example. If an error has occurred in the BT, Word 2 of the BTR will return a value of -32000.

Parameter Read Full
(continued)

EXAMPLE

In this example a Parameter Read Full was performed through Block Transfer on a 1336 FORCE. N10:10 shows the Header Message for the BTW. The Data is returned in the BTR Data File, starting with Word 4, for Parameter 20. Word 4 shows the present value in drive units. Word 5 through Word 9 provide scaling information, used to convert drive units to engineering units. Word 10 through Word 17 provide the parameter name. This example shows the response message N10:90 through N10:112 in both binary and ASCII. Note the ASCII information beginning with N10:99. The parameter name characters return in reverse order for each Word. N10:99 has the ASCII value of aM. To read this, invert the Word to read Ma. The next word ix, inverted gives you xi. These words along with the following two words, form the word Maximum. The parameter name Maximum Voltage can be seen in Word 10 through Word 17 of the response message. In addition, Word 23 is also returned in this format. This Word provides the units the parameter is defined in — In this example V/ls. Word 18 contains the file, group and element which are used to reference the parameter.

Words 19-21 contain the minimum, maximum and default values of this parameter.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	768	20							
	N10:90	0	768	20	4096	355	1	4096	460	0	24909
BTR DATA FILE	N10:100	27000	30061	8301	28502	29804	26465	8293	1794	1024	4915
	N10:110	4096	27734	29556							
	N10:90	0	0300	0014	1000	01c	0001	1000	01CC	0000	aM
	N10:100	ix	um	m	oV	tl	ga	e	07 02	04 00	13 0
	N10:110	1000	IV	st							
	N10:90	0	0300	0014	1000	01c	0001	1000	01CC	0000	aM

ASCII Display Values

● These Values vary depending on parameters and products.

PARAMETER WRITE

Parameter Value Write

MESSAGE DESCRIPTION

This message sent by the PLC Comm Board will read the 16 bit parameter data value for the parameter number selected.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 4 Words

BTR Instruction Length: 4 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 4	HEADER WORD 1
PLC DECIMAL VALUE -31999	HEADER WORD 2
PARAMETER NUMBER (Refer to Parameter List in Chapter 7)	DATA WORD 3
PARAMETER VALUE	DATA WORD 4

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 769 — MESSAGE OK -31999 — MESSAGE ERROR	HEADER WORD 2
PARAMETER NUMBER	DATA WORD 3
PARAMETER VALUE OR STATUS WORD	DATA WORD 4

MESSAGE OPERATION

The Parameter Value Write function specified in the BTW will send a new value (specified in Word 4 of the BTW Header Message) to the parameter specified in the BTW Header Word 3. The value must be in device units. If an error has occurred, Word 2 of the response will return a value of -31999 and Word 4 will contain a status code.

EXAMPLE

In this example the value a value of 4096 was sent to Parameter 20. 4096 is in drive units and indicates a value of 100% of rated drive volts as defined by Parameter 147 — Drive Rated Volts.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	4	-31999	20	4096						
BTR DATA FILE	N10:90	0	769	20	4096						

● These values vary depending on parameters and products.

PARAMETER WRITE

Continuous Parameter Value Write

MESSAGE DESCRIPTION


This function writes to a continuous list of parameters beginning with the starting parameter number.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 5-64 Words

BTR Instruction Length: 5-64 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

The Continuous Parameter Value Write function specified in the BTW will write data values to a consecutive group of parameters, beginning with the starting parameter number defined in Word 4 of the BTW message. The number of parameters to be written to is defined in Word 3 of the BTW message. If an error has occurred in writing to any of the values, the BTR Data File status word will contain an error code. If no error has occurred, it will return a value of 0.

Continuous Parameter Value Write
(continued)

EXAMPLE

In this example, (8) 1336 FORCE parameter values were written to, starting with Parameter 10. The eight parameter values are in device units. Since all of the parameter values were accepted, values of 0 were returned in the BTR status words.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	12	-32767	① 6	① 10	① 1	① 1	① 1	① 1	① 1	① 101
	N10:20	① 1	① 51								
BTR DATA FILE	N10:90	0	1	① 8	① 10	① 0	① 0	① 0	① 0	① 0	① 0
	N10:100	① 0	① 0								

① These values vary depending on parameters and products.

PARAMETER WRITE

Scattered Parameter Value Write

MESSAGE DESCRIPTION

This function writes to a list of parameters and returns the status of each parameter in its value location. Parameter numbers do not need to be in consecutive order.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 5-63 Words

BTR Instruction Length: 5-63 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 5-63	HEADER WORD 1
PLC DECIMAL VALUE -32765	HEADER WORD 2
NUMBER OF PARAMETER VALUES TO WRITE	DATA WORD 3
PARAMETER NUMBER 1	DATA WORD 4
PARAMETER VALUE 1	DATA WORD 5
PARAMETER NUMBER 2	DATA WORD 6
PARAMETER VALUE 2	DATA WORD 7
PARAMETER NUMBER 3	DATA WORD 8
PARAMETER VALUE 3	DATA WORD 9
•	•
•	•
PARAMETER NUMBER 30	DATA WORD 62
PARAMETER VALUE 30	DATA WORD 63

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 3 — MESSAGE OK -32765 — MESSAGE ERROR	HEADER WORD 2
NUMBER OF PARAMETER VALUES TO WRITE	DATA WORD 3
PARAMETER NUMBER 1	DATA WORD 4
STATUS WORD 1	DATA WORD 5
PARAMETER NUMBER 2	DATA WORD 6
STATUS 2 WORD 2	DATA WORD 7
PARAMETER NUMBER 3	DATA WORD 8
STATUS 3 WORD 3	DATA WORD 9
•	•
•	•
•	•
PARAMETER NUMBER 30	DATA WORD 62
PARAMETER VALUE OR STATUS WORD 30	DATA WORD 63

Scattered Parameter Value Write
(continued)

MESSAGE OPERATION

The Scattered Parameter Value Write function specified in the BTW will write data values to a defined group of parameters in any order. The number of parameters to be written to is defined in Word 3 of the BTW Data File. The parameters to be written to, and their order is defined starting with Word 4. The BTR response message will return a status word for each value written to, indicating if the parameter write was successful. If a transfer is not successful for a given parameter, the value in the parameter number location will be negative (bit 15 =1).

EXAMPLE

In this example, six parameters were written to in a 1336 FORCE. Word 3 of the BTW message (N10:12) defines the number of parameter values that will be transferred. Each parameter number followed by its value is listed in the message beginning with Word 4. The values are entered in drive units. The BTR response (N10:90) returns the status of each parameter write. If the BTW was successful, a zero will be returned. If an error has occurred, the response will return a status code for the error. Note that a value of 600 was sent to Parameter 392 (words N10:7 and N10:8). Word N10:91 indicates the Block Transfer operation was not completely successful. If all parameter values had been successfully transferred, N10:91 would contain the value 3. Word N10:97 contains a negative value indicating the error occurred with Parameter 392. Word N10:98 contains the status code indicating the parameter value is out of range.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	15	-32767	8	90	1	150	4	392	6000	31
	N10:20	10	10	2	12	5					
BTR DATA FILE	N10:90	0	-32765	8	90	0	150	0	392	6	31
	N10:100	0	10	0	12	0					

● These values vary depending on parameters and products.

FAULT QUEUE

Fault Clear/Reset

MESSAGE DESCRIPTION


This message will activate the fault functions shown below in the message request.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 4 Words

BTR Instruction Length: 4 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

The Fault Clear/Reset function specified in the BTW will send a fault handling request to the drive. A Fault Clear Request will clear the last fault that occurred. A Clear Fault Queue will clear the entire fault buffer. A drive reset will reset the drive, the fault queue will be cleared, and parameter information stored in EEPROM will be written to RAM. If an error has occurred in the BT, Word 2 of the BTR will return a value of -30976

EXAMPLE

In this example, a Fault Clear Request was sent to the drive through the BT. The BTR response indicated a successful clear by returning a value of 1792 in Word 2, and a value of 0 in Word 4.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	4	-30976	0	1						
BTR DATA FILE	N90:0	0	1792	0	0						

● These values vary depending on parameters and products.

FAULT QUEUE

Trip Fault Queue Number

MESSAGE DESCRIPTION


This message provides the fault queue number of the fault that caused the drive to trip.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 4 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

The Trip Fault Queue Number function will provide the entry number of the fault in the fault queue that tripped the drive. The BTR response contains that number in Word 4. The Fault Queue Number will equal 0 when the drive is not faulted. If an error has occurred in the BT, Word 2 of the response will be -30975.

EXAMPLE

In this example, the first entry in the drive fault queue has caused the drive to trip. Word 4 of the BTR indicates the entry number.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	1794	0							
BTR DATA FILE	N10:90	0	1794	0	1						

● These values vary depending on parameters and products.

FAULT QUEUE

Fault Entry Read Full

MESSAGE DESCRIPTION

This function reads the contents of the fault queue entry specified. A message is returned which includes the fault text and fault code associated with the specified fault queue entry and the time stamp associated with the fault.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 12 or 16 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE 3	HEADER WORD 1
PLC DECIMAL VALUE 1792	HEADER WORD 2
FAULT QUEUE ENTRY NUMBER	HEADER WORD 3

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 1792 — MESSAGE OK -30976 — MESSAGE ERROR	HEADER WORD 2
FAULT QUEUE ENTRY NUMBER	DATA WORD 3
FAULT TEXT CHARACTER 2 CHARACTER 1	DATA WORD 4
FAULT TEXT CHARACTER 4 CHARACTER 3	DATA WORD 5
FAULT TEXT CHARACTER 6 CHARACTER 5	DATA WORD 6
FAULT TEXT CHARACTER 8 CHARACTER 7	DATA WORD 7
FAULT TEXT CHARACTER 10 CHARACTER 9	DATA WORD 8
FAULT TEXT CHARACTER 12 CHARACTER 11	DATA WORD 9
FAULT TEXT CHARACTER 14 CHARACTER 13	DATA WORD 10
FAULT TEXT CHARACTER 16 CHARACTER 15	DATA WORD 11
FAULT CODE VALUE	DATA WORD 12
CLOCK TIME SECONDS REF	DATA WORD 13
CLOCK TIME HOUR MINUTE	DATA WORD 14
CLOCK TIME DATE DAY	DATA WORD 15
CLOCK TIME YEAR MONTH	DATA WORD 16

Fault Entry Read Full
(continued)

MESSAGE OPERATION

The Fault Queue Entry Read Full function specified in the BTW will read the contents of the fault queue specified in Word 3 of the BTW Message. The response will return the fault text which can be as ASCII text. The text will have every 2 characters in reverse order and return a time stamp, indicating the day and time the fault occurred. The Clock Time will be returned in the order as seen in the Header Message. This information should be viewed as ASCII text.

1. Reference will indicate AM, with a value of 0, or PM with a value of 1.
2. The Date will indicate the date of the month in ASCII.
3. The Day will indicate the day of the week, with 1 being Sunday, and 7 being Saturday.
4. The Year will indicate the number of the year with 1990 being a reference of 0. The year 1995 would return a value of 5.
5. The Month is a number between 0-12.

If an error has occurred, Word 2 of the response will return a negative value.

EXAMPLE

In this example, Fault Queue Entry #3 was retrieved from the drive. The BTR response returned the ASCII text Drive Reset Flt, with each character reversed. The Fault Code for this example is 22.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	1792	3							
BTR DATA FILE	N10:90	0	1792	3	29252	30313	8293	25938	25971	8308	27718
	N10:100	8308	22	7681	3594	5893	1282				
	N10:90	0	0700	0300	rD	Vi	e	eR	es	t	IF
	N10:100	1	0016	1E01	0E0A	1705	0502				

ASCII Display Values

● These Values vary depending on parameters and products.

WARNING QUEUE

Warning Clear

MESSAGE DESCRIPTION


This message will issue a clear warning fault command to the drive.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 4 Words

BTR Instruction Length: 4 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

The Warning Clear function specification in the BTW will send a warning fault handling request to the drive. Word 4 of the BTW defines which fault handling option is requested. A value of 1 in Word 4 will clear the last warning fault. A value of 21 will clear the entire warning fault queue. If an error has occurred in the request, Word 2 of the BTR will return a value of -30975. Word 4 of the BTR will respond to the request of BTW Word 4.

EXAMPLE

In this example, a Clear Fault/Warning request was sent to the drive by putting a value of 1 in Word 4 of the BTW. Word 2 of the BTR indicated a successful clear by returning a value of 2048.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	4	-30720	0	01						
BTR DATA FILE	N10:90	0	2048	0	1						

WARNING QUEUE

Warning Queue Read Full

MESSAGE DESCRIPTION

This message is provided to read the contents of a warning queue entry. The entry is specified by the instance, which includes information such as the warning code, fault event time stamp, and the fault text associated with the specified warning code. This is a read only message.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 16 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 3	HEADER WORD 1
PLC DECIMAL VALUE 2048	HEADER WORD 2
WARNING QUEUE ENTRY NUMBER	DATA WORD 3

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 2048 — MESSAGE OK -30720 — MESSAGE ERROR	HEADER WORD 2
WARNING QUEUE ENTRY NUMBER	HEADER WORD 3
WARNING TEXT CHARACTER 2 CHARACTER 1	DATA WORD 4
WARNING TEXT CHARACTER 4 CHARACTER 3	DATA WORD 5
WARNING TEXT CHARACTER 6 CHARACTER 5	DATA WORD 6
WARNING TEXT CHARACTER 8 CHARACTER 7	DATA WORD 7
WARNING TEXT CHARACTER 10 CHARACTER 9	DATA WORD 8
WARNING TEXT CHARACTER 12 CHARACTER 11	DATA WORD 9
WARNING TEXT CHARACTER 14 CHARACTER 13	DATA WORD 10
WARNING TEXT CHARACTER 16 CHARACTER 15	DATA WORD 11
WARNING CODE VALUE	DATA WORD 12
CLOCK TIME SECOND 1/10 OF SECOND	DATA WORD 13
CLOCK TIME HOUR MINUTE	DATA WORD 14

Warning Queue Read Full
(continued)

BLOCK TRANSFER READ (CONTINUED)

CLOCK TIME		DATA WORD 15
DATE	DAY	
CLOCK TIME		DATA WORD 16
YEAR	MONTH	

MESSAGE OPERATION

The Warning Queue Entry Read Full function specified in the BTW will read the contents of the warning queue specified in Word 3 of the BTW Message. The response will return the warning text which can be seen as ASCII text. The text will have every 2 characters in reverse order and return a time stamp indicating the day and time the warning occurred. The Clock Time will be returned in the order as seen in the header message. This information should be viewed As ASCII text.

1. The Day will indicate the day of the week, with 1 being Sunday, and 7 being Saturday.
2. The Year will indicate the number of the year with 1990 being a reference of 0. The year 1995 would return a value of 5.
3. The Month is a number between 0-12.
4. The Date and Time are in hexadecimal format.

EXAMPLE

In this example, Warning Queue Entry #1 was retrieved from the drive. The BTR returned the ASCII text VeI Fdbk LOSS, with each 2 characters reversed. The fault occurred at 10:14AM on Thursday Feb. 23rd, 1995.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	2048	1							
BTR DATA FILE	N10:90	0	2048	1	25942	8300	25670	27490	19488	29551	8307
	N10:100	8224	5048	7681	3594	5893	1282				
	N10:90	0000	0800	0001	eV	I	df	kb	L	so	s
	N10:100	0000	13B8	1E01	0E0A	1705	0502				

ASCII Display Values

EE MEMORY REQUEST

Save/Recall/Initialize

MESSAGE DESCRIPTION

This message is sent by the PLC Comm Board and will activate the EE functions detailed in the Message Request.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 4 Words

BTR Instruction Length: 3 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 4	HEADER WORD 1
PLC DECIMAL VALUE -31998	HEADER WORD 2
0	HEADER WORD 3
EE COMMAND	HEADER WORD 4

VALUE	EE COMMAND
00	NOT USED
01	EE SAVE
02	EE RECALL
03	EE DEFAULT INITIALIZE

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 770 — MESSAGE OK -31998 — MESSAGE ERROR	HEADER WORD 2
0	HEADER WORD 3

MESSAGE OPERATION

The EE Memory function allows 3 different Message Requests. EE Save will save parameter information from working memory or RAM to EEPROM. EE Recall will retrieve the last saved data from EEPROM and place it in working memory or RAM. EE Default Initialize will clear RAM and EEPROM and set all parameter values to default. If an error has occurred, Word 2 of the response will return a value of -31998.

EXAMPLE

This example is requesting an EEPROM save.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	4	-31998	0	1						
BTR DATA FILE	N10:90	0	770	0							

● These values vary depending on parameters and products.

LINK READ

Link Parameter Read

MESSAGE DESCRIPTION

This message will read the source parameter number that is linked to the specified sink parameter.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 4 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 3	HEADER WORD 1
PLC DECIMAL VALUE 2304	HEADER WORD 2
PARAMETER NUMBER (Refer to Parameter List in Chapter 7)	HEADER WORD 3

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 2304 — MESSAGE OK -30464 — MESSAGE ERROR	HEADER WORD 2
SINK PARAMETER LINK	HEADER WORD 3
SOURCE PARAMETER NUMBER	DATA WORD 4

MESSAGE OPERATION

The Link Parameter Read function specified in the BTW will read the source parameter that is linked to the requested sink parameter, defined in Word 3 of the Header Message. The source parameter will be returned in Word 4 of the BTR. If an error has occurred, Word 2 of the BTR will return a value of -30464.

EXAMPLE

In this example the link associated with Parameter 101 was requested from the drive. The BTW Header Message Word 4 defines the sink parameter of the requested link with a value of 101. The linked source Parameter 330 is returned in Word 4 of the BTR.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:0	3	2304	101	0						
BTR DATA FILE	N10:90	0	2304	101	330						

LINK READ

Continuous Parameter Link Read

MESSAGE DESCRIPTION

This message will return a list of up to 60 parameters that are linked to each drive parameter in a consecutive list.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 4 Words

BTR Instruction Length: 5-64 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 4	HEADER WORD 1
PLC DECIMAL VALUE 4	HEADER WORD 2
NUMBER OF PARAMETER LINKS TO READ	HEADER WORD 3
STARTING PARAMETER NUMBER	HEADER WORD 4

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 4 — MESSAGE OK -327664 — MESSAGE ERROR	HEADER WORD 2
NUMBER OF PARAMETER LINKS TO READ	HEADER WORD 3
STARTING PARAMETER NUMBER	HEADER WORD 4
SOURCE PARAMETER NUMBER 1	HEADER WORD 5
SOURCE PARAMETER NUMBER 2	HEADER WORD 6
•	HEADER WORD
•	HEADER WORD
•	HEADER WORD
SOURCE PARAMETER NUMBER 60	HEADER WORD 64

MESSAGE OPERATION

The request must specify the number of links to be read and the starting sink parameter number. The response source will return the parameter number of the source that is linked to each sink parameter. The response returns links for a consecutive list of sink parameters (up to 60 links). If a parameter is not linked, a value of 0 will be returned.

Continuous Parameter Link Read
(continued)

EXAMPLE

A Continuous Parameter Link Read is requested for 9 parameter links (word N10:2) beginning with Parameter 359. The Block Transfer response will return the source parameters that are linked to Parameters 359-367. In this example, Parameter 359 is linked to Parameter 56, Parameter 360 is linked to Parameter 143, Parameter 367 is linked to Parameter 380, and Parameters 361-366 are not linked.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:0	4	4	9	359						
BTR DATA FILE	N10:90	0	4	9	359	56	360	59	361	81	362
	N10:100	80	363	168	364	167	365	134	366	26	367
	N10:110	330									

LINK READ

Scattered Parameter Link Read

MESSAGE DESCRIPTION

This message will return a list of up to (30) links in the source-to-sink order found in the drive. The links do not have to be in consecutive order.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 5-63 Words

BTR Instruction Length: 5-63 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 5-63	HEADER WORD 1
PLC DECIMAL VALUE 5	HEADER WORD 2
NUMBER OF PARAMETER LINKS TO READ	HEADER WORD 3
PARAMETER NUMBER 1	HEADER WORD 4
0	HEADER WORD 5
PARAMETER NUMBER 2	HEADER WORD 6
0	HEADER WORD 7
•	HEADER WORD
•	HEADER WORD
•	•
PARAMETER NUMBER 30	HEADER WORD 62
0	HEADER WORD 63

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 5 — MESSAGE OK -32763 — MESSAGE ERROR	HEADER WORD 2
NUMBER OF PARAMETER LINKS TO READ	HEADER WORD 3
BIT 15 PARAMETER NUMBER 1	HEADER WORD 4
SOURCE PARAMETER NUMBER 1	HEADER WORD 5
BIT 15 PARAMETER NUMBER 2	HEADER WORD 6
SOURCE PARAMETER NUMBER 2	HEADER WORD 7
•	HEADER WORD
•	HEADER WORD
•	HEADER WORD
BIT 15 PARAMETER NUMBER 30	HEADER WORD 62
SOURCE PARAMETER NUMBER 30	HEADER WORD 63

MESSAGE OPERATION

The Scattered Parameter Link Read function requested in the BTW will read up to (30) non-consecutive links made in the drive. The user requests the desired link information by defining the sink parameters in the BTW message. The corresponding source parameters will be returned through the BTR response.

Scattered Parameter Link Read

(continued)

EXAMPLE

In this example, a Scattered Parameter Link Read of (4) links was requested through the BTW. Sink parameters 119-367 and 401 were defined as the desired links to be read. The BTR returned the corresponding source parameter values in the words reserved for this information. If an error had occurred for a specific link, the value returned would be negative.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	12	5	4	119	0	368	0	367	0	401
	N10:20	0									
BTW DATA FILE	N10:90	0	5	4	119 Sink	0 Source	368 Sink	331 Source	367	330	401
	N10:100	0									

LINK WRITE

Link Parameter Write

MESSAGE DESCRIPTION

This message will write the source parameter link to the sink parameter. This function will write to only (1) link Block Transfer.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 4 Words

BTR Instruction Length: 4 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

4	HEADER WORD 1
PLC DECIMAL VALUE -30464	HEADER WORD 2
SINK PARAMETER NUMBER (Refer to Parameter List in Chapter 7)	HEADER WORD 3
LINK PARAMETER	DATA WORD 4

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 2304 — MESSAGE OK -30464 — MESSAGE ERROR	HEADER WORD 2
SINK PARAMETER NUMBER	HEADER WORD 3
LINK NUMBER	HEADER WORD 4

MESSAGE OPERATION

The Link Parameter Write function specified in the BTW will write the corresponding source parameter link to the defined sink parameter. The sink parameter is defined in Word 3 of the BTW Data File with its' linked source defined in Word 4. If an error has occurred in the link, Word 20 of the BTR will return a value of -30464.

EXAMPLE

In this example, a link was defined between the sink parameter defined in Word 3 (Parameter 101 — External Velocity Reference), and the source parameter (Parameter 340 — Analog Input 2). The BTR Header Message confirmed the link by returning a value of 2034 in Word 2, and the link in order of sink-to-source in Words 3 &4.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:0	4	-30464	101	340						
BTR DATA FILE	N10:90	0	2304	101	340						

LINK WRITE

Continuous Parameter Link Write

MESSAGE DESCRIPTION

This message will write a list of up to (60) consecutive links to the drive, starting at the defined sink parameter.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 5-64 Words

BTR Instruction Length: 5-64 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 5-64	HEADER WORD 1
PLC DECIMAL VALUE -32764	HEADER WORD 2
NUMBER OF PARAMETER LINKS TO WRITE	HEADER WORD 3
PARAMETER NUMBER 1	HEADER WORD 4
LINK NUMBER 1	HEADER WORD 5
LINK NUMBER 2	HEADER WORD 6
•	HEADER WORD
•	HEADER WORD
•	HEADER WORD
LINK NUMBER 60	HEADER WORD 64

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 4 — MESSAGE OK -32764 — MESSAGE ERROR	HEADER WORD 2
NUMBER OF PARAMETER LINKS TO WRITE	HEADER WORD 3
STARTING PARAMETER NUMBER	HEADER WORD 4
STATUS NUMBER 1	HEADER WORD 5
STATUS NUMBER 2	HEADER WORD 6
•	HEADER WORD 7
•	HEADER WORD
•	HEADER WORD
•	HEADER WORD
STATUS NUMBER 60	HEADER WORD 64

MESSAGE OPERATION

The Continuous Parameter Link Write function specified in the BTW will write a set of consecutive links to the drive. The number of links to be written is defined in the BTW Header Word 3. The starting sink parameter is defined in Word 4. The consecutive link source parameters are then listed in the remaining Header Words. Up to (60) continuous links can be made with this Block Transfer function.

Continuous Parameter Link Write
(continued)

EXAMPLE

In this example, a group of (4) continuous links were sent to the drive, starting at Parameter 119. A length of (4) links is defined in Word 3 of the BTW Header Message. Word 4 defines the starting link sink Parameter 119. Words 5-8 then list the source parameters that will be linked to the (4) continuous sink parameters, Parameters 119-122. The BTR message will return the status of the write request. 0's returned in Words 5-8 indicate that the write was successful.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:0	8	-32764	4	119	339	340	341	342		
BTR DATA FILE	N10:90	0	4	4	119	0	0	0	0		

LINK WRITE

Scattered Parameter Link Write

MESSAGE DESCRIPTION


This function writes a scattered group of links to the drive.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 5-63 Words

BTR Instruction Length: 5-63 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

The Scattered Parameter Link Write function will read a predefined group of links in any order from the drive. The number of links to write is defined in Word 3 of the BTW. The links are then defined, followed by each sink's corresponding source in the remainder of the Header Message. Up to (30) scattered links can be defined with this function. If an incorrect link is defined, the BTR response will return a negative value for the sink parameter, followed by a status or error code. If there is an error in the BT, Word 2 of the BTR will contain a value of -32763.

Scattered Parameter Link Write
(continued)

EXAMPLE

In this example, (4) scattered links were written to the drive as defined in Word 3 of the BTW. Words 4 & 5 contain the 1st link with Word 4 defining the sink parameter, and Word 5 the corresponding source. Words 6 & 7 contain the next link, in the order of sink-to-source. The remaining (2) links are contained in Words 8-11. The BTR responds with 0 in place of the source parameter to indicate a successful link.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:0	11	-32763	4	387	146	388	168	367	330	368
	N10:20	331									
BTR DATA FILE	N10:90	0	5	4	387	0	388	0	367	0	368
	N10:100	0									

LINK WRITE

Parameter Link Clear

MESSAGE DESCRIPTION


This message will delete all user configured parameter links in the drive.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 4 Words

BTR Instruction Length: 3 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

When this request is sent to the drive, all drive parameter links configured by the user will be deleted. If an error has occurred, Word 2 of the BTR will return a value of -30464.

EXAMPLE

In this example a Parameter Link Clear request was sent through the BTW. The BTR was only required to check for an error.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:0	4	-30464	0	1						
BTR DATA FILE	N10:90	0	2304	0							

USER TEXT STRING

User Text String Read

MESSAGE DESCRIPTION

This read only message retrieves from the drive the user custom product name/location test string which identifies the product. The text string is 16 characters long.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 11 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 3	HEADER WORD 1
PLC DECIMAL VALUE 261	HEADER WORD 2
0	HEADER WORD 3

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 261 — MESSAGE OK -32507 — MESSAGE ERROR	HEADER WORD 2
0	HEADER WORD 3
PRODUCT TEXT CHARACTER 2 CHARACTER 1	DATA WORD 4
PRODUCT TEXT CHARACTER 4 CHARACTER 3	DATA WORD 5
PRODUCT TEXT CHARACTER 6 CHARACTER 5	DATA WORD 6
PRODUCT TEXT CHARACTER 8 CHARACTER 7	DATA WORD 7
PRODUCT TEXT CHARACTER 10 CHARACTER 9	DATA WORD 8
PRODUCT TEXT CHARACTER 12 CHARACTER 11	DATA WORD 9
PRODUCT TEXT CHARACTER 14 CHARACTER 13	DATA WORD 10
PRODUCT TEXT CHARACTER 16 CHARACTER 15	DATA WORD 11

MESSAGE OPERATION

This operation read the user’s custom product test string stored in the drive. The response message will return this information beginning with Data Word 4. The text string will be returned with each data word containing (2) ASCII characters per word. This data will return with the 1st and 2nd characters in opposite order as shown in the example. If an error has occurred in the BTW, Word 2 of the BTR will return a value of -32507.

User Text String Read
(continued)

EXAMPLE

In this example, the BTW defined a User Text String Read request in Word 2 of the BTW with a value of 261. The BTR responds by returning a value of 261 in Word 2, indicating a successful read. In addition, it returned the user text string in Data Words 4-11 stored in the drive. The characters of each word are returned in reverse order. The user text string should read Press 8 Level 2.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	261	0							
	N10:20	\00\03	\01\05	\00\00							
BTR DATA FILE	N10:90	0	261	0	21072	21317	8275	8248	17740	17750	8268
	N10:100	12832									
	N10:90	00\00	01\05	00\00	rP	se	s	8	el	ev	L
	N10:100	2									

ASCII Display Values

USER TEXT STRING

User Text String Write

MESSAGE DESCRIPTION

This is a write message that stores in the drive the user custom product name/location text string which identifies the product. The text string is 16 characters long.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 11 Words

BTR Instruction Length: 4 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 11	HEADER WORD 1
PLC DECIMAL VALUE -32507	HEADER WORD 2
0	HEADER WORD 3
PRODUCT TEXT CHARACTER 2 CHARACTER 1	DATA WORD 4
PRODUCT TEXT CHARACTER 4 CHARACTER 3	DATA WORD 5
PRODUCT TEXT CHARACTER 6 CHARACTER 5	DATA WORD 6
PRODUCT TEXT CHARACTER 8 CHARACTER 7	DATA WORD 7
PRODUCT TEXT CHARACTER 10 CHARACTER 9	DATA WORD 8
PRODUCT TEXT CHARACTER 12 CHARACTER 11	DATA WORD 9
PRODUCT TEXT CHARACTER 14 CHARACTER 13	DATA WORD 10
PRODUCT TEXT CHARACTER 16 CHARACTER 15	DATA WORD 11

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 261 — MESSAGE OK -32507 — MESSAGE ERROR	HEADER WORD 2
ERROR CODE	HEADER WORD 3
0	HEADER WORD 4

MESSAGE OPERATION

The User Text String Write allows the user to write a custom product identification string to the drive. this string can be 16 ASCII characters long, which will be defined in the 8 words of the BTW. The characters must be entered in the order shown, with the 1st and 2nd character of each word entered in opposite order as shown in the example.

User Text String Write
(continued)

EXAMPLE

In this example, the BTW defined a text string of Press 8 Level 2 to be written to the drive. This information was entered in ASCII text, with the 2 characters of each word entered in opposite order. The BTR returned a value of 261 in Word 2, indicating a successful write. In addition, it returned the text string in Words 4-11. If an error had occurred in the BTW, the BTR would have returned an error code in Word 3 of -32507.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	11	-32507	0	21072	21317	8275	8248	17740	17750	8268
	N10:20	12832									
	N10:10	000B	7EVB	0000	rP	se	s	8	el	ev	L
	N10:20	2									
BTR DATA FILE	N10:90	0	261	0	21072	21317	8275	8248	17740	17750	8268
	N10:100	12832									

ASCII Display Values

CLOCK DATA

Real Time Clock Data Read

MESSAGE DESCRIPTION


This message is provided to allow the drive to read the specified real time clock. The time in seconds, minutes and hours as well as day, date, month and year can be read by the slave device.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 7 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

This function will read the real time clock data from the drive. The Clock Time will be returned in the order as seen in the Header Message. This information should be viewed as ASCII text.

1. The Time is based on a 24 hour clock.
2. The Seconds are shown in seconds and 10^{ths} of seconds.
3. The Date will indicate the date of the month in Hex.
4. The Day will indicate the day of the week, with 1 being Sunday, and 7 being Saturday.
5. The Year will indicate the number of the year with 1990 being a reference of 0. The year 1995 would return a value of 5 — The 5th year on the 1990 year 0 base.
6. The month is a number between 0-12.

If an error occurs in the BT, a value of -29952 will be returned in Word 2 of the BTR response.

Real Time Clock Data Read
(continued)

EXAMPLE

In this example, the clock was read with a value of 2816 in Word 2 of the BTW. The BTR response indicated a successful read with a value of 2816 in Word 2.

1. Word 4 indicated a changing value for seconds.
2. The Hour value 0E indicates hour 14 of a 24 hour clock, or 2 PM. The minute value 0A indicates 10, or 12:10 PM.
3. The Date of 17 in ASCII is the 23rd and the 5th day of the month, or Thursday.
4. The Year 05 is 1995.
5. The Month of 02 is February.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	2816	0							
BTR DATA FILE	N10:90	0	2816	0	7681	3594	5893	1282			
	N10:90				0E01 S.IS	0E0A HrMin	1705 DateDay	0502 YrMth			

ASCII Display Values

CLOCK DATA

Real Time Clock Data Write

MESSAGE DESCRIPTION

This message is provided to allow the drive to write the specified real time clock data. This allows the user to write the new real time clock seconds, minutes and hours, as well as day, date, month and year.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 7 Words

BTR Instruction Length: 3 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 7	HEADER WORD 1
PLC DECIMAL VALUE 2816	HEADER WORD 2
0	HEADER WORD 3
CLOCK TIME SECONDS 1/10 OF SECOND	DATA WORD 4
CLOCK TIME HOUR MINUTE	DATA WORD 5
CLOCK TIME DATE DAY	DATA WORD 6
CLOCK TIME YEAR MONTH	DATA WORD 7

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 2816 — MESSAGE OK -29952 — MESSAGE ERROR	HEADER WORD 2
0	HEADER WORD 3

MESSAGE OPERATION

This function allows the user to define the clock data for the drive. The clock time will be written in the order as seen in the Header Message. This information should be sent as ASCII text.

1. The Time is based on a 24 hour clock.
2. Seconds are shown in seconds and 10^{ths} of seconds.
3. The Date will indicate the day of the month in Hex.
4. The Day will indicate the day of the week, with 1 being Sunday and 7 being Saturday.
5. The Year will indicate the number of the year will 1990 being a reference of 0. The year 1995 would be defined as a value of 5, the 5th year on the 1990 year 0 base.
6. The Month is a number 0-12.

If an error occurs in the BT, a value of -29952 will be returned in Word 2 of the BTR response.

Real Time Clock Data Write
(continued)

EXAMPLE

In this example, a real time clock data value of Friday, February 10, 1995 12:00 AM was written to the drive. Word 2 defines the request with a value of 2817.

1. Word 4 defines 0 seconds.
2. Word 5 defines 12:00.
3. Word 6 defines the 6th day (Friday) with a date of the 10th.
4. Word 7 defines 1995 and the second month (February).

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	7	2816	0	0000	0000	2566	1283			
	N10:10				0001 S:1S	0000 H:MM	0A06 Date:Day	0502 Y:MM			
BTR DATA FILE	N10:90	0	2816	0							

ASCII Display Values

RUN TIME ACCUMULATOR

Run Time Accumulator Data Read

MESSAGE DESCRIPTION

This message provides the drive with the accumulated time for running services. This information is in hours and is read only. The function is typically used as a maintenance feature.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 4 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 3	HEADER WORD 1
PLC DECIMAL VALUE 2817	HEADER WORD 2
0	HEADER WORD 3

PLC RESPONSE — BLOCK TRANSFER READ

0	HEADER WORD 1
PLC DECIMAL VALUE 2817 — MESSAGE OK -29951 — MESSAGE ERROR	HEADER WORD 2
0	DATA WORD 3
ACCUMULATED VALUE IN HOURS	DATA WORD 4

MESSAGE OPERATION

The Run Time Accumulator Data Read through BTR Word 4, provides the running service time in hours. As a maintenance feature, this information can be used to help define a service schedule for the drive.

The accumulated time can be cleared through a clear run time accumulator request. Information can then provide the accumulated run time between each scheduled service.

EXAMPLE

In this example, the BTW requested the accumulated running time of the drive. The BTR response returned a value of 41 in Word 4, indicating a running time of 41 hours. This value can be monitored, and when a specified running time has accumulated, a maintenance down time can be scheduled.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	0	2817	0							
BTR DATA FILE	N10:90	0	2817	0	41						

RUN TIME ACCUMULATOR

Clear Run Time Accumulator

MESSAGE DESCRIPTION


This message provides a way of clearing the run time accumulator data stored in the drive.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 3 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

The clear run time accumulator defines a value of -29950 in the BTW. Word 2 can clear the accumulated run time stored in the drive. This provides the user with the ability to monitor an accumulated time based on a specific event.

EXAMPLE

This function was requested to clear the accumulated run time in the drive since the last scheduled maintenance downtime. In this example, the BTW requested a clear with a value of -29950 in Word 2. The BTR response indicated a successful clear by returning a value of 2818 in Word 20 of the BTR Header Message.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	-29950	0							
BTR DATA FILE	N10:90	3	2818	0							

TIME STAMP

Reference Time Stamp Data Read

MESSAGE DESCRIPTION


The message will read the reference time stamp value from the drive.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 7 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

The reference time stamp can be defined by the user to monitor the time of a specific event. This function will allow this time to be read from the device. The time stamp will be returned in the order seen in the header message. This information should be viewed as ASCII text.

1. The Time is based on a 24 hour clock.
2. Seconds are shown in seconds and 10^{ths} of seconds.
3. The Date will indicate the day of the month in Hex.
4. The Day will indicate the day of the week, with 1 being Sunday and 7 being Saturday.
5. The Year will indicate the number of the year will 1990 being a reference of 0. The year 1995 would be defined as a value of 5, the 5th year on the 1990 year 0 base.
6. The Month is a number 0-12.

If an error occurs in the BTW, a value of -29952 will be returned in Word 2 of the BTR response.

Reference Time Stamp Data Read
(continued)

EXAMPLE

In this example, a reference time stamp data read was requested through the BTW. Word 2 of the BTW defines this request with a decimal value of 2816 for the PLC command code. The BTR response indicates a successful request with a returned value of 2816 in BTR Word 2. Words 4-7 then return the clock data. The clock data indicates a time stamp of February 1995, the 5th day of the week (Thursday), and a date of 23 (17 in ASCII). The hour, minutes and seconds will change according to the time.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	2816	0							
BTR DATA FILE	N10:90	0	2816	0	7681	3594	5893	1282			
	N10:90				0E01 SLIS	0E0A HMMin	1705 DateDay	0502 YAMth			

ASCII Display Values

TIME STAMP

Reference Time Stamp Data Write

MESSAGE DESCRIPTION


This message is provided to allow the drive to write the specified real time clock. This allows the drive to write a new reference stamp.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 7 Words

BTR Instruction Length: 3 Words

MESSAGE STRUCTURE



MESSAGE OPERATION

The Reference Time Stamp Data Write will allow the user to define a specific time stamp to be used in the drive.

1. The Time is based on a 24 hour clock.
2. Seconds are shown in seconds and 10^{ths} of seconds.
3. The Date will indicate the day of the month in Hex.
4. The Day will indicate the day of the week, with 1 being Sunday and 7 being Saturday.
5. The Year will indicate the number of the year will 1990 being a reference of 0. The year 1995 would be defined as a value of 5, the 5th year on the 1990 year 0 base.

Reference Time Stamp Data Write
(continued)

EXAMPLE

This example has defined the Reference Time Stamp as Friday, February the 10th, 1995. The Hour of 0 indicates a starting time of 10:00AM. This information can then be used to track scheduled maintenance down times or other information as desired.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	7	-29952	0	0	0	2566	1283			
	N10:10				0000	0000	0A06	0502			
BTR DATA FILE	N10:90	0	2816	0							

ASCII Display Values

TIME STAMP

Load Clock Info Reference Stamp

MESSAGE DESCRIPTION

This message will load the Real time clock data into the reference stamp.

PLC BLOCK TRANSFER INSTRUCTION DATA

BTW Instruction Length: 3 Words

BTR Instruction Length: 3 Words

MESSAGE STRUCTURE

PLC REQUEST — BLOCK TRANSFER WRITE

MESSAGE LENGTH 3	HEADER WORD 1
PLC DECIMAL VALUE 0	HEADER WORD 2
0	HEADER WORD 3

PLC RESPONSE — BLOCK TRANSFER READ

MESSAGE LENGTH 0	HEADER WORD 1
PLC DECIMAL VALUE 2818 — MESSAGE OK -29950 — MESSAGE ERROR	HEADER WORD 2
0	HEADER WORD 3

MESSAGE OPERATION

The Load Clock Info Reference Stamp function specified in the BTW will send the real time clock data to the reference stamp. The reference stamp time will then follow the real time clock data.

EXAMPLE

In this example, the request to load the real time clock data into the reference stamp was sent through the BTW. The BTR responded with a message of OK.

DATA FORMAT

		0	1	2	3	4	5	6	7	8	9
BTW DATA FILE	N10:10	3	0	0							
BTR DATA FILE	N10:90	0	2818	0							

End of Chapter

Troubleshooting

Chapter Objectives

Chapter 6 provides information to guide the user in trouble shooting the PLC Comm Adapter Board. Included is a listing and description of PLC Comm Adapter Faults, Error Messages, Alarms and logic responses to each.



ATTENTION: Only qualified personnel familiar with the 1336 FORCE drive system and associated machinery should perform troubleshooting or maintenance functions on the drive. Failure to comply may result in personnel injury and/or equipment damage.

Fault and Status LEDs




Figure 6-1 — PLC Comm Adapter Board Fault and Status LEDs

(15) Status and Fault LEDs are located on the PLC Comm Adapter Board to provide a visual indication of board operation. The PLC Comm Adapter Board is a non-serviceable device. Improper configuration will cause the PLC Comm Board to indicate faults and/or hardware malfunctions and should be verified first.

**Domino Processor (DP) Status
D1 and D2**

These LEDs reflect the operational status of the PLC Comm Adapter Board DIP switches.

LED	STATE	FUNCTION
D1 (RED)	LED LIT	DP Hard Fault
	LED NOT LIT	D2 On or Hardware Malfunction
	LED BLINKING	DP Soft Fault
D2 (GREEN)	LED LIT	Normal DP Operation
	LED NOT LIT	D1 On or Hardware Malfunction
	LED BLINKING	DP Warning

**Application Processor (AP) Status
D3 and D5**

These LEDs reflect the operational status of the application processor.

LED	STATE	FUNCTION
D3 (RED)	LED LIT	AP Hard Fault
	LED NOT LIT	D5 On or Hardware Malfunction
	LED BLINKING	AP Soft Fault
D5 (GREEN)	LED LIT	Normal AP Operation
	LED NOT LIT	D3 On or Hardware Malfunction
	LED BLINKING	AP Warning

**CHANNEL A Status
D4, D6 and D7**

**CHANNEL B Status
D8, D9 and D10**

These LEDs reflect the operational status of either RIO or DH+ communications.

LED	STATE	RIO FUNCTION	DH+ FUNCTION
D4 & D8 (RED)	LED BLINKING	PLC Has Rack Inhibited	Duplicate Node Address on DH+ Link
D6 & D9 (YELLOW)	LED LIT	None	Normal DH+ Communications
	LED NOT LIT	None	PLC Comm Adapter Faulted
	LED BLINKING	None	No Communications over DH+
D7 & D10 (GREEN)	LED LIT	Normal PLC Controller Communications	None
	LED NOT LIT	No Communications to PLC Controller	None
	LED BLINKING	PLC Controller is in Reset/Program/Test Mode	None

**PLC Comm Adapter Status
D11, D12, D13, D18 and D21**

These LEDs reflect the operational status of the drive permissives.

LED	STATE	FUNCTION
D11 (RED)	LED LIT	System Fault Present
	LED NOT LIT	System Fault Not Present
D12 (RED)	LED LIT	External Fault Present
	LED NOT LIT	External Fault Not Present
D13 (RED)	LED LIT	Normal Drive Stop Signal Present
	LED NOT LIT	Normal Drive Stop Signal Not Present
D18 (RED)	LED LIT	Motor Thermoguard Open
	LED NOT LIT	Motor Thermoguard Closed
D21 (GREEN)	LED LIT	Drive Enable Signal Present
	LED NOT LIT	Drive Disabled

Faults and Fault Queues

The 1336 FORCE monitors both internal and external operating conditions, responding to incorrect conditions as programmed by the user. Most malfunctions that occur will induce one of (2) types of faults.

HARD FAULTS

Hard faults indicate that the 1336 FORCE has detected a malfunction where internal recovery is not possible. Hard faults are the most severe type of faults. Hard faults indicate that a major internal component or system has failed and that drive functions may be lost. When a hard fault occurs, recovery can only be accomplished by issuing a Drive Reset or recycling drive power.

SOFT FAULTS

Soft faults exist to protect drive system components from internal and external malfunctions. Unlike hard faults, in most instances drive control can be maintained. Soft faults indicate that the 1336 FORCE has detected a malfunction that could cause damage to drive control or power components, or the motor. Soft faults may also indicate undesirable external operating conditions. Fault recovery can be accomplished by a clear fault command, clear fault queue, drive reset, or recycling of drive power.

FAULT QUEUE

All faults that have occurred are shown in the fault queue. Each entry shows the type of fault, and is time & date stamped at occurrence. Fault information is maintained in BRAM until it is commanded to be cleared by a Clear Fault Queue command. A Clear Fault command, Drive Reset command, or recycling drive power will not clear the queue. Up to (32) faults may be displayed, each with the following information.

- A fault queue entry number to indicate the position of the fault in the fault queue.
- A trip point (TP) to indicate which entry in the fault queue caused the drive to trip (all faults displayed previous to the TP fault occurred after the TP was logged).
- A (5) character decimal numbered fault code (described on the next page).
- The time and date that the fault occurred.
- Descriptive fault text plus all clear fault commands and when they were executed.

Fault Codes

FAULT TEXT AND CODE	DESCRIPTION	ACTION
Adpt BRAM Cksm 24009	(Soft Fault) Discrepancy between calculated and saved checksum for adapter data.	Reset drive. If fault persists, execute BRAM store, then reset drive and clear faults.
Main BRAM Cksm 24012	(Soft Fault) Discrepancy between calculated and saved checksum for main control board.	Reset drive. If fault persists, execute BRAM store, then reset drive and clear faults.
SW Malfunction 24013	(Hard Fault) Integrity check on board software has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
SW Malfunction 24014	(Hard Fault) Integrity check on board software has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
SW Malfunction 24015	(Hard Fault) Integrity check on board software has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
SW Malfunction 24016	(Hard Fault) Integrity check on board software has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
SW Malfunction 24017	(Hard Fault) Integrity check on board software has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
SW Malfunction 24018	(Hard Fault) Integrity check on board software has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
AP SW/LM Rev Err 24025	(Soft Fault) PLC Comm Adapter Board software/language module mismatch.	Verify board software and language module versions with A-B.
Adapter Config Err 24026	(Soft Fault) PLC Comm Adapter has detected that board DIP switch settings do not match values stored in BRAM.	Verify DIP switch settings and execute a BRAM store to save the new settings.
No AP LM Exists 25023	(Hard Fault) The PLC Comm Adapter has detected that a language module has not been installed on the PLC Comm Adapter.	Reset drive. If fault persists, replace the language module.
No AP LM Exists 25023	(Hard Fault) The PLC Comm Adapter has detected that a language module has not been installed on the PLC Comm Adapter.	Reset drive. If fault persists, replace the language module.

Fault Codes (continued)

FAULT TEXT AND CODE	DESCRIPTION	ACTION
No MC LM Exists 25024	(Hard Fault) The PLC Comm Adapted has detected that a language module has not been installed on the Main Control Board.	Reset drive. If fault persists, replace the language module.
SB Pt1 Timeout 26038	(Warning) Device connected to Port 1 of SCANport has been disconnected.	None
SB Pt1 Timeout 26039	(Warning) Device connected to Port 1 of SCANport has been disconnected.	None
SB Pt2 Timeout 26040	(Warning) Device connected to Port 2 of SCANport has been disconnected.	None
SB Pt3 Timeout 26041	(Warning) Device connected to Port 3 of SCANport has been disconnected.	None
SB Pt4 Timeout 26042	(Warning) Device connected to Port 4 of SCANport has been disconnected.	None
SB Comm Fault 26043	(Hard Fault) Integrity check on board hardware has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
HW Malfunction 34001	(Hard Fault) Integrity check on board hardware has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
HW Malfunction 34002	(Hard Fault) Integrity check on board hardware has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
HW Malfunction 34003	(Hard Fault) Integrity check on board hardware has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
HW Malfunction 34004	(Hard Fault) Integrity check on board hardware has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.
HW Malfunction 34005	(Hard Fault) Integrity check on board hardware has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.

Fault Codes (continued)

FAULT TEXT AND CODE	DESCRIPTION	ACTION														
ChA Protocol 34006	(Soft Fault) PLC Comm Adapter has detected an incorrect protocol DIP switch setting.	Check parameter 303 — DIP Switch ChA and refer to the table below to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board.														
		<table border="1"> <thead> <tr> <th>CHANNEL A LOW</th> <th>sw 1</th> <th>sw 2</th> </tr> </thead> <tbody> <tr> <td>RIO w/o Bk Trans</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>RIO w/ Bk Trans</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>DH+</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>None</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	CHANNEL A LOW	sw 1	sw 2	RIO w/o Bk Trans	OFF	OFF	RIO w/ Bk Trans	OFF	ON	DH+	ON	OFF	None	ON
CHANNEL A LOW	sw 1	sw 2														
RIO w/o Bk Trans	OFF	OFF														
RIO w/ Bk Trans	OFF	ON														
DH+	ON	OFF														
None	ON	ON														
ChB Protocol 34007	(Soft Fault) PLC Comm Adapter has detected an incorrect protocol DIP switch setting.	Check parameter 304 — DIP Switch ChB and refer to the table below to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board.														
		<table border="1"> <thead> <tr> <th>CHANNEL B LOW</th> <th>sw 1</th> <th>sw 2</th> </tr> </thead> <tbody> <tr> <td>RIO w/o Bk Trans</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>RIO w/ Bk Trans</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>DH+</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>None</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	CHANNEL B LOW	sw 1	sw 2	RIO w/o Bk Trans	OFF	OFF	RIO w/ Bk Trans	OFF	ON	DH+	ON	OFF	None	ON
CHANNEL B LOW	sw 1	sw 2														
RIO w/o Bk Trans	OFF	OFF														
RIO w/ Bk Trans	OFF	ON														
DH+	ON	OFF														
None	ON	ON														
ChA Baud Rate 34008	(Soft Fault) PLC Comm Adapter has detected an incorrect Baud rate DIP switch setting.	Check parameter 303 — DIP Switch ChA and refer to the table below to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board.														
		<table border="1"> <thead> <tr> <th>CHANNEL A LOW</th> <th>sw 3</th> <th>sw 4</th> </tr> </thead> <tbody> <tr> <td>56.7k Baud</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>115.2k Baud</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>230.4k Baud</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>None</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	CHANNEL A LOW	sw 3	sw 4	56.7k Baud	OFF	OFF	115.2k Baud	OFF	ON	230.4k Baud	ON	OFF	None	ON
CHANNEL A LOW	sw 3	sw 4														
56.7k Baud	OFF	OFF														
115.2k Baud	OFF	ON														
230.4k Baud	ON	OFF														
None	ON	ON														
ChB Baud Rate 34009	(Soft Fault) PLC Comm Adapter has detected an incorrect Baud rate DIP switch setting.	Check parameter 304 — DIP Switch ChB and refer to the table below to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board.														
		<table border="1"> <thead> <tr> <th>CHANNEL A LOW</th> <th>sw 3</th> <th>sw 4</th> </tr> </thead> <tbody> <tr> <td>56.7k Baud</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>115.2k Baud</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>230.4k Baud</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>None</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	CHANNEL A LOW	sw 3	sw 4	56.7k Baud	OFF	OFF	115.2k Baud	OFF	ON	230.4k Baud	ON	OFF	None	ON
CHANNEL A LOW	sw 3	sw 4														
56.7k Baud	OFF	OFF														
115.2k Baud	OFF	ON														
230.4k Baud	ON	OFF														
None	ON	ON														

Fault Codes (continued)

FAULT TEXT AND CODE	DESCRIPTION	ACTION																									
ChA Rack Rate 34010	(Soft Fault) PLC Comm Adapter has detected an incorrect rack size DIP switch setting.	Check parameter 303 — DIP Switch ChA and refer to the table below to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board. <table border="1"> <thead> <tr> <th>CHANNEL A</th> <th>SW 5</th> <th>SW 6</th> <th>Last</th> <th>Not Last</th> </tr> </thead> <tbody> <tr> <td>¼ Rack</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>½ Rack</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>¾ Rack</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>Full Rack</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> </tr> </tbody> </table> <p>Note: Full Rack can only have the Last/Not Last switch set to OFF.</p>	CHANNEL A	SW 5	SW 6	Last	Not Last	¼ Rack	OFF	OFF	OFF	ON	½ Rack	OFF	ON	OFF	ON	¾ Rack	ON	OFF	OFF	ON	Full Rack	ON	ON	OFF	OFF
CHANNEL A	SW 5	SW 6	Last	Not Last																							
¼ Rack	OFF	OFF	OFF	ON																							
½ Rack	OFF	ON	OFF	ON																							
¾ Rack	ON	OFF	OFF	ON																							
Full Rack	ON	ON	OFF	OFF																							
ChB Rack Size 34011	(Soft Fault) PLC Comm Adapter has detected an incorrect rack size DIP switch setting.	Check parameter 304 — DIP Switch ChB and refer to the table below to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board. <table border="1"> <thead> <tr> <th>CHANNEL A</th> <th>SW 5</th> <th>SW 6</th> <th>Last</th> <th>Not Last</th> </tr> </thead> <tbody> <tr> <td>¼ Rack</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>½ Rack</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>¾ Rack</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>Full Rack</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> </tr> </tbody> </table> <p>Note: Full Rack can only have the Last/Not Last bit set to 0.</p>	CHANNEL A	SW 5	SW 6	Last	Not Last	¼ Rack	OFF	OFF	OFF	ON	½ Rack	OFF	ON	OFF	ON	¾ Rack	ON	OFF	OFF	ON	Full Rack	ON	ON	OFF	OFF
CHANNEL A	SW 5	SW 6	Last	Not Last																							
¼ Rack	OFF	OFF	OFF	ON																							
½ Rack	OFF	ON	OFF	ON																							
¾ Rack	ON	OFF	OFF	ON																							
Full Rack	ON	ON	OFF	OFF																							
ChA Module Group 34012	(Soft Fault) PLC Comm Adapter has detected a Channel A module group that is not valid for the selected rack size.	Check parameter 303 — DIP Switch ChA and refer to the table below to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board. <table border="1"> <thead> <tr> <th>CHANNEL A HIGH</th> <th>sw 1</th> <th>sw 2</th> </tr> </thead> <tbody> <tr> <td>Module 0</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>Module 2</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>Module 4</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>Module 6</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	CHANNEL A HIGH	sw 1	sw 2	Module 0	OFF	OFF	Module 2	OFF	ON	Module 4	ON	OFF	Module 6	ON	ON										
CHANNEL A HIGH	sw 1	sw 2																									
Module 0	OFF	OFF																									
Module 2	OFF	ON																									
Module 4	ON	OFF																									
Module 6	ON	ON																									
ChB Module Group 34013	(Soft Fault) PLC Comm Adapter has detected a Channel B module group that is not valid for the selected rack size.	Check parameter 304 — DIP Switch ChB and refer to the table below to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board. <table border="1"> <thead> <tr> <th>CHANNEL B HIGH</th> <th>sw 1</th> <th>sw 2</th> </tr> </thead> <tbody> <tr> <td>Module 0</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>Module 2</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>Module 4</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>Module 6</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	CHANNEL B HIGH	sw 1	sw 2	Module 0	OFF	OFF	Module 2	OFF	ON	Module 4	ON	OFF	Module 6	ON	ON										
CHANNEL B HIGH	sw 1	sw 2																									
Module 0	OFF	OFF																									
Module 2	OFF	ON																									
Module 4	ON	OFF																									
Module 6	ON	ON																									

Fault Codes (continued)

FAULT TEXT AND CODE	DESCRIPTION	ACTION																									
Redund Rack Size 34014	(Soft Fault) PLC Comm Adapter has detected different rack sizes for Channels A & B when RIO with redundancy was selected.	Check parameters 303 & 304 — DIP Switch ChA & B. Refer to the table below to verify DIP switch settings — Both channels must have the same rack size. Reset drive. If Fault persists, replace PLC Comm Adapter Board. <table border="1"> <thead> <tr> <th>CHANNELS A/B LOW</th> <th>sw 5</th> <th>sw 6</th> <th>Last</th> <th>Not Last</th> </tr> </thead> <tbody> <tr> <td>¼ Rack</td> <td>OFF</td> <td>OFF</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>½ Rack</td> <td>OFF</td> <td>ON</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>¾ Rack</td> <td>ON</td> <td>OFF</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>Full Rack</td> <td>ON</td> <td>ON</td> <td>OFF</td> <td>OFF</td> </tr> </tbody> </table> <p>Note: Full Rack can only have the Last/Not Last switch set to OFF.</p>	CHANNELS A/B LOW	sw 5	sw 6	Last	Not Last	¼ Rack	OFF	OFF	OFF	ON	½ Rack	OFF	ON	OFF	ON	¾ Rack	ON	OFF	OFF	ON	Full Rack	ON	ON	OFF	OFF
CHANNELS A/B LOW	sw 5	sw 6	Last	Not Last																							
¼ Rack	OFF	OFF	OFF	ON																							
½ Rack	OFF	ON	OFF	ON																							
¾ Rack	ON	OFF	OFF	ON																							
Full Rack	ON	ON	OFF	OFF																							
Redund Diff Prot 34015	(Soft Fault) PLC Comm Adapter has detected redundant operation has been called for, but Channel A is not configured for RIO protocol.	Check parameters 303 & 304 — DIP Switch ChA & B. Refer to the tables below to verify DIP switch settings — Both channels must be configured for RIO protocol when using the redundant mode. If fault persists, replace PLC Comm Adapter Board. <table border="1"> <thead> <tr> <th>CHANNEL A LOW</th> <th>sw 8</th> </tr> </thead> <tbody> <tr> <td>Non-Redundant</td> <td>OFF</td> </tr> <tr> <td>Redundant</td> <td>ON</td> </tr> </tbody> </table> <table border="1"> <thead> <tr> <th>CHANNEL B LOW</th> <th>sw 1</th> <th>sw 2</th> </tr> </thead> <tbody> <tr> <td>RIO w/o Blk Trans</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>RIO w/ Blk Trans</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>DH+</td> <td>ON</td> <td>OFF</td> </tr> <tr> <td>None</td> <td>ON</td> <td>ON</td> </tr> </tbody> </table>	CHANNEL A LOW	sw 8	Non-Redundant	OFF	Redundant	ON	CHANNEL B LOW	sw 1	sw 2	RIO w/o Blk Trans	OFF	OFF	RIO w/ Blk Trans	OFF	ON	DH+	ON	OFF	None	ON	ON				
CHANNEL A LOW	sw 8																										
Non-Redundant	OFF																										
Redundant	ON																										
CHANNEL B LOW	sw 1	sw 2																									
RIO w/o Blk Trans	OFF	OFF																									
RIO w/ Blk Trans	OFF	ON																									
DH+	ON	OFF																									
None	ON	ON																									
SW Malfunction 34016	(Hard Fault) Integrity check on board software has failed.	Reset drive. If fault persists, replace PLC Comm Adapter Board.																									
ChA Dup Nodeaddr 36019	(Soft Fault) PLC Comm Adapter has detected a duplicate Channel A DH+ node address.	Check parameter 303 — DIP Switch ChA and refer to the table in Chapter 7 to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board.																									
ChB Dup Nodeaddr 36020	(Soft Fault) PLC Comm Adapter has detected a duplicate Channel B DH+ node address.	Check parameter 304 — DIP Switch ChB and refer to the table in Chapter 7 to verify DIP switch settings. Reset drive. If Fault persists, replace PLC Comm Adapter Board.																									

Fault Codes (continued)

FAULT TEXT AND CODE	DESCRIPTION	ACTION												
ChB Dup Nodeaddr 36020	(Soft Fault) PLC Comm Adapter has detected a duplicate Channel B DH+ node	Check parameter 304 — DIP Switch ChB. Refer to the PLC Comm Adapter Board DIP Switch Setting Table in Chapter 7 to verify DIP switch address. Reset drive. If Fault persists, replace PLC Comm Adapter Board.												
ChA Comm Loss 36021	(Warning) PLC Comm Adapter has detected a loss of Channel A communications with the PLC Controller.	<p>Check for a break in the communications cable. Verify that all connections are intact. Clear fault by issuing a Clear Fault, Drive Reset or recycle power.</p> <p>Check parameter 425 — ChA RIO Fit Sel to determine the drive response to faults. Par 425 is bit coded. Bits 1 & 0 determine the fault response to Channel A comm loss.</p> <table border="1"> <thead> <tr> <th>DRIVE FAULT RESPONSE</th> <th>BIT 1</th> <th>BIT 0</th> </tr> </thead> <tbody> <tr> <td>No Response</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>Warning</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>Fault Trip</td> <td>ON</td> <td>OFF</td> </tr> </tbody> </table> <p>Check parameter 436 — ChA Fit Sts. Bit 5 = 1 indicates a fault if configured to do so in parameter 425 — ChA RIO Fit Sel.</p> <p>Check parameter 437 — ChA Warn Sts. Bit 5 = 1 indicates a fault if configured to do so in parameter 426 — ChA RIO Warn Sel.</p>	DRIVE FAULT RESPONSE	BIT 1	BIT 0	No Response	OFF	OFF	Warning	OFF	ON	Fault Trip	ON	OFF
DRIVE FAULT RESPONSE	BIT 1	BIT 0												
No Response	OFF	OFF												
Warning	OFF	ON												
Fault Trip	ON	OFF												

Fault Codes (continued)

FAULT TEXT AND CODE	DESCRIPTION	ACTION												
ChA Comm Loss 36022	(Warning) PLC Comm Adapter has detected a loss of Channel B communications with the PLC Controller.	<p>Check for a break in the communications cable. Verify that all connections are intact. Clear fault by issuing a Clear Fault, Drive Reset or recycle power.</p> <p>Check parameter 430 — ChB RIO Fit Sel to determine the drive response to faults. Par 430 is bit coded. Bits 3 & 4 determine the fault response to Channel A comm loss.</p> <table border="1"> <thead> <tr> <th>DRIVE FAULT RESPONSE</th> <th>BIT 3</th> <th>BIT 4</th> </tr> </thead> <tbody> <tr> <td>No Response</td> <td>OFF</td> <td>OFF</td> </tr> <tr> <td>Warning</td> <td>OFF</td> <td>ON</td> </tr> <tr> <td>Fault Trip</td> <td>ON</td> <td>OFF</td> </tr> </tbody> </table> <p>Check parameter 438 — ChB Fit Sts. Bit 5 = 1 indicates a fault if configured to do so in parameter 430 — ChA RIO Fit Sel.</p> <p>Check parameter 439 — ChB Warn Sts. Bit 5 = 1 indicates a fault if configured to do so in parameter 430 — ChA RIO Warn Sel.</p>	DRIVE FAULT RESPONSE	BIT 3	BIT 4	No Response	OFF	OFF	Warning	OFF	ON	Fault Trip	ON	OFF
DRIVE FAULT RESPONSE	BIT 3	BIT 4												
No Response	OFF	OFF												
Warning	OFF	ON												
Fault Trip	ON	OFF												

Fault Codes (continued)

FAULT TEXT AND CODE	DESCRIPTION	ACTION
ChA Prg/Res/Test 36023	(Warning) PLC Comm Adapter has detected the PLC Controller being switched from the run mode to another mode.	<p>Check the PLC mode switch and the I/O control reset. Clear fault by issuing a Clear Fault, Drive Reset or recycle power.</p> <p>Check parameters 425 — ChA RIO Flt Sel and 426 — ChA RIO Warn Sel to determine the drive response to faults. These parameters determine the resolution of the condition, either fault, warning or none. Both parameters are bit coded.</p> <p>Bit 0 determines the resolution to ChA Prg/Res/Test. If bit 0 is set in par 425, a soft fault is logged. If bit 0 is reset in 425 and bit 0 in par 426 is set, a warning fault is logged. If bit 0 is reset in 425 and 426, no action is taken.</p> <p>Bit 1 determines the data output status of a fault. If set to 0, zeros are transmitted. If set to 1, the last state is transmitted.</p> <p>Check Parameter 436 — ChA Flt Sts. Bit 0 = 1 indicates a fault if configured to do so in Parameter 425 — ChA RIO Flt Sel.</p> <p>Check Parameter 437 — ChA Warn Sts. Bit 0 = 1 indicates a fault if configured to do so in Parameter 426 — ChA RIO Warn Sel.</p>

Fault Codes (continued)

FAULT TEXT AND CODE	DESCRIPTION	ACTION
ChB Prg/Res/Test 36024	(Warning) PLC Comm Adapter has detected the PLC Controller being switched from the run mode to another mode.	<p>Check the PLC mode switch and the I/O control reset. Clear fault by issuing a Clear Fault, Drive Reset or recycle power.</p> <p>Check parameters 430 — ChB RIO Fit Sel and 431 — ChB RIO Warn Sel to determine the drive response to faults. These parameters determine the resolution of the condition, either fault, warning or none. Both parameters are bit coded.</p> <p>Bit 0 determines the resolution to ChB Prg/Res/Test. If bit 0 is set in par 430, a soft fault is logged. If bit 0 is reset in 430 and bit 0 in par 426 is set, a warning fault is logged. If bit 0 is reset in 430 and 431, no action is taken.</p> <p>Bit 1 determines the data output status of a fault. If set to 0, zeros are transmitted. If set to 1, the last state is transmitted.</p> <p>Check parameter 438 — ChB Fit Sts. Bit 0 = 1 indicates a fault if configured to do so in parameter 430 — ChB RIO Fit Sel.</p> <p>Check parameter 439 — ChB Warn Sts. Bit 0 = 1 indicates a fault if configured to do so in parameter 431 — ChB RIO Warn Sel.</p>

Specifications and Supplemental Information

Chapter Objectives

Chapter 7 provides specifications and supplemental information including a parameter cross reference by number or name, parameter block diagrams, a hardware block diagram, and PLC Comm Adapter Board DIP switch settings.

Specifications

ENVIRONMENTAL

Operating Temperature: 0 to 40°C (32 to 104°F)
 Storage Temperature: – 40 to 70°C (– 40 to 158°F)
 Relative Humidity: 5 to 95% Non-Condensing
 Shock: 15G Peak for 11 ms Duration (±1.0 ms)
 Vibration: 0.006 Inches (0.15 mm) Displacement, 1G Peak

ELECTRICAL

Input Voltage: Supplied by Drive
 Input Frequency: NA
 Input Current: NA
 SCANport Load: 60 mA
 Vibration: 0.006 Inches (0.15 mm) Displacement, 1G Peak

COMMUNICATIONS

Drive Side: SCANport Peripheral Interface
 PLC Side: Allen-Bradley RIO/DH+
 BAUD Rates: 57.6k, 115.2k, 230.4k
 Rack Size: 1/4, 1/2, 3/4 or Full

PRODUCT COMPATIBILITY

The PLC Comm Adapter Board is designed to be used with the following terminal interface devices (TIDs).

Drive Tools

Allen-Bradley Programmable Controllers ●






- PLC-2/30 With SD2
- PLC-3
- SLC-500 With 1747-SN Scanner
- PLC-5/10, PLC-5/15, PLC-5/25 Family
- PLC-5/30, PLC-5/40, PLC-5/40L, PLC-5/60, PLC-5/40L Family, PLC-5/80
- PLC-6 Scanner Modules and Subscanners

- These adapters were tested with the current revision level of the listed PLC processors. Earlier versions of these processors may not be compatible.

Software Block Diagram

Shown in Figures 7-1a and 7-1b is the parameter linking and interaction within the PLC Comm Adapter Board.

SCANport



Logic Command





Figure 7-1a — PLC Comm Adapter Software Block Diagram

RIO Parameters



Analog I/O Parameters




Figure 7-1b — PLC Comm Adapter Software Block Diagram

Hardware Block Diagram




Figure 7-2 — PLC Comm Adapter Hardware Block Diagram

Parameter Cross Reference — By Number

No.	Name	Group ①	No.	Name	Group ①
300	PLC Comm Adpt ID	1 — Adapter Info	367	Pt6 Logic Cmd In	3 — SCANport I/O
301	PLC Comm Version	1 — Adapter Info	368	Pt7 Logic Cmd In	3 — SCANport I/O
302	PLC Comm Config	1 — Adapter Info	369	Stop Owner	5 — Owners
303	ChA DIP Switch	7 — Channel A	370	Dir Owner	5 — Owners
304	ChB DIP Switch	8 — Channel B	371	Start Owner	5 — Owners
305	ChA LED State	7 — Channel A	372	Jog 1 Owner	5 — Owners
306	ChB LED State	8 — Channel B	373	Jog 2 Owner	5 — Owners
309	Language Select	1 — Adapter Info	374	Set Ref Owner	5 — Owners
310	Adv/Basic Select	1 — Adapter Info	375	Local Owner	5 — Owners
314	Data In A1	3 — SCANport I/O	376	Flux Owner	5 — Owners
315	Data In A2	3 — SCANport I/O	377	Trim Owner	5 — Owners
316	Data In B1	3 — SCANport I/O	378	Ramp Owner	5 — Owners
317	Data In B2	3 — SCANport I/O	379	Cirflt Owner	5 — Owners
318	Data In C1	3 — SCANport I/O	386	SB Analog Out	3 — SCANport I/O
319	Data In C2	3 — SCANport I/O	387	Analog Out 1	6 — Analog I/O
320	Data In D1	3 — SCANport I/O	388	Analog Out 2	6 — Analog I/O
321	Data In D2	3 — SCANport I/O	389	Analog Out 3	6 — Analog I/O
322	ChA RIO In 1	7 — Channel A	390	Analog Out 4	6 — Analog I/O
323	ChA RIO In 2	7 — Channel A	391	SB Analog Sel	3 — SCANport I/O
324	ChA RIO In 3	7 — Channel A	392	An In 1 Offset	6 — Analog I/O
325	ChA RIO In 4	7 — Channel A	393	An In 1 Scale	6 — Analog I/O
326	ChA RIO In 5	7 — Channel A	394	An In 2 Offset	6 — Analog I/O
327	ChA RIO In 6	7 — Channel A	395	An In 2 Scale	6 — Analog I/O
328	ChA RIO In 7	7 — Channel A	396	An In 3 Offset	6 — Analog I/O
329	ChA RIO In 8	7 — Channel A	397	An In 3 Scale	6 — Analog I/O
330	ChB RIO In 1	8 — Channel B	398	An In 4 Offset	6 — Analog I/O
331	ChB RIO In 2	8 — Channel B	399	An In 4 Scale	6 — Analog I/O
332	ChB RIO In 3	8 — Channel B	400	An Out 1 Offset	6 — Analog I/O
333	ChB RIO In 6	8 — Channel B	401	An Out 1 Scale	6 — Analog I/O
336	ChB RIO In 7	8 — Channel B	402	An Out 2 Offset	6 — Analog I/O
337	ChB RIO In 8	8 — Channel B	403	An Out 2 Scale	6 — Analog I/O
338	SB Analog In	3 — SCANport I/O	404	An Out 3 Offset	6 — Analog I/O
339	Analog In 1	6 — Analog I/O	405	An Out 3 Scale	6 — Analog I/O
340	Analog In 2	6 — Analog I/O	406	An Out 4 Offset	6 — Analog I/O
341	Analog In 3	6 — Analog I/O	407	An Out 4 Scale	6 — Analog I/O
342	Analog In 4	6 — Analog I/O	408	Port Enable Mask	4 — Masks
343	Data Out A1	3 — SCANport I/O	409	Dir Mask	4 — Masks
344	Data Out A2	3 — SCANport I/O	410	Start Mask	4 — Masks
345	Data Out B1	3 — SCANport I/O	411	Jog Mask	4 — Masks
346	Data Out B2	3 — SCANport I/O	412	Ref Mask	4 — Masks
347	Data Out C1	3 — SCANport I/O	413	Cir Fault Mask	4 — Masks
348	Data Out C2	3 — SCANport I/O	414	Reset Drive Mask	4 — Masks
349	Data Out D1	3 — SCANport I/O	415	Local Mask	4 — Masks
350	Data Out D2	3 — SCANport I/O	416	SB Default Ref	3 — SCANport I/O
351	ChA RIO Out 1	7 — Channel A	425	ChA RIO Flt Sel	2 — Adapter Diag
352	ChA RIO Out 2	7 — Channel A	426	ChA RIO Warn Sel	2 — Adapter Diag
353	ChA RIO Out 3	7 — Channel A	427	Redund Chan No	7 — Channel A
354	ChA RIO Out 4	7 — Channel A	430	ChB RIO Flt Sel	2 — Adapter Diag
355	ChA RIO Out 5	7 — Channel A	431	ChB RIO Warn Sel	2 — Adapter Diag
356	ChA RIO Out 6	7 — Channel A	435	DIP Fault Setup	2 — Adapter Diag
357	ChA RIO Out 7	7 — Channel A	436	ChA Fault Sts	2 — Adapter Diag
358	ChA RIO Out 8	7 — Channel A	437	ChA Warn Sts	2 — Adapter Diag
359	ChB RIO Out 1	8 — Channel B	438	ChB Fault Sts	2 — Adapter Diag
360	ChB RIO Out 2	8 — Channel B	439	ChB Warn Sts	2 — Adapter Diag
361	ChB RIO Out 3	8 — Channel B	440	SB Fault Sel	2 — Adapter Diag
362	ChB RIO Out 4	8 — Channel B	441	SB Warn Sel	2 — Adapter Diag
363	ChB RIO Out 5	8 — Channel B	442	SB Fault Sts	2 — Adapter Diag
364	ChB RIO Out 6	8 — Channel B	443	SB Warn Sts	2 — Adapter Diag
365	ChB RIO Out 7	8 — Channel B			
366	ChB RIO Out 8	8 — Channel B			

① Parameters included in Groups 7 and 8 will vary depending upon the selected communications present.

② Shaded Parameters do not exist when DH+ is selected. Inputs are variable and dependent on rack size and whether block transfer is enabled.

Parameter Cross Reference — By Name

No.	Name	Group ①	No.	Name	Group ①
310	Adv/Basic Select	1 — Adapter Info	431	ChB RIO Warn Sel	2 — Adapter Diag
392	An In 1 Offset	6 — Analog I/O	439	ChB Warn Sts	2 — Adapter Diag
393	An In 1 Scale	6 — Analog I/O	413	Clr Fault Mask	4 — Masks
394	An In 2 Offset	6 — Analog I/O	379	Clrflt Owner	5 — Owners
395	An In 2 Scale	6 — Analog I/O	435	DIP Fault Setup	2 — Adapter Diag
396	An In 3 Offset	6 — Analog I/O	409	Dir Mask	4 — Masks
397	An In 3 Scale	6 — Analog I/O	370	Dir Owner	5 — Owners
398	An In 4 Offset	6 — Analog I/O	376	Flux Owner	5 — Owners
399	An In 4 Scale	6 — Analog I/O	307	Func Bk Chksum	1 — Adapter Info
400	An Out 1 Offset	6 — Analog I/O	308	Func Bk ID	1 — Adapter Info
401	An Out 1 Scale	6 — Analog I/O	372	Jog 1 Owner	5 — Owners
402	An Out 2 Offset	6 — Analog I/O	373	Jog 2 Owner	5 — Owners
403	An Out 2 Scale	6 — Analog I/O	411	Jog Mask	4 — Masks
404	An Out 3 Offset	6 — Analog I/O	309	Language Select	1 — Adapter Info
405	An Out 3 Scale	6 — Analog I/O	415	Local Mask	4 — Masks
406	An Out 4 Offset	6 — Analog I/O	375	Local Owner	5 — Owners
407	An Out 4 Scale	6 — Analog I/O	300	PLC Comm Adpt ID	1 — Adapter Info
339	Analog In 1	6 — Analog I/O	302	PLC Comm Config	1 — Adapter Info
340	Analog In 2	6 — Analog I/O	301	PLC Comm Version	1 — Adapter Info
341	Analog In 3	6 — Analog I/O	408	Port Enable Mask	4 — Masks
342	Analog In 4	6 — Analog I/O	367	Pt6 Logic Cmd In	3 — SCANport I/O
387	Analog Out 1	6 — Analog I/O	368	Pt7 Logic Cmd In	3 — SCANport I/O
388	Analog Out 2	6 — Analog I/O	378	Ramp Owner	5 — Owners
389	Analog Out 3	6 — Analog I/O	427	Redund Chan No	7 — Channel A ②
390	Analog Out 4	6 — Analog I/O	412	Ref Mask	4 — Masks
303	ChA DIP Switch	7 — Channel A	414	Reset Drive Mask	4 — Masks
436	ChA Fault Sts	2 — Adapter Diag	338	SB Analog In	3 — SCANport I/O
305	ChA LED State	7 — Channel A	386	SB Analog Out	3 — SCANport I/O
425	ChA RIO Fit Sel	2 — Adapter Diag	391	SB Analog Sel	3 — SCANport I/O
322	ChA RIO In 1	7 — Channel A	416	SB Default Ref	3 — SCANport I/O
323	ChA RIO In 2	7 — Channel A	440	SB Fault Sel	2 — Adapter Diag
324	ChA RIO In 3	7 — Channel A	442	SB Fault Sts	2 — Adapter Diag
325	ChA RIO In 4	7 — Channel A	441	SB Warn Sel	2 — Adapter Diag
326	ChA RIO In 5	7 — Channel A	443	SB Warn Sts	2 — Adapter Diag
327	ChA RIO In 6	7 — Channel A	314	Data In A1	3 — SCANport I/O
328	ChA RIO In 7	7 — Channel A	315	Data In A2	3 — SCANport I/O
329	ChA RIO In 8	7 — Channel A	316	Data In B1	3 — SCANport I/O
351	ChA RIO Out 1	7 — Channel A	317	Data In B2	3 — SCANport I/O
352	ChA RIO Out 2	7 — Channel A	318	Data In C1	3 — SCANport I/O
353	ChA RIO Out 3	7 — Channel A	319	Data In C2	3 — SCANport I/O
354	ChA RIO Out 4	7 — Channel A	320	Data In D1	3 — SCANport I/O
355	ChA RIO Out 5	7 — Channel A	321	Data In D2	3 — SCANport I/O
356	ChA RIO Out 6	7 — Channel A	343	Data Out A1	3 — SCANport I/O
357	ChA RIO Out 7	7 — Channel A	344	Data Out A2	3 — SCANport I/O
358	ChA RIO Out 8	7 — Channel A ②	345	Data Out B1	3 — SCANport I/O
426	ChA RIO Warn Sel	2 — Adapter Diag	346	Data Out B2	3 — SCANport I/O
437	ChA Warn Sts	2 — Adapter Diag	347	Data Out C1	3 — SCANport I/O
304	ChB DIP Switch	8 — Channel B	348	Data Out C2	3 — SCANport I/O
438	ChB Fault Sts	2 — Adapter Diag	349	Data Out D1	3 — SCANport I/O
306	ChB LED State	8 — Channel B	350	Data Out D2	3 — SCANport I/O
430	ChB RIO Fit Sel	2 — Adapter Diag	374	Set Ref Owner	5 — Owners
330	ChB RIO In 1	8 — Channel B	410	Start Mask	4 — Masks
331	ChB RIO In 2	8 — Channel B	371	Start Owner	5 — Owners
332	ChB RIO In 3	8 — Channel B	369	Stop Owner	5 — Owners
333	ChB RIO In 6	8 — Channel B	377	Trim Owner	5 — Owners
336	ChB RIO In 7	8 — Channel B			
337	ChB RIO In 8	8 — Channel B			
359	ChB RIO Out 1	8 — Channel B			
360	ChB RIO Out 2	8 — Channel B			
361	ChB RIO Out 3	8 — Channel B			
362	ChB RIO Out 4	8 — Channel B			
363	ChB RIO Out 5	8 — Channel B			
364	ChB RIO Out 6	8 — Channel B			
365	ChB RIO Out 7	8 — Channel B			
366	ChB RIO Out 8	8 — Channel B ②			

① Parameters included in Groups 7 and 8 will vary depending upon the selected communications present.

② Shaded Parameters do not exist when DH+ is selected. Inputs are variable and dependent on rack size and whether block transfer is enabled.

PLC Comm Adapter Board DIP Switch Settings

DIP SWITCHES U2 (CHANNEL A) OR U4 (CHANNEL B)								DIP SWITCHES U3 (CHANNEL A) OR U5 (CHANNEL B)								
SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	
PROTOCOL																
RIO w/o Block Transfer		OFF	OFF													
RIO w/ Block Transfer		OFF	ON													
DH+		ON	OFF													
Not Used		ON	ON													
BAUD Rate																
57.6K		OFF	OFF													
115.2K		OFF	ON													
230.4K		ON	OFF													
Not Used		ON	ON													
RIO Rack Size																
1/4		OFF	OFF													
1/2		OFF	ON													
3/4		ON	OFF													
Full		ON	ON													
Not Last / Last																
Last						ON										
Not Last						OFF										
Redundant																
Yes						ON										
No						OFF										
RIO Starting Group																
0						OFF	OFF									
2						OFF	ON									
4						ON	OFF									
6						ON	ON									
RIO Rack Address or DH+ Station Address																
● 00						OFF	OFF	OFF	OFF	OFF	OFF					
01						OFF	OFF	OFF	OFF	OFF	ON					
02						OFF	OFF	OFF	OFF	ON	OFF					
03						OFF	OFF	OFF	OFF	ON	ON					
04						OFF	OFF	OFF	ON	OFF	OFF					
05						OFF	OFF	OFF	ON	OFF	ON					
06						OFF	OFF	OFF	ON	ON	OFF					
07						OFF	OFF	OFF	ON	ON	ON					
10						OFF	OFF	ON	OFF	OFF	OFF					
11						OFF	OFF	ON	OFF	OFF	ON					
12						OFF	OFF	ON	OFF	ON	OFF					
13						OFF	OFF	ON	OFF	ON	ON					
14						OFF	OFF	ON	ON	OFF	OFF					
15						OFF	OFF	ON	ON	OFF	ON					
16						OFF	OFF	ON	ON	ON	OFF					
17						OFF	OFF	ON	ON	OFF	ON					

● Address 00 only valid for DH+ configuration.

	DIP SWITCHES U2 (CHANNEL A) OR U4 (CHANNEL B)								DIP SWITCHES U3 (CHANNEL A) OR U5 (CHANNEL B)							
	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8	SW1	SW2	SW3	SW4	SW5	SW6	SW7	SW8
RIO Rack Address or DH+ Station Address																
20											OFF	ON	OFF	OFF	OFF	OFF
21											OFF	ON	OFF	OFF	OFF	ON
22											OFF	ON	OFF	OFF	ON	OFF
23											OFF	ON	OFF	OFF	ON	ON
24											OFF	ON	OFF	ON	OFF	OFF
25											OFF	ON	OFF	ON	OFF	ON
26											OFF	ON	OFF	ON	ON	OFF
27											OFF	ON	OFF	ON	ON	ON
30											OFF	ON	ON	OFF	OFF	OFF
31											OFF	ON	ON	OFF	OFF	ON
32											OFF	ON	ON	OFF	ON	OFF
33											OFF	ON	ON	OFF	ON	ON
34											OFF	ON	ON	ON	OFF	OFF
35											OFF	ON	ON	ON	OFF	ON
36											OFF	ON	ON	ON	ON	OFF
37											OFF	ON	ON	ON	ON	ON
40											ON	OFF	OFF	OFF	OFF	OFF
41											ON	OFF	OFF	OFF	OFF	ON
42											ON	OFF	OFF	OFF	ON	OFF
43											ON	OFF	OFF	OFF	ON	ON
44											ON	OFF	OFF	ON	OFF	OFF
45											ON	OFF	OFF	ON	OFF	ON
46											ON	OFF	OFF	ON	ON	OFF
47											ON	OFF	OFF	ON	ON	ON
50											ON	OFF	ON	OFF	OFF	OFF
51											ON	OFF	ON	OFF	OFF	ON
52											ON	OFF	ON	OFF	ON	OFF
53											ON	OFF	ON	OFF	ON	ON
54											ON	OFF	ON	ON	OFF	OFF
55											ON	OFF	ON	ON	OFF	ON
56											ON	OFF	ON	ON	ON	OFF
57											ON	OFF	ON	ON	ON	ON
60											ON	ON	OFF	OFF	OFF	OFF
61											ON	ON	OFF	OFF	OFF	ON
62											ON	ON	OFF	OFF	ON	OFF
63											ON	ON	OFF	OFF	ON	ON
64											ON	ON	OFF	ON	OFF	OFF
65											ON	ON	OFF	ON	OFF	ON
66											ON	ON	OFF	ON	ON	OFF
67											ON	ON	OFF	ON	ON	ON
70											ON	ON	ON	OFF	OFF	OFF
71											ON	ON	ON	OFF	OFF	ON
72											ON	ON	ON	OFF	ON	OFF
73											ON	ON	ON	OFF	ON	ON
74											ON	ON	ON	ON	OFF	OFF
75											ON	ON	ON	ON	OFF	ON
76											ON	ON	ON	ON	ON	OFF
77											ON	ON	ON	ON	ON	ON



We Want Our Manuals to be the Best!

You can help! Our manuals must meet the needs of you, the user. This is your opportunity to make sure they do just that. By filling out this form you can help us provide the most useful, thorough, and accurate manuals available. Please take a few minutes to tell us what you think. Then mail this form, FAX it, or send comments via E-Mail.

FAX: to your local Allen-Bradley Sales Office or 414/242-8579

E-Mail: via Internet to "SEPATTER@ABPOST.remnet.ab.com"

PUBLICATION NAME _____

PUBLICATION NUMBER, DATE AND PART NUMBER (IF PRESENT) _____

✓ CHECK THE FUNCTION THAT MOST CLEARLY DESCRIBES YOUR JOB.

- SUGGEST/RESPONSIBLE FOR THE PURCHASE OF EQUIPMENT
- DESIGN/IMPLEMENT ELECTRICAL SYSTEMS
- SUPERVISE FLOOR OPERATIONS
- MAINTAIN/OPERATE PROGRAMMABLE MACHINERY
- TRAIN/EDUCATE MACHINE USERS

✓ WHAT LEVEL OF EXPERIENCE DO YOU HAVE WITH EACH OF THE FOLLOWING PRODUCTS?

	NONE	LITTLE	MODERATE	EXTENSIVE
PROGRAMMABLE CONTROL	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
AC/DC DRIVES	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
PERSONAL COMPUTERS	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
NC/CNC CONTROLS	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
DATA COMMUNICATIONS/LAN	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

✓ RATE THE OVERALL QUALITY OF THIS MANUAL BY CIRCLING YOUR RESPONSE BELOW. (1) = POOR (5) = EXCELLENT

HELPFULNESS OF INDEX/TABLE OF CONTENTS	1	2	3	4	5
CLARITY	1	2	3	4	5
EASE OF USE	1	2	3	4	5
ACCURACY AND COMPLETENESS	1	2	3	4	5
QUALITY COMPARED TO OTHER COMPANIES' MANUALS	1	2	3	4	5
QUALITY COMPARED TO OTHER ALLEN-BRADLEY MANUALS	1	2	3	4	5

✓ WHAT DID YOU LIKE MOST ABOUT THIS MANUAL?

✓ WHAT DID YOU LIKE LEAST ABOUT THIS MANUAL?

✓ PLEASE LIST ANY ERRORS YOU FOUND IN THIS MANUAL (REFERENCE PAGE, TABLE, OR FIGURE NUMBERS).

✓ DO YOU HAVE ANY ADDITIONAL COMMENTS?

✓ COMPLETE THE FOLLOWING.

NAME _____ COMPANY _____

TITLE _____ DEPARTMENT _____

STREET _____ CITY _____ STATE _____ ZIP _____

TELEPHONE _____ DATE _____

CUT ALONG DOTTED LINE


FOLD HERE

FOLD HERE



BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 413 MEQUON, WI

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



POSTAGE WILL BE PAID BY ADDRESSEE

ALLEN-BRADLEY
Attn: Marketing Communications
P.O. Box 760
Mequon, WI 53092-9907



1336 FORCE™, SCANport™ and DH+™ are trademarks of Allen-Bradley Company, Inc., a Rockwell International Company.

PLC® is a registered trademark of Allen-Bradley Company, Inc., a Rockwell International Company.



ALLEN-BRADLEY
A ROCKWELL INTERNATIONAL COMPANY

Allen-Bradley has been helping its customers improve productivity and quality for 90 years. We design, manufacture and support a broad range of control and automation products worldwide. They include logic processors, power and motion control devices, man-machine interfaces, sensors and a variety of software. Allen-Bradley is a subsidiary of Rockwell International, one of the world's leading technology companies.



With major offices worldwide.

Algeria • Argentina • Australia • Austria • Bahrain • Belgium • Brazil • Bulgaria • Canada • Chile • China, PRC • Colombia • Costa Rica • Croatia • Cyprus • Czech Republic • Denmark • Ecuador • Egypt • El Salvador • Finland • France • Germany • Greece • Guatemala • Honduras • Hong Kong • Hungary • Iceland • India • Indonesia • Israel • Italy • Jamaica • Japan • Jordan • Korea • Kuwait • Lebanon • Malaysia • Mexico • New Zealand • Norway • Oman • Pakistan • Peru • Philippines • Poland • Portugal • Puerto Rico • Qatar • Romania • Russia-CIS • Saudi Arabia • Singapore • Slovakia • Slovenia • South Africa, Republic • Spain • Switzerland • Taiwan • Thailand • The Netherlands • Turkey • United Arab Emirates • United Kingdom • United States • Uruguay • Venezuela • Yugoslavia

World Headquarters, Allen-Bradley, 1201 South Second Street, Milwaukee, WI 53204 USA, Tel: (1) 414 382-2000 Fax: (1) 414 382-4444

