



Frequency converters

VLT® 6000



## Quick Setup

Installation  
Setting  
Operation



VLT® is a trademark of Danfoss A/S



## VLT® 6000 HVAC



The voltage of the frequency converter is dangerous whenever the equipment is connected to mains. Incorrect installation of the motor or the frequency converter may cause damage to the equipment, serious personal injury or death. Consequently, the instructions in this manual, as well as national and local rules and safety regulations, must be complied with.

### ■ Safety regulations

1. The VLT frequency converter must be disconnected from mains if repair work is to be carried out.  
Check that the mains supply has been disconnected and that the necessary time has passed before removing motor and mains plugs.
2. The [OFF/STOP] key on the control panel of the VLT frequency converter does not disconnect the equipment from mains and is thus not to be used as a safety switch.
3. Correct protective earthing of the equipment must be established, the user must be protected against supply voltage, and the motor must be protected against overload in accordance with applicable national and local regulations.
4. The earth leakage currents are higher than 3.5 mA.
5. Protection against motor overload is included in the factory setting. Parameter 117, *Motor thermal protection*, default value is ETR trip 1.

### NB!



The function is initialised at 1.0 x rated motor current and rated motor frequency (See parameter 117, *Motor thermal protection*).

For the North American market: The ETR functions ensure overload protection of the motor, Class 20, in accordance with NEC.

6. Do not remove the plugs for the motor and mains supply while the VLT frequency converter is connected to mains. Check that the mains supply has been disconnected and that the necessary time has passed before removing motor and mains plugs.
7. Reliable galvanic isolation (PELV) is not complied with if the RFI switch is placed in OFF position.  
This means that all control in- and outputs can only be considered low-voltage terminals with basic galvanic isolation.
8. Please note that the VLT frequency converter has more voltage inputs than L1, L2, L3 when the DC-bus terminals are used. Check that all voltage inputs have been disconnected and that the necessary time has passed before repair work is commenced.

### ■ Warning against unintended start

1. The motor can be brought to a stop by means of digital commands, bus commands, references or a local stop, while the frequency converter is connected to mains. If personal safety considerations make it necessary to ensure that no unintended start occurs, these stop functions are not sufficient.
2. While parameters are being changed, the motor may start. Consequently, the stop key [OFF/STOP] must always be activated, following which data can be modified.
3. A stopped motor may start if a fault occurs in the electronics of the VLT frequency converter, or if a temporary overload or a fault in the supply mains or the motor connection ceases.



### Warning:

Touching the electrical parts may be fatal - even after the equipment has been disconnected from mains.

Using VLT 6002-6005: wait at least 4 minutes

Using VLT 6006-6275: wait at least 15 minutes

**■ CE-labelling****What is CE-labelling?**

The purpose of CE-labelling is to avoid technical obstacles to trade within EFTA and the EU. The EU has introduced the CE-label as a simple way of showing whether a product complies with the relevant EU directives. The CE-label says nothing about the quality or specifications of a product. Three EU directives relate to frequency converters:

- **The machine directive (89/392/EEC)**  
All machines with critical, moving parts are comprised by the machine directive which came into force on 1 January 1995. Since a frequency converter is largely electrical by function, it does not fall under the machine directive. However, if a frequency converter is supplied for use in a machine, we provide information about the safety aspects relating to the frequency converter. We do that by means of a manufacturer's declaration.
- **The low voltage directive (73/23/EEC)**  
Frequency converters must be CE-labelled in accordance with the low voltage directive which came into force on 1 January 1997. This directive applies to all electrical equipment and units used in the 50-1000 V AC and 75-1500 V DC voltage ranges. Danfoss provides its

units with CE-labels in accordance with the directive and issues declarations of conformity upon request.

- **The EMC directive (89/336/EEC)**  
EMC is short for electromagnetic compatibility. The presence of electromagnetic compatibility means that the mutual interference between different components/appliances is so small that the functioning of the appliances is not affected. The EMC directive came into force on 1 January 1996. In accordance with the directive, Danfoss CE-labels its products and issues a declaration of conformity upon request.

To help ensure that your installation is EMC-correct, the manual provides detailed instructions for installation. Furthermore, we specify which norms that are complied with by which of our products. We offer the filters that can be seen from the specifications and gladly provide other types of assistance that can help you obtain the best possible EMC result.

In most cases the VLT frequency converter is used by professionals of the trade as a complex component forming part of a larger appliance, system or installation. It must be noted that the responsibility for the final EMC properties of the appliance, system or installation rests with the installer.



## VLT® 6000 HVAC

### ■ Mechanical installation



Please pay attention to the requirements that apply to integration and field mounting kit, see the below list. The information given in the list must be observed to avoid serious damage or injury, especially when installing large units.

The VLT frequency converter *must* be installed vertically.

The VLT frequency converter is cooled by means of air circulation. For the unit to be able to release its cooling air, the *minimum* distance over and below the unit must be as shown in the illustration below.

To protect the unit from overheating, it must be ensured that the ambient temperature *does not rise above the max. temperature stated for the VLT frequency converter* and that the 24-hour average temperature *is not exceeded*.

If the ambient temperature is in the range of 45°C - 55°C, derating of the VLT frequency converter will become relevant

The service life of the VLT frequency converter will be reduced if derating for ambient temperature is not taken into account.

### ■ Enclosure protection

	IP 00	IP 20	IP 54
Bookstyle	-	OK	-
VLT 6002-6032 200-240 V	-	OK	OK
VLT 6002-6550 380-460 V	OK	OK	OK

### ■ Field-mounting

	IP 00	IP 20	IP 54
Bookstyle	-	No	-
VLT 6002-6032 200-240 V	-	No	OK
VLT 6002-6550 380-460 V	No	No	OK


IP 20 with 4x top cover			
VLT 6002-6005 200-240 V	-	OK	OK
VLT 6002-6016 380-460 V	-	OK	OK

IP 20 terminal cover			
VLT 6006-6032 200-240 V	-	OK	OK
VLT 6022-6062 380-460 V	-	OK	OK


### ■ Spacing when installing of VLT 6002-6005 200-240 V, VLT 6002-6011 380-460 V

Bookstyle IP 00, IP 20 and IP 54.

#### Cooling



#### Side-by-side



All the above-mentioned units require a minimum space of 100 mm above and below the enclosure.



All the above-mentioned units can be installed side by side without any space, since these units do not require any cooling on the sides.




## VLT® 6000 HVAC

### ■ Installation of VLT 6006-6032 200-240 V, VLT 6016-6062 380-460 V IP 20 and IP 54 Side-by-side

#### Cooling



IP 20




IP 54 (flange-by-flange)

All units in the above-mentioned series require a minimum space of 200 mm above and below the enclosure and must be installed on a plane, vertical surface (no spacers). This applies both to IP 20 and IP 54 units. These units can be installed side by side without any spacing, since they do not require any cooling on the sides.


### ■ Installation of VLT 6042-6062 200-240 V, VLT 6075-6275 380-460 V IP 00, IP 20 and IP 54

#### Cooling




VLT 6075-6275

#### Side-by-side



VLT 6075-6275 IP 00 and IP 20



All units require a minimum space of 225 mm above and below the enclosure and must be installed on a plane, vertical surface (no spacers). This applies to IP 00, IP 20 and IP 54 units alike.

All IP 00 and IP 20 units in the above-mentioned series can be installed side by side without any spacing.



## VLT® 6000 HVAC

### ■ General information about electrical installation

#### ■ High voltage warning



The voltage of the frequency converter is dangerous whenever the equipment is connected to mains. Incorrect installation of the motor or the frequency converter may cause damage to the equipment, serious personal injury or death. Consequently, the instructions in this Design Guide, as well as national and local safety regulations, must be complied with. Touching the electrical parts may be fatal - even after disconnection from mains: Using VLT 6002-6005 wait at least 4 minutes and using VLT 6006-6550 wait at least 15 minutes.



#### NB!

It is the user's or certified electrician's responsibility to ensure correct earthing and protection in accordance with applicable national and local norms and standards.

### ■ Earthing

The following basic issues need to be considered when installing a frequency converter, so as to obtain electromagnetic compatibility (EMC).

- **Safety earthing:** Please note that the frequency converter has a high leakage current and must be earthed appropriately for safety reasons. Apply local safety regulations.
- **High-frequency earthing:** Keep the earth wire connections as short as possible.

Connect the different earth systems at the lowest possible conductor impedance. The lowest possible conductor impedance is obtained by keeping the conductor as short as possible and by using the greatest possible surface area. A flat conductor, for example,

has a lower HF impedance than a round conductor for the same conductor cross-section  $C_{VESS}$ .

If more than one device is installed in cabinets, the cabinet rear plate, which must be made of metal, should be used as a common earth reference plate. The metal cabinets of the different devices are mounted on the cabinet rear plate using the lowest possible HF impedance. This avoids having different HF voltages for the individual devices and avoids the risk of radio interference currents running in connection cables that may be used between the devices. The radio interference will have been reduced.

In order to obtain a low HF impedance, use the fastening bolts of the devices as HF connection to the rear plate. It is necessary to remove insulating paint or similar from the fastening points.

### ■ Cables

Control cables and the filtered mains cable should be installed separate from the motor cables so as to avoid interference overcoupling. Normally, a distance of 20 cm will be sufficient, but it is recommended to keep the greatest possible distance wherever possible, especially where cables are installed in parallel over a substantial distance.

With respect to sensitive signal cables, such as telephone cables and data cables, the greatest possible distance is recommended with a minimum of 1 m per 5 m of power cable (mains and motor cable). It must be pointed out that the necessary distance depends on the sensitivity of the installation and the signal cables, and that therefore no precise values can be stated.

If cable jaws are used, sensitive signal cables are not to be placed in the same cable jaws as the motor cable or brake cable. If signal cables are to cross power cables, this should be done at an angle of 90 degrees. Remember that all interference-filled in- or outgoing cables to/from a cabinet should be screened/armoured or filtered.

**■ Screened/armoured cables**

The screen must be a low HF-impedance screen. This is ensured by using a braided screen of copper, aluminium or iron. Screen armour intended for mechanical protection, for example, is not suitable for an EMC-correct installation.

---

**■ Extra protection with regard to indirect contact**

ELCB relays, multiple protective earthing or earthing can be used as extra protection, provided that local safety regulations are complied with.

In the case of an earth fault, a DC content may develop in the faulty current.

Never use ELCB relays, type A, since such relays are not suitable for DC fault currents. If ELCB relays are used, this must be done in accordance with local regulations.

If ELCB relays are used, they must be:

- Suitable for protecting equipment with a direct current content (DC) in the faulty current (3-phase bridge rectifier)
- Suitable for power-up with short charging current to earth
- Suitable for a high leakage current.

---

**■ RFI switch**

Mains supply isolated from earth:

When the VLT frequency converter is supplied from an isolated mains source (IT mains), the RFI switch must be closed (OFF). In the OFF position, the internal RFI capacitors (filter capacitors) between the chassis and the intermediate circuit are cut out so as to avoid damaging the intermediate circuit and to reduce the earth leakage currents (see IEC 1800-3).

**NB!**

When the RFI switch is set to OFF parameter 407 Switching frequency max is only allowed to be set to factory setting.

**NB!**

The RFI switch is not to be operated with mains supply connected to the unit. Check that the mains supply has been disconnected before operating the RFI switch.

**NB!**

The RFI switch disconnects the capacitors galvanically; however, transients higher than approx. 1,000 V will be bypassed by a spark gap.



Reliable galvanic isolation (PELV) is lost if the RFI switch is placed in the OFF position. This means that all control in- and outputs can only be considered low-voltage terminals with basic galvanic isolation. In addition, the VLT 6000 HVAC EMC performance will be reduced if the RFI switch is placed in the OFF position.

Mains supply connected to earth:

The RFI switch must be ON for all installations on earthed mains supplies.

---

**■ High voltage test**

A high voltage test can be carried out by short-circuiting terminals U, V, W, L<sub>1</sub>, L<sub>2</sub> and L<sub>3</sub> and energizing by max. 2.5 kV DC for one second between this short-circuit and the chassis.

**NB!**

The RFI switch must be closed (position ON) when high voltage tests are carried out. The mains and motor connection must be interrupted in the case of high voltage tests of the total installation if the leakage currents are too high.



---

## VLT® 6000 HVAC

---

### ■ Heat emission from VLT 6000 HVAC

The tables in *General technical data* show the power loss  $P_{\phi}(W)$  from VLT 6000 HVAC. The maximum cooling air temperature  $t_{IN, MAX}$  is 40° at 100% load (of rated value).

---

### ■ Ventilation of integrated VLT 6000 HVAC

The quantity of air required for cooling frequency converters can be calculated as follows:

1. Add up the values of  $P_{\phi}$  for all the frequency converters to be integrated in the same panel.

The highest cooling air temperature ( $t_{IN}$ ) present must be lower than  $t_{IN, MAX}$  (40°C). The day/night average must be 5°C lower (VDE 160).

The outlet temperature of the cooling air must not exceed:  $t_{OUT, MAX}$  (45° C).

2. Calculate the permissible difference between the temperature of the cooling air ( $t_{IN}$ ) and its outlet temperature ( $t_{OUT}$ ):

$$\Delta t = 45^{\circ} C - t_{IN}$$

3. Calculate the required

$$\text{quantity of air} = \frac{\Sigma P_{\phi} \times 3.1}{\Delta t} \quad \text{m}^3/\text{h}$$

Insert  $\Delta t$  in Kelvin

The outlet from the ventilation must be placed above the highest-mounted frequency converter.






Allowance must be made for the pressure loss across the filters and for the fact that the pressure is going to drop as the filters are choked.

---

■ **Earthing of screened/armoured control cables**

Generally speaking, control cables must be screened/armoured and the screen must be connected by means of a cable clamp at both ends to the metal cabinet of the unit.

The drawing below indicates how correct earthing is carried out and what to be done if in doubt.



Correct earthing

Control cables and cables for serial communication must be fitted with cable clamps at both ends to ensure the best possible electrical contact.

Wrong earthing

Do not use twisted cable ends (pigtails), since these increase the screen impedance at high frequencies.

Protection with respect to earth potential between PLC and VLT

If the earth potential between the VLT frequency converter and the PLC (etc.) is different, electric noise may occur that will disturb the whole system. This problem can be solved by fitting an equalizing cable, to be placed next to the control cable. Minimum cable cross-section: 16 mm<sup>2</sup>.

For 50/60 Hz earth loops

If very long control cables are used, 50/60 Hz earth loops may occur that will disturb the whole system. This problem can be solved by connecting one end of the screen to earth via a 100nF condenser (keeping leads short).

Cables for serial communication

Low-frequency noise currents between two VLT frequency converters can be eliminated by connecting one end of the screen to terminal 61. This terminal is connected to earth via an internal RC link. It is recommended to use twisted-pair cables to reduce the differential mode interference between the conductors.



## VLT® 6000 HVAC

### ■ Tightening-up torque and screw sizes

The table shows the torque required when fitting terminals to the VLT frequency converter. For VLT 6002-6032, 200 -240 V, VLT 6002-6062, 380-460 V, the cables must be fastened with screws. For VLT 6042-6062, 200-240 V and for VLT 6075-6550, the cables must be fastened with bolts.

These figures apply to the following terminals:

#### Mains terminals

**Nos. 91, 92, 93**  
**L1, L2, L3**

#### Motor terminals

**Nos. 96, 97, 98**  
**U, V, W**

#### Earth terminal

**No. 99**

VLT type	Tightening-up torque	Screw size
3 x 200-240 V		
VLT 6002-6005	0.5 - 0.6 Nm	M3
VLT 6006-6011	1.8 Nm	M4
VLT 6016-6027	3.0 Nm	M5
VLT 6032	4.0 Nm	M6

VLT type	Tightening-up torque	Bolt size
3 x 200-240 V		
VLT 6042-6062	11.3 Nm	M8

VLT type	Tightening-up torque	Screw size
3 x 380-460 V		
VLT 6002-6011	0.5 - 0.6 Nm	M3
VLT 6016-6027	1.8 Nm	M4
VLT 6032-6062	3.0 Nm	M5

VLT type	Tightening-up torque	Bolt size
3 x 380-460 V		
VLT 6075-6125	11.3 Nm	M8
VLT 6150-6275	11.3 Nm	M8
VLT 6350-6550	42.0 Nm	M12

### ■ Mains connection

Mains must be connected to terminals 91, 92, 93.

Mains voltage 3 x 200-240 V

**Nos. 91, 92, 93**  
**L1, L2, L3**

Mains voltage 3 x 380-460 V



#### NB!

Check that the mains voltage fits the mains voltage of the VLT frequency converter, which can be seen from the nameplate.

### ■ Pre-fuses

For VLT type 6002-6275, external pre-fuses must be installed in the mains supply to the frequency converter. For UL/cUL applications with a mains voltage of 200-240 V, pre-fuses of type Bussmann KTN-R (200-240 V) or similar must be used. For UL/cUL applications with a mains voltage of 380-460 V, pre-fuses of type Bussmann KTS-R (380-460 V) or similar must be used.



## VLT® 6000 HVAC

### ■ Motor connection

The motor must be connected to terminals 96, 97, 98. Earth to terminal 99.

Motor voltage 0-100% of mains voltage.  
Earth connection.

**Nos. 96, 97, 98**  
**U, V, W**  
**No. 99**

All types of three-phase asynchronous standard motors can be used with a VLT 6000 HVAC unit.


Small-size motors are normally star-connected. (220/380 V,  $\Delta/Y$ ). Large-size motors are delta-connected (380/660 V,  $\Delta/Y$ ). The correct connection and voltage can be read from the motor nameplate.





### NB!

In older motors without phase coil insulation, a LC filter should be fitted to the VLT frequency converter output. See the Design Guide or contact

Danfoss.




### ■ Direction of motor rotation



The factory setting is for clockwise rotation with the VLT frequency transformer output connected as follows.

Terminal 96 connected to U-phase  
Terminal 97 connected to V-phase  
Terminal 98 connected to W-phase

The direction of rotation can be changed by switching two phases in the motor cable.

**■ Parallel coupling of motors**


VLT 6000 HVAC is able to control several motors connected in parallel. If the motors are to have different rpm values, the motors must have different rated rpm values. Motor rpm is changed simultaneously, which means that the ratio between the rated rpm values is maintained across the range.

The total current consumption of the motors is not to exceed the maximum rated output current  $I_{VLT,N}$  for the VLT frequency converter.

Problems may arise at the start and at low rpm values if the motor sizes are widely different. This is because the relatively high ohmic resistance in small motors calls for a higher voltage at the start and at low rpm values.

In systems with motors connected in parallel, the electronic thermal relay (ETR) of the VLT frequency converter cannot be used as motor protection for the individual motor. Consequently, additional motor protection is required, such as thermistors in each motor (or individual thermal relays).


**NB!**

Parameter 107 *Automatic Motor Adaptation, AMA* and *Automatic Energy Optimization, AEO* in parameter 101

*Torque characteristics* cannot be used if motors are connected in parallel.

---

**■ Motor cables**

See *Technical data* for correct sizing of motor cable cross-section and length. Always comply with national and local regulations on cable cross-sections.


**NB!**

If an unshielded cable is used, some EMC requirements are not complied with, see *EMC test results*.

If the EMC specifications regarding emission are to be complied with, the motor cable must be shielded, unless otherwise stated for the RFI filter in question. It is important to keep the motor cable as short as possible so as to reduce the noise level and leakage currents to a minimum. The motor cable shield must be connected to the metal cabinet of the frequency converter and to the metal cabinet of the motor. The shield connections are to be made with the biggest possible surface (cable clamp). This is enabled by different installation devices in the different VLT frequency converters. Mounting with twisted shield ends (pigtailed) is to be avoided, since these spoil the shielding effect at higher frequencies. If it is necessary to break the shield to install a motor isolator or motor contactor, the shield must be continued at the lowest possible HF impedance.

---



## VLT® 6000 HVAC

### ■ Motor thermal protection

The electronic thermal relay in UL-approved VLT frequency converters has received UL approval for single motor protection, as long as parameter 117 *Motor thermal protection* has been set to ETR Trip and parameter 105 *Motor current,  $I_{VLTN}$*  has been programmed for the rated motor current (can be read from the motor nameplate).

### ■ High-voltage relay

The cable for the high-voltage relay must be connected to terminals 01, 02, 03. The high-voltage relay is programmed in parameter 323, *Relay 1, output*.

**No. 1**

Relay output 1  
1+3 break, 1+2 make.  
Max. 240 V AC, 2 Amp.  
Min. 24 V DC, 10 mA or  
24 V AC, 100 mA.

### ■ Earth connection

Since the leakage currents to earth may be higher than 3.5 mA, the VLT frequency converter must always be earthed in accordance with applicable national and local regulations. In order to ensure good mechanical connection of the earth cable, its cable cross-section must be at least 10 mm<sup>2</sup>. For added security, an RCD (Residual Current Device) may be installed. This ensures that the VLT frequency converter will cut out if the leakage currents get too high. See RCD instructions MI.66.AX.02.

Max. cross-section: 4 mm<sup>2</sup>/10 AWG.  
Torque: 0.5 - 0.6 Nm.  
Screw size: M3.

### ■ Control card

All terminals for the control cables are located under the protective cover of the VLT frequency converter.

The protective cover (see drawing below) can be removed by means of a pointed object - a screwdriver or similar.


### ■ DC bus connection

The DC bus terminal is used for DC back-up, with the intermediate circuit being supplied from an external DC source. In addition, a 12-pulse option can be connected to reduce the total harmonic distortion.

Terminal nos.

**Nos. 88, 89**

Contact Danfoss if you require further information.





## VLT® 6000 HVAC


### ■ Connection example, VLT 6000 HVAC

The diagram below gives an example of a typical VLT 6000 HVAC installation. The mains supply is connected to terminals 91 (L1), 92 (L2) and 93 (L3), while the motor is connected to 96 (U), 97 (V) and 98 (W). These numbers can also be seen from the terminals of the VLT frequency converter. An external DC supply or a 12-pulse option can be connected to terminals 88 and 89. Please ask Danfoss for a Design Guide to learn more. Analogue inputs can be connected to terminals 53 [V], 54 [V] and 60 [mA]. These inputs can be programmed for either reference, feedback or thermistor. See *Analogue inputs* in parameter group 300.

There are 8 digital inputs, which can be connected to terminals 16-19, 27, 29, 32, 33.

There are two analogue/digital outputs (terminals 42 and 45), which can be programmed to show the present status or a process value, such as  $0-f_{MAX}$ . Relay outputs 1 and 2 can be used for giving the present status or a warning.

On terminals 68 (P+) and 69 (N-) RS 485 interface, the VLT frequency converter can be controlled and monitored via serial communication.





175HA390.12

**■ Electrical installation, control cables**

Max. control cable cross-section: 1.5 mm<sup>2</sup>/16 AWG

Torque: 0.5-0.6 Nm  
Screw size: M3

See *Earthing of screened/armoured control cables* for correct termination of control cables.



DANFOSS  
175HA379.10

No.	Function
<b>04, 05</b>	Relay output 1 can be used for indicating status and warnings.
<b>12, 13</b>	Voltage supply to digital inputs. For the 24 V DC to be used for digital inputs, switch 4 on the control card must be closed, position "on".
<b>16-33</b>	Digital inputs. See parameters 300-307 <i>Digital inputs</i> .
<b>20</b>	Ground for digital inputs.
<b>39</b>	Ground for analogue/digital outputs. Must be connected to terminal 55 by means of a three-wire transmitter.
<b>42, 45</b>	Analogue/digital outputs for indicating frequency, reference, current and torque. See parameters 319-322 <i>Analogue/digital outputs</i> .
<b>50</b>	Supply voltage to potentiometer and thermistor 10 V DC.

<b>53, 54</b>	Analogue voltage input, 0 - 10 V DC.
<b>55</b>	Ground for analogue voltage inputs.
<b>60</b>	Analogue current input 0/4-20 mA. See parameters 314-316 <i>Terminal 60</i> .
<b>61</b>	Termination of serial communication. See <i>Earthing of screened/armoured control cables</i> . This terminal is not normally to be used.
<b>68, 69</b>	RS 485 interface, serial communication. Where the VLT frequency converter is connected to a bus, switches 2 and 3 (switches 1- 4 - see next page) must be closed on the first and the last VLT frequency converter. On the remaining VLT frequency converters, switches 2 and 3 must be open. The factory setting is closed (position on).



## VLT® 6000 HVAC

### ■ Control unit LCP

The front of the VLT frequency converter features a control panel - LCP (Local Control Panel). This is a complete interface for operation and programming of the VLT 6000 HVAC.

The control panel is detachable and can - as an alternative - be installed up to 3 metres away from the VLT frequency converter, e.g. on the front panel, by means of a mounting kit option.


The functions of the control panel can be divided into five groups:

1. Display
2. Keys for changing display mode
3. Keys for changing program parameters
4. Indicator lamps
5. Keys for local operation.

All data are indicated by means of a 4-line alpha-numeric display, which, in normal operation, is able to show 4 operating data values and 3 operating condition values continuously. During programming, all the information required for quick, effective parameter Setup of the VLT frequency


converter will be displayed. As a supplement to the display, there are three indicator lamps for voltage (ON), warning (WARNING) and alarm (ALARM), respectively.

All VLT frequency converter parameter Setups can be changed immediately via the control panel, unless this function has been programmed to be *Locked* [1] via parameter 016 *Lock for data change* or via a digital input, parameters 300-307 *Lock for data change*.



### ■ Control keys for parameter Setup

The control keys are divided into functions. This means that the keys between display and indicator lamps are used for parameter Setup, including selecting the display indication during normal operation.



DISPLAY  
MODE

[DISPLAY / STATUS] is used for selecting the indication mode of the display or when returning to the Display mode from either the Quick menu or the Extend menu mode.

QUICK  
MENU

[QUICK MENU] gives access to the parameters used for the Quick menu. It is possible to switch between the Quick menu and the Extend menu modes.

EXTEND  
MENU

[EXTEND MENU] gives access to all parameters. It is possible to switch between the Extend menu and the Quick menu modes.

CHANGE  
DATA


[CHANGE DATA] is used for changing a setting selected either in the Extend menu or the Quick menu mode.

CANCEL

[CANCEL] is used if a change of the selected parameter is not to be carried out.


OK

[OK] is used for confirming a change of the parameter selected.



[+/-] is used for selecting parameters and for changing a chosen parameter. These keys are also used to change the local reference.

In addition, the keys are used in Display mode to switch between operation variable readouts.



[<>] is used when selecting a parameter group and for moving the cursor when changing numerical values.

On the control terminals, the following control signals will still be active when [HAND START] is activated:

- Hand start - Off stop - Auto start
- Safety Interlock
- Reset
- Coasting stop inverse
- Reversing
- Setup select lsb - Setup select msb
- Jog
- Run permissive
- Lock for data change
- Stop command from serial communication

#### ■ Indicator lamps

At the bottom of the control panel is a red alarm lamp, a yellow warning lamp, as well as a green voltage LED.

red      yellow      green

If certain threshold values are exceeded, the alarm and/or warning lamp is activated, and a status or alarm text is displayed.



**NB!**

The voltage indicator lamp is activated when the VLT frequency converter receives voltage.



**NB!**

If parameter 201 Output frequency low limit  $f_{MIN}$  is set to an output frequency greater than 0 Hz, the motor will start and ramp up to this frequency when [HAND START] is activated.




[OFF/STOP] is used for stopping the connected motor. Can be selected as Enable [1] or Disable [0] via parameter 013. If the stop function is activated, line 2 will flash.



[AUTO START] is used if the VLT frequency converter is to be controlled via the control terminals and/or serial communication. When a start signal is active on the control terminals and/or the bus, the VLT frequency converter will start.

#### ■ Local control

Underneath the indicator lamps are keys for local control.



[HAND START] is used if the VLT frequency converter is to be controlled via the control unit. The VLT frequency converter will start the motor, since a start command is given by means of [HAND START].



**NB!**

An active HAND-OFF-AUTO signal via the digital inputs will have higher priority than the control keys [HAND START]-[AUTO START].



[RESET] is used for resetting the VLT frequency converter after an alarm (trip). Can be selected as *Enable* [1] or *Disable* [0] via parameter 015 *Reset on LCP*.



## VLT® 6000 HVAC

### ■ Display mode

In normal operation, any 4 different operating variables can be indicated continuously: 1.1 and 1.2 and 1.3 and 2. The present operating status or alarms and warnings that have arisen are shown in line 2 in the form of a number. In the case of alarms, the alarm in question will be shown in lines 3 and 4, accompanied by an explanatory note. Warnings will flash in line 2, with an explanatory note in line 1. In addition, the display shows the active Setup. The arrow indicates the direction of rotation; here the VLT frequency converter has an active reversing signal. The arrow body disappears if a stop command is given or if the output frequency falls below 0.01 Hz. The bottom line gives the status of the VLT frequency converter. The scroll list on the next page gives the operating data that can be shown for variable 2 in display mode. Changes are made via the [+/-] keys.



The table below gives the operating data options for the first and second line of the display.

Scroll-list:	Unit:
Resulting reference, %	[%]
Resulting reference, unit	[unit]
Frequency	[Hz]
% of maximum output frequency	[%]
Motor current	[A]
Power	[kW]
Power	[HP]
Output energy	[kWh]
Hours run	[hours]
Used-defined readout	[unit]
Setpoint 1	[unit]
Setpoint 2	[unit]
Feedback 1	[unit]
Feedback 2	[unit]
Feedback	[unit]
Motor voltage	[V]
DC-link voltage	[V]
Thermal load on motor	[%]
Thermal load on VLT	[%]
Input status, dig. input	[binary code]
Input status, analogue terminal 53	[V]
Input status, analogue terminal 54	[V]
Input status, analogue terminal 60	[mA]
Pulse reference	[Hz]
External reference	[%]
Heat sink temperature	[°C]
User-defined text	[-]

Three operating data values can be shown in the first display line, while one operating variable can be shown in the second display line. To be programmed via parameters 007, 008, 009 and 010 *Display readout*.

Ž Status line:



The left part of the status line indicates the control element of the VLT frequency converter that is active. AUTO means that control is via the control terminals, while HAND indicates that control is via the local keys on the control unit.

OFF means that the VLT frequency converter ignores all control commands and stops the motor.

The centre part of the status line indicates the reference element that is active. REMOTE means that the reference from the control terminals is active, while LOCAL indicates that the reference is determined via the [+/-] keys on the control panel.

The last part of the status line indicates the current status, for example "Running", "Stop" or "Alarm".

■ Display mode I:

VLT 6000 HVAC offers different display modes depending on the mode selected for the VLT frequency converter. The figure on the next page shows the way to navigate between different display modes.

Below is a display mode, in which the VLT frequency converter is in Auto mode with remote reference at an output frequency of 40 Hz. In this display mode, reference and control are determined via the control terminals. The text in line 1 gives the operating variable shown in line 2.



Line 2 gives the current output frequency and the active Setup.

Line 4 says that the VLT frequency converter is in Auto mode with remote reference, and that the motor is running.

■ **Display mode II:**

This display mode makes it possible to have three operating data values displayed at the same time in line 1. The operating data values are determined in parameters 007-010 *Display readout*.



■ **Display mode III:**

This display mode can be generated as long as the [DISPLAY MODE] key is kept depressed. In the first line, operating data names and units of operating data are displayed. In the second line, operating data 2 remains unchanged. When the key is released, the different operating data values are shown.




■ **Display mode IV:**

This display mode is only generated in connection with local reference. In this display mode, the reference is determined via the [+/-] keys and control is carried out by means of the keys underneath the indicator lamps. The first line indicates the required reference. The third line gives the relative value of the present output frequency at any given time in relation to the maximum frequency. The display is in the form of a bar graph.



■ Navigation between display modes






## VLT® 6000 HVAC

### ■ Changing data

Regardless of whether a parameter has been selected under the Quick menu or the Extend menu, the procedure for changing data is the same.


Pressing the [CHANGE DATA] key gives access to changing the selected parameter, following which the underlining in line 4 will flash on the display.

The procedure for changing data depends on whether the selected parameter represents a numerical data value or a functional value. If the chosen parameter represents a numeric data value, the first digit can be changed by means of the [+/-] keys. If the second digit is to be changed, first move the cursor by using the [<>] keys, then change the data value using the [+/-] keys.



The selected digit is indicated by a flashing cursor. The bottom display line gives the data value that will be entered (saved) when signing off by pressing the [OK] button. Use [CANCEL] to cancel the change.


If the selected parameter is a functional value, the selected text value can be changed by means of the [+/-] keys.




The functional value flashes until signing off by pressing the [OK] button. The functional value has now been selected. Use [CANCEL] to cancel the change.

### ■ Infinitely variable change of numeric data value

If the chosen parameter represents a numeric data value, a digit is first selected by means of the [<>] keys.



Then the chosen digit is changed infinitely variably by means of the [+/-] keys:



The chosen digit is indicated by the digit flashing. The bottom display line shows the data value that will be entered (saved) when signing off with [OK].



■ **Changing of data value, step-by-step**

Certain parameters can be changed both step by step and infinitely variably. This applies to *Motor power* (parameter 102), *Motor voltage* (parameter 103) and *Motor frequency* (parameter 104).

This means that the parameters are changed both as a group of numeric data values and as numeric data values infinitely variably.

---

■ **Manual initialisation**

Disconnect from mains and hold the [DISPLAY/STATUS] + [CHANGE DATA] + [OK] keys down while at the same time reconnecting the mains supply.

Release the keys; the VLT frequency converter has now been programmed for the factory setting.

The following parameters are not zeroed by means of manual initialisation:

- parameter 500, *Protocol*
- 600, *Operating hours*
- 601, *Hours run*
- 602, *kWh counter*
- 603, *Number of power-ups*
- 604, *Number of overtemperatures*
- 605, *Number of overvoltages*

It is also possible to carry out initialisation via parameter 620 *Operating mode*.




---

VLT® 6000 HVAC

---

**Quick menu**

The [QUICK MENU] key gives access to the 12 most important parameters of the VLT frequency converter. After programming, the VLT frequency converter will in most cases be ready for operation. Scroll through the Quick menu using the [+/-] keys and change the data values by pushing [CHANGE DATA] + [OK].



Quick menu: Parameter 1 of 12

Used to select the language for the display.

Quick menu: Parameter 2 of 12

Select the kW value that equals the rated motor value  $P_{M,N}$ . There is a choice of four undersizes or one oversize in relation to the factory setting.

Quick menu: Parameter 3 of 12

Used to set the rated motor voltage  $U_{M,N}$  while taking into consideration whether the motor is star or delta connected.

Quick menu: Parameter 4 of 12

Used to select the rated motor frequency  $f_{M,N}$ .

Quick menu: Parameter 5 of 12

Used to select motor current  $I_{M,N}$  while taking into consideration whether the motor is star or delta connected.

Quick menu: Parameter 6 of 12

Used to select the value that corresponds to the rated motor speed  $n_{M,N}$  that can be seen from the nameplate data.

Quick menu: Parameter 7 of 12

Used to select a minimum frequency limit, corresponding to the lowest frequency at which the motor is to run.

Quick menu: Parameter 8 of 12

Used to select a maximum frequency limit, corresponding to the highest frequency at which the motor is to run.

Quick menu: Parameter 9 of 12

The ramp-up time is the acceleration time from 0 Hz to the rated motor frequency  $f_{M,N}$  (parameter 104).

Quick menu: Parameter 10 of 12

The ramp-down time is the deceleration time from the rated motor frequency  $f_{M,N}$  (parameter 104) to 0 Hz.

Quick menu: Parameter 11 of 12

Relay output 1 can be used for indicating status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled.

Quick menu: Parameter 12 of 12

Relay output 2 can be used for indicating status and warnings. The relay is activated when the conditions for the relevant data values have been fulfilled.

■ **Status messages**

Status messages appear in the 4th line of the display - see example below.

The left part of the status line indicates the active type of control of the VLT frequency converter.

The centre part of the status line indicates the active reference.

The last part of the status line gives the present status, e.g. "Running", "Stop" or "Stand by".



**Auto mode (AUTO)**

The VLT frequency converter is in Auto mode, i.e. control is carried out via the control terminals and/or serial communication. See also *Auto start*.

**Hand mode (HAND)**

The VLT frequency converter is in Hand mode, i.e. control is carried out via the control keys. See also *Hand start*.

**OFF (OFF)**

OFF/STOP is activated either by means of the control key, or by the digital inputs *Hand start* and *Auto start* both being a logic '0'. See also *OFF/STOP*.

**Local reference (LOCAL)**

If LOCAL has been selected, the reference is set via the [+/-] keys on the control panel. See also *Display modes*.

**Remote reference (REM.)**

If REMOTE has been selected, the reference is set via the control terminals or via serial communication. See also *Display modes*.

**Running (RUNNING)**

The motor speed now corresponds to the resulting reference.

**Ramp operation (RAMPING)**

The output frequency is now changed in accordance with the preset ramps.

**Auto-ramp (AUTO RAMP)**

Parameter 208 *Automatic ramp-down* is enabled, i.e. the VLT frequency converter is trying to avoid a trip from overvoltage by increasing its output frequency.

**Sleep Boost (SLEEP .BST)**

The boost function in parameter 406 *Boost setpoint* is enabled. This function is only possible in *Closed loop* operation.

**Sleep mode (SLEEP)**

The energy saving function in parameter 403 *Sleep mode timer* is enabled. This means that at present the motor has stopped, but that it will restart automatically when required.

**Start delay (START DEL)**

A start delay time has been programmed in parameter 111 *Start delay*. When the delay has passed, the output frequency will start by ramping up to the reference.

**Run request (RUN REQ.)**

A start command has been given, but the motor will be stopped until a *Run permissive* signal is received via a digital input.

**Jogging (JOG)**

Jog has been enabled via a digital input or via serial communication.

**Jog request (JOG REQ.)**

A JOG command has been given, but the motor will remain stopped until a *Run permissive* signal is received via a digital input.

**Freeze output (FRZ.OUT)**

Freeze output has been enabled via a digital input.



---

## VLT® 6000 HVAC

---

### **Freeze output request (FRZ.REQ.)**

A freeze output command has been given, but the motor will remain stopped until a *Run permissive* signal is received via a digital input.

### **Reversing and start (START F/R)**

*Reversing and start* [2] on terminal 19 (parameter 303 *Digital inputs*) and *Start* [1] on terminal 18 (parameter 302 *Digital inputs*) are enabled at the same time. The motor will remain stopped until one of the signals becomes a logic '0'.

### **Automatic Motor Adaptation running (AMA RUN)**

Automatic motor adaptation has been enabled in parameter 107 *Automatic Motor Adaptation, AMA*.

### **Automatic Motor Adaptation completed (AMA STOP)**

Automatic motor adaptation has been completed. The VLT frequency converter is now ready for operation after the *Reset* signal has been enabled. Please note that the motor will start after the VLT frequency converter has received the *Reset* signal.

### **Stand by (STANDBY)**

The VLT frequency converter is able to start the motor when a start command is received.

### **Stop (STOP)**

The motor has been stopped via a stop signal from a digital input, [OFF/STOP]-button or serial communication.

### **DC stop (DC STOP)**

The DC brake in parameter 114-116 has been enabled.

### **DRIVE ready (UN. READY)**

The VLT frequency converter is ready for operation, but terminal 27 is a logic '0' and/or a *Coasting command* has been received via the serial communication.

### **Control ready (CTR.READY)**

This status is only active when a profibus option card is installed.

### **Not ready (NOT READY)**

The VLT frequency converter is not ready for operation, because of a trip or because OFF1, OFF2 or OFF3 is a logic '0'.

### **Start disabled (START IN.)**

This status will only be displayed if, in parameter 599 *Statemachine, Profidrive* [1] has been selected and OFF2 or OFF3 is a logic '0'.

### **Exceptions XXXX (EXCEPTIONS XXXX)**

The microprocessor of the control card has stopped and the VLT frequency converter is out of operation.

The cause may be noise on the mains, motor or control cables, leading to a stop of the control card microprocessor.

Check for EMC-correct connection of these cables.





---

**VLT® 6000 HVAC**


---

**■ List of warnings and alarms**

No.	Description	Warning	Alarm	Trip locked
1	10 Volts low (10 VOLT LOW)	X		
2	Live zero fault (LIVE ZERO ERROR)	X	X	
4	Mains imbalance (MAINS IMBALANCE)	X	X	X
5	Voltage warning high (DC LINK VOLTAGE HIGH)	X		
6	Voltage warning low (DC LINK VOLTAGE LOW)	X		
7	Overvoltage (DC LINK OVERVOLT)	X	X	
8	Undervoltage (DC LINK UNDERVOLT)	X	X	
9	Inverter overloaded (INVERTER TIME)	X	X	
10	Motor overloaded (MOTOR TIME)	X	X	
11	Motor thermistor (MOTOR THERMISTOR)	X	X	
12	Current limit (CURRENT LIMIT)	X	X	
13	Overcurrent (OVERCURRENT)	X	X	X
14	Earth fault (EARTH FAULT)		X	X
15	Switch mode fault (SWITCH MODE FAULT)		X	X
16	Short-circuit (CURR.SHORT CIRCUIT)		X	X
17	Serial communication timeout (STD BUSTIMEOUT)	X	X	
18	HPFB bus timeout (HPFB TIMEOUT)	X	X	
19	Fault in EEprom on power card (EE ERROR POWER)	X		
20	Fault in EEprom on control card (EE ERROR CONTROL)	X		
22	Auto-optimisation not OK (AMA FAULT)		X	
29	Heat-sink temperature too high (HEAT SINK OVERTEMP)		X	
30	Motor phase U missing (MISSING MOT.PHASE U)		X	
31	Motor phase V missing (MISSING MOT.PHASE V)		X	
32	Motor phase W missing (MISSING MOT.PHASE W)		X	
34	HPFB communication fault (HPFB COMM. FAULT)	X	X	
37	Inverter fault (GATE DRIVE FAULT)		X	X
39	Check parameters 104 and 106 (CHECK P:104 & P:106)	X		
40	Check parameters 103 and 105 (CHECK P:103 & P:106)	X		
41	Motor too big (MOTOR TOO BIG)	X		
42	Motor too small (MOTOR TOO SMALL)	X		
60	Safety stop (EXTERNAL FAULT)		X	
61	Output frequency low (FOUT < FLOW)	X		
62	Output frequency high (FOUT > FHIGH)	X		
63	Output current low (I MOTOR < I LOW)	X	X	
64	Output current high (I MOTOR > I HIGH)	X		
65	Feedback low (FEEDBACK < FDB LOW)	X		
66	Feedback high (FEEDBACK > FDB HIGH)	X		
67	Reference low (REF. < REF. LOW)	X		
68	Reference high (REF. > REF. HIGH)	X		
69	Temperature auto derate (TEMPAUTO DERATE)	X		
99	Unknown fault (UNKNOWN ALARM)		X	X



VLT® 6000



Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed.



175R0107

MG60C402

