

# Contents

|  |         |
|--|---------|
| PREFACE .....  | I       |
| CHAPTER 1 SAFETY AND PRECAUTIONS .....                           | - 2 -   |
| 1.1 SAFETY PRECAUTIONS .....                                     | - 2 -   |
| 1.2 ATTENTION ITEMS .....  | - 6 -   |
| CHAPTER 2 PRODUCT INFORMATION .....                              | - 10 -  |
| 2.1 NAME DESIGNATION RULES AND NAMEPLATE .....                   | - 10 -  |
| 2.2 MAIN MODELS OF NICE 1000 INTEGRATED CONTROLLER SERIES: ..... | - 11 -  |
| 2.3 TECHNICAL SPECIFICATION .....                                | - 11 -  |
| 2.4 PRODUCT APPEARANCE .....                                     | - 13 -  |
| 2.5 DAILY MAINTENANCE OF CONTROLLER .....                        | - 16 -  |
| CHAPTER 3 INSTALLATION AND WIRING .....                          | - 20 -  |
| 3.1 SYSTEM CONFIGURE INTRODUCTION .....                          | - 20 -  |
| 3.2 MECHANICAL INSTALLATION .....                                | - 20 -  |
| 3.3 ELECTRIC INSTALLATION AND WIRING .....                       | - 21 -  |
| CHAPTER 4 INSTRUCTION OF DEBUGGING TOOLS .....                   | - 34 -  |
| 4.1 DEBUGGING TOOLS FOR NICE 1000 .....                          | - 34 -  |
| 4.2 OPERATION PANEL DESCRIPTION .....                            | - 34 -  |
| CHAPTER 5 FUNCTION PARAMETERS TABLE .....                        | - 40 -  |
| 5.1 DESCRIPTION OF FUNCTION PARAMETERS.....                      | - 40 -  |
| 5.2 FUNCTION PARAMETER TABLE .....                               | - 41 -  |
| CHAPTER 6 FUNCTIONAL PARAMETER SPECIFICATION .....               | - 78 -  |
| 6.1 GROUP F0 BASIC FUNCTION GROUP.....                           | - 78 -  |
| 6.2 F1 GROUP MOTOR PARAMETERS .....                              | - 80 -  |
| 6.3 GROUP F2 VECTOR CONTROL PARAMETER.....                       | - 84 -  |
| 6.4 GROUP F3 RUNNING CONTROL PARAMETERS.....                     | - 86 -  |
| 6.5 GROUP F4 POSITION PARAMETERS.....                            | - 91 -  |
| 6.6 F5 GROUP TERMINAL INPUT FUNCTION PARAMETERS .....            | - 94 -  |
| 6.7 GROUP F6 LIFT BASIC PARAMETERS .....                         | - 110 - |

|               |   |         |
|---------------|---|---------|
| 6.8 GROUP F7  | TERMINAL OUTPUT FUNCTION PARAMETER .....    | - 114 - |
| 6.9 GROUP F8  | REINFORCE FUNCTION PARAMETERS .....         | - 117 - |
| 6.10 GROUP F9 | TIME PARAMETERS.....                        | - 120 - |
| 6.11 GROUP FA | KEYBOARD SETTING PARAMETERS.....            | - 121 - |
| 6.12 GROUP FB | DOOR FUNCTION PARAMETERS .....              | - 127 - |
| 6.13 GROUP FC | PROTECTION FUNCTION PARAMETERS.....         | - 131 - |
| 6.14 FD GROUP | RESERVED PARAMETERS .....                   | - 133 - |
| 6.15 FE GROUP | LIFT FUNCTION SETTING PARAMETERS.....       | - 133 - |
| 6.16 GROUP FE | FACTORY PARAMETERS (RESERVED) .....         | - 139 - |
| 6.17 GROUP FP | USER PARAMETERS.....                        | - 139 - |
| CHAPTER       | TYPICAL SYSTEM APPLICATION & ADJUSTING..... | - 142 - |
| 7.1           | ELEVATOR ADJUSTING .....                    | - 142 - |
| 7.2           | SYSTEM TYPICAL APPLICATION.....             | - 143 - |
| CHAPTER 8     | FAULTS – CAUSES - REMEDIES .....            | - 154 - |
| 8.1           | FAULT CLASSIFICATION.....                   | - 154 - |
| 8.2           | FAULT DETAILS & REMEDIES .....              | - 155 - |

## Preface

NICE 1000 is the elevator integrated controller, which is under the research and development of SUHZOU MONARCH CONTROL TECHNOLOGY Co., Ltd. With the core of NICE 1000, the elevator electrical system adapts complete parallel modes for signal transfer and combines the advantage of high stability, easy using, free of debugging, all that makes NICE 1000 more perfectly suitable for villa elevators and freight elevators.

NICE 1000 integrated controller has the following features:

- Structural Features:

- 1) Compact structure

Integrated structure saves space for the control board, and reduces the size of the control cabinet.

- 2) 27 input points for switch signal

There are three strong electric input circuits in switch signal input; they can connect the safety circuit, hall door lock circuit, cage door lock circuit directly into the control board. It saves the links of the contactor, and reduces the fault points. Signals directly inputted into the main control board make the wiring in the control board more clear. It saves a lot of time in making the control cabinet and enhances the possibility of success, saving more than one in five control board wirings than those traditional freight lifts.

- 3) 20 points for buttons inputting and lights outputting

The main control board has 20 button input points. While there's no added point, it can fulfill the full selective application for 7 floors, and single selective application for 9 floors.

All the button points can be flexible defined. According to the required functions and the application situation, they can be flexible distributed. All the button points are shared by the inputting and outputting. One signal wiring fulfills the button's signal collection and indicator's outputting, greatly reducing the numbers of the wirings those buttons occupied.

- 4) fast speed counter port of encoder,

Corresponding frequency which reaches as high as 80 kHz can satisfy the encoder inputting with all wirings. Through the installation of different PG cards, synchronous motor can suit for the encoders of sine cosine and UVW types.

5) 24 points for relay output

The output groups are separated definitely. Each terminal's function can be flexibly defined. The unique design assures the complete automatic changeover ways of the power when there's power failure emergency and confirms the safety running of the villa elevator. It uses relay output to display output, and the code ways can be selected. Users can equip the display panel depends on their needs.

6) Expansion cards

It can expand 3 output points, 6 button input and output points, 1 MODBUS communication terminal, and 1 analog input terminal.

The expansion of the expansion cards for the button's input and output points enables NICE 1000 to cover all the application conditions of the freight elevator and villa elevator. The analog's input terminal can be used for the input and output of car cage load.

● Function Features:

- 1) Abundant door function setting can satisfy the goods lift's needs for the variety of the door control.
- 2) Practical and reliable power failure emergency application scheme, which can set passengers free automatically when power failure occurs.
- 3) The default is popularization, reducing the setting of vary application as much as possible.
- 4) After the appropriate settings in the factory, it can realize the zero parameter debugging on the spot.
- 5) Direct stopping function makes it more comfortable to take and more effective to run.
- 6) Over short floor running without special debugging.
- 7) Supplemented by the pre-opening module, it can easily fulfill the

functions of pre-opening and re-leveling after opening.

Instruction of NICE 1000 Elevator integrated controller:

| sequence       | Function   | Remark   | Sequence | Function  | Remark   |
|----------------|--|----------|----------|---|----------|
| Basic Function |  |          |          |   |          |
| 1              | Maintenance running                                | Standard | 27       | Repeating opening the door                        | Standard |
| 2              | Direct stopping                                    | Standard | 28       | Door opening signal to open the door at door zone | Standard |
| 3              | Self-rescue leveling                               | Standard | 29       | Hall opening                                      | Standard |
| 4              | Emergency rescue running                           | Standard | 30       | Pre-opening of door                               | Standard |
| 5              | Motor parameters self-tuning                       | Standard | 31       | Open the door and re-leveling                     | Standard |
| 6              | Shaft parameters self-tuning                       | Standard | 32       | Full load bypass                                  | Standard |
| 7              | Staircase lock function                            | Standard | 33       | Overload protection                               | Standard |
| 8              | Automatic back to the base floor                   | Standard | 34       | Attendant operation                               | Standard |
| 9              | Lights off for energy-saving                       | Standard | 35       | Direction reversing                               | Standard |
| 10             | Service floor setting for the front and back doors | Standard | 36       | Fire emergence back to base floor                 | Standard |
| 11             | Service floor setting                              | Standard |          |   | Standard |

| sequence | Function                              | Remark   | Sequence | Function                             | Remark   |
|----------|---------------------------------------|----------|----------|--------------------------------------|----------|
| 12       | Self-tuning for car location          | Standard | 37       | Independent running                  | Standard |
| 13       | Jumping floor display                 | Standard | 38       | Reversal protection running          | Standard |
| 14       | Cancel the wrong command              | Standard | 39       | Anti-skid protection                 | Standard |
| 15       | Reverse canceling                     | Standard | 40       | Contactors adhesion protection       | Standard |
| 16       | Automatic door switch                 | Standard | 41       | Motor Over-current protection        | Standard |
| 17       | Door keep opening time setting        | Standard | 42       | Power source over-voltage protection | Standard |
| 18       | Plural hall call in the same floor    | Standard | 43       | Motor overload protection            | Standard |
| 19       | Door fault protection                 | Standard | 44       | Encoder fault protection             | Standard |
| 20       | Open-through door independent control | Standard | 45       | Fault record                         | Standard |
| 21       | Door machine Artificial selection     | Standard | 46       | Weight compensation signal           | Standard |
| 22       | Reverse cancellation                  | Standard | 47       | Pre-torque setting                   | Standard |
| 23       | Automatic door switch                 | Standard | 48       | Full selective                       | Standard |
| 24       | Door keep opening                     | Standard | 49       | Communication state                  | Standard |

| sequence | Function                               | Remark   | Sequence | Function                                  | Remark   |
|----------|--|----------|----------|---|----------|
|          | time setting                           |          |          | surveillance                              |          |
| 25       | Plural hall call in the same floor     | Standard | 50       | Reduce the pick-up for outside hall calls | Standard |
| 26       | Door fault protection                  | Standard | 51       | Lock jump-out detection                   | Standard |
| Features |  |          |          |   |          |
| 52       | The best curve generated automatically | Standard | 56       | Lock jump-out protection                  | Standard |
| 53       | Up selective                           | Standard | 57       | Short-circuit test against the earth      | Standard |
| 54       | Down selective                         | Standard | 58       | Testing function                          | Standard |
| 55       | Call adhesion judgment                 | Standard | 59       | Force reducer monitoring function         | Standard |





## Safety and Precautions

---

## Chapter 1 Safety and Precautions

Safety definition:

There are two kinds of safety items in this manual:



Failure to follow the instructions will result in death or serious injury



Failure to follow these instructions can result in medium hurt or equipment damage

Please read this manual carefully and operate strictly according to the safety tips while installing, debugging, maintaining the system. MONARCH company is free of charge to any damage or loss caused by any operations that not performed according to the requirements.

### 1.1 Safety Precautions

#### 1.1.1 Before Installation



- Do not install in the condition of water seepage in the control system, components scarcity or damage while opening the case!
- Do not install while the packing list is not in the accordance with the products!



- Please uplift and drop gently in the portage otherwise the equipment will be damaged!
- Do not use any controller that is damaged or not complete. Cautious for the danger of getting hurt!
- Do not touch the elements of the controller with your hand, otherwise the static electricity hurt may be caused!

### 1.1.2 During Installation

**⚠ Danger**

- Please mount the controller on incombustible surface like metal, and keep away from flammable substances! Otherwise it may cause fire!
- Do not twist the fixing bolts of the components, especially the bolts with red marks!

**⚠ Note**

- Do not let wiring terminal or screw enter the controller, otherwise the controller will be damaged!
- Install the controller where there's less shaking and no direct sunshine.

### 1.1.3 During Wiring

**⚠ Danger**

- Only the qualified electrical engineer can perform the wiring, otherwise there will be danger of electric shock.
- A circuit breaker must be installed between the power supply and the controller; otherwise there will be danger of fire.
- Wiring can only be done after the power is cut off; otherwise there will be danger of electric shock.
- Please connect the controller to the ground according to the requirements, otherwise it will be dangerous

**⚠ Danger**

- Do not connect the input current with the controller's output terminals (U, V, W). Please note the marks and do not connect the wrong wires otherwise the controller may be damaged!
- Ensure the wiring meet the EMC requirements and the local safety standard. The wire size shall be determined according to the manual, otherwise accidents may occur!
- Brake resistor can never be connected between the DC bus terminals (+) and (-) directly, otherwise fire may occur!

**Danger**

- Encode connection must use Shielded line, shielding layer must be one side connected to earth reliably!
- Communication wires must use STP with the lay of 20mm~30mm, shielding layer must be connected to earth!

**1.1.4 Before Power-on****Note**

- Please confirm the mains voltage level is consistent with that of the controller ;the input (R,S,T) and output (U,V,W) wirings are correct; and check if there is any short circuit in peripheral circuit and if the wiring is fixed and fast; otherwise the controller may be damaged!
- Ensure the synchronous motor has done the dynamic self-learning and try to run the motor before restoring wire ropes.
- No part of controller needs further dielectric strength testing since it has been done in the factory; Otherwise accidents will occur!

**Danger**

- Mount the cover plate properly before power-on the controller; otherwise there will be danger of electric shock!
- All the external parts wirings must be connected according to the instruction of this manual, otherwise accidents may occur!

**1.1.5 Upon Power-on****Danger**

- Do not open the cover of the controller after power-on, otherwise there will be danger of electric shock!
- Do not touch the controller and its circuit with wet hand; otherwise there will be danger of electric shock.
- Do not touch the controller terminals; otherwise there will be danger of electric shock.
- At power-on, the controller will perform the security check of the external heavy-current circuit. At this time do not touch U, V, W terminals of controller or the wirings terminals of the motor; otherwise

there will be danger of electric shock!

 **Danger**

- If parameter identification is required, please pay attention that the rotating motor may injure people, otherwise accident may occur!
- Do not change the factory settings; otherwise the equipment may be damaged!

### 1.1.6 Running

 **Danger**

- Do not touch the fan and the discharging resistor to check the temperature, otherwise burning will occur!
- Only the qualified technician can check the signal while it's running. Otherwise there will be danger of personal injury or equipment damage!

 **Note**

- Do not let objects fall in a running controller; otherwise the controller may be damaged!
- Do not start and stop the controller by on/off of the contactor, otherwise the controller may be dangerous.

### 1.1.7 Maintenance

 **Danger**

- Please do not repair or maintain the controllers with power on, otherwise there will be danger of electric shock!
- Ensure the repair and maintenance of the controller is operated in the condition that the controller voltage is below AC36V, two minutes after the power is switch-off. Otherwise the residual Charge in the capacitor will injure people.
- Only qualified electrical engineer can repair or maintain the controller, otherwise there will be danger of human injury or damaging the equipment.
- Reset the parameters after changing the controller; all the insets must

|   |
|---|
| be unplugged while the power is switch-off! |
|---|

## **1.2 Attention Items**

### **1.2.1 Motor insulation check**

When the motor is used for the first time, or reused after storing for a long time, or in a regular checkup, the user must check the insulation of the motor to prevent the poor insulation of the windings of motor from damaging the controller. The motor connection must be divided from the controller during the insulation check. It is recommended to use a 500V Mega-Ohm-Meter to check and the insulation resistance shall not be less than 5MΩ.

### **1.2.2 Thermal Protection of Motor**

If the rated capacity of the motor selected is not matching that of the controller, especially when the rated power of the controller is bigger than that of the motor, make sure to adjust the parameters for motor protection inside the controller or to install a thermal relay to the motor to guarantee the protection to the motor.

### **1.2.3 Motor Heat and Noise**

Since the output voltage of the controller is in PWM wave with some harmonic wave, the temperature may raise, the noise and vibration may increase compared with the controller running at main frequency.

### **1.2.4 Pressure-sensitive Device or Capacitor at the Output Side of the Controller**

Because the controller outputs PWM wave, the capacitor used for improving power factor and pressure-sensitive resistor used for lightning-proof shouldn't be installed at the output side of the controller. Otherwise the controller may have transient over-current and may be damaged.

### **1.2.5 Switches Used at the Input and Output terminal of the Controller**

If the contactor is required to be installed between the controller input terminal and the power supply, it is prohibited to start or stop the controller with the contactor. If the switches like contactors are connected between the output terminal and the motor, make sure to start and stop the controller when the controller has no outputting, otherwise the modules in the

controller may be damaged.

#### **1.2.6 Usage out of the Range of Rated Voltage**

The NICE1000 controller shall not be used out of the specified range of operation voltage. Otherwise the internal components of the controller may be damaged. If needed, please use corresponding voltage regulation device to change the voltage.

#### **1.2.7 Lightning Strike Protection**

There are lightning protection devices inside the controller, but the user should install other lightning protection device at the front end of the controller if lightning strike occurs frequently.

#### **1.2.8 Altitude and De-rating**

When the altitude is higher than 1000m, the cooling effect of consult is deteriorated because of the rarefaction of air, then it is a necessity to derate the use of controller and please contact our company for detailed technical support in this circumstance.

#### **1.2.9 Cautions for Scrap of controller**

The electrolytic capacitors in the main circuits and PCB may explode when they are burned and poisonous gas may be generated when the plastic parts are burned. Please dispose the controller as industrial rubbish.

#### **1.2.10 About Applicable Motor**

- 1) The controller is applicable to squirrel-cage asynchronous motor and AC permanent-magnet synchronous motor. Please be sure to select the applicable controller according to the Data plate of the motor.
- 2) The controller has already been configured with default parameters which is applicable to squirrel-cage Asynchronous motor. To perform the motor parameter identification according to the actual conditions will promote the operation effect. Synchronous motor must carry out parameter tuning.
- 3) The output part of controller should not be short. Otherwise the controller may alarm or be damaged. Therefore, before Power-on, we must execute short-circuit-test for new elevator. Please make sure that the controller be cut from the testing parts when the

testing is undergoing..



## Product information


---

## Chapter 2 Product information

### 2.1 Name Designation Rules and Nameplate

#### 2.1.1 Applies to Asynchronous/ Synchronous motor:

Name designation rules:



Structure number G presents for Asynchronous motor;

Structure number V presents for Synchronous motor.

#### 2.1.2 Applies to Asynchronous/ Synchronous motor:

Name designation rules:

Asynchronous motor nameplate:

|  |                          |
|--|--------------------------|
| <b>MODLE</b>                               | NICE-L-G-4015            |
| <b>POWER</b>                               | 15kW                     |
| <b>INPUT</b>                               | 3PH AC380V 36A 50Hz/60Hz |
| <b>OUTPUT</b>                              | 3PH AC380V 33A 0~90Hz    |
| <b>S/N</b>                                 |                          |
| Suzhou MONARCH Control Technology Co.,Ltd. |                          |

Synchronous motor nameplate:

|  |                          |
|--|--------------------------|
| <b>MODLE</b>                               | NICE-L-V-4015            |
| <b>POWER</b>                               | 15kW                     |
| <b>INPUT</b>                               | 3PH AC380V 36A 50Hz/60Hz |
| <b>OUTPUT</b>                              | 3PH AC380V 33A 0~90Hz    |
| <b>S/N</b>                                 |                          |
| Suzhou MONARCH Control Technology Co.,Ltd. |                          |

**2.2 Main models of NICE 1000 integrated controller series:**

| Model           | Input Voltage                       | Power Capacity(KVA) | Input Current (A) | Output Current(A) | Adaptable Motor(KW) |
|-----------------|-------------------------------------|---------------------|-------------------|-------------------|---------------------|
| NICE-L-G/V-2002 | Three phase 220V                    | 4.0                 | 13.2              | 9.6               | 2.2                 |
| NICE-L-G/V-2003 | Range: -15%~20%                     | 5.9                 | 17.0              | 15.6              | 3.7                 |
| NICE-L-G/V-4002 | Three phase 380V<br>Range: -15%~20% | 4.0                 | 6.5               | 5.1               | 2.2                 |
| NICE-L-G/V-4003 |                                     | 5.9                 | 10.5              | 9.0               | 3.7                 |
| NICE-L-G/V-4005 |                                     | 8.9                 | 14.8              | 13.0              | 5.5                 |
| NICE-L-G/V-4007 |                                     | 11.0                | 20.5              | 18.0              | 7.5                 |
| NICE-L-G/V-4011 |                                     | 17.0                | 29.0              | 27.0              | 11                  |
| NICE-L-G/V-4015 |                                     | 21.0                | 36.0              | 33.0              | 15                  |
| NICE-L-G/V-4018 |                                     | 24.0                | 41.0              | 39.0              | 18.5                |
| NICE-L-G/V-4022 |                                     | 30.0                | 49.5              | 48.0              | 22                  |
| NICE-L-G/V-4030 |                                     | 40.0                | 62.0              | 60.0              | 30                  |

The products with the input voltage 220V correspond to 3- phase inputting. If the input voltage is single phase, it shall match with a larger frequency. For example, NICE-L-G-2003 can be used in the situation that single phase inputting 220V to drive the motor with 2.2 KW.

**2.3 Technical Specification**

| Item          |                   | Specification  |
|---------------|-------------------|--|
| Specification | Maximum frequency | 90Hz   |
|               | Carrier frequency | 0.5k~16k (Hz); Carrier frequency can be adjusted automatically according to the load characteristic. |
|               | Control mode      | Open loop vector control (SVC)/ Closed loop vector control (VC)                                      |

| Item                          | Specification  |               |
|-------------------------------|--|---------------|
| Start torque                  | Type G: 0.5Hz / 180% (SVC), 0Hz/200% (VC)  |               |
| Speed adjustment range        | 1 : 100 (SVC)  | 1 : 1000 (VC) |
| Speed stabilization precision | ±0.5%(SVC)   | ±0.05%(SVC)   |
| Torque control precision      | ±5%(VC)  |               |
| Overload capability           | 150% rated current for 60 seconds; 200% rated current for 1 second.  |               |
| Motor tuning                  | Asynchronous motor: Static tuning<br>Synchronous motor: Initial angle tuning   |               |
| Distance control              | Flexible adjustment for leveling direct stop   |               |
| Speed up and speed down curve | N curves can generate automatically.   |               |
| Re-leveling                   | Leveling re-adjustments after the car load changes   |               |
| Compulsive deceleration       | New and reliable compulsive deceleration function helps to identify the deceleration shelf automatically.  |               |
| Well self-tuning              | 32-bit data, record the well position accurately.  |               |
| Leveling adjustment           | Flexible and easy leveling adjustment function   |               |
| Starting torque compensation  | considerate weighing self-learning   |               |
| Testing function              | Convenient ways to realize many functions for elevator adjusting.  |               |
| Failure protection            | Provide 53 variety kinds of protection such as electrify short circuit survey, in-out lack phase protection, over current protection, encoder protection etc. A complete elevator fault-dealing system |               |
| Electrify peripheral          | Implement electrify and do peripheral equipment detection  |               |

| Item                        |                                   | Specification   |
|-----------------------------|-----------------------------------|---|
|                             | equipment safety self-examination | like grounding, short circuit etc.  |
|                             | State monitor                     | According each feedback signal to judge elevator work state, ensure the elevator work effectively.  |
|                             | Digital input                     | 24 Digital input terminal, specification:24V, 5mA   |
|                             | Analog data input                 | Expansion board offers analog data input , inputting voltage range: 0V~10V  |
| Input/output characteristic | Communication terminal            | Expansion board offers Modbus communication   |
|                             | Output terminal                   | 24 relay output   |
|                             | Encoder interface                 | Default apply increment push-pull output and plough collector output;<br>MCTC-PG-D apply U,V,W type encoder;<br>MCTC-PG-E apply sine cosine increment encoder |
|                             | Operation panel                   | 5-bit LED display, show parameters of function, running speed, bus voltage, etc.  |
|                             | Small keyboard                    | Well self-tuning  |
| Display and keypad          | State monitoring                  | Monitoring parameters in different states   |
|                             | Altitude                          | Lower than 1000m  |
|                             | Ambient temperature               | -10℃~ +40℃ ( ambient temperature is within 40℃~50℃ , and de-rating is required)   |
| Application environment     | Humidity                          | Less than 95% RH, without condensation  |
|                             | Vibration                         | Less than 5.9m/s <sup>2</sup> (0.6g)  |
|                             | Storage temperature               | -20℃ ~ +60℃   |



**2.4 Product Appearance**


The controller has three types of size, listed in the following diagram:




| Model           | Adaptable Motor (KW) | Structural Type |
|-----------------|----------------------|-----------------|
| NICE-L-G/V-2002 | 2.2                  | SIZE-C          |
| NICE-L-G/V-2003 | 3.7                  | SIZE-C          |
| NICE-L-G/V-4002 | 2.2                  | SIZE-C          |
| NICE-L-G/V-4003 | 3.7                  | SIZE-C          |
| NICE-L-G/V-4005 | 5.5                  | SIZE-C          |
| NICE-L-G/V-4007 | 7.5                  | SIZE-D          |
| NICE-L-G/V-4011 | 11                   | SIZE-D          |
| NICE-L-G/V-4015 | 15                   | SIZE-D          |
| NICE-L-G/V-4018 | 18.5                 | SIZE-E          |
| NICE-L-G/V-4022 | 22                   | SIZE-E          |
| NICE-L-G/V-4030 | 30                   | SIZE-E          |

Note: The products with other frequency such as over 37KW are not listed because of seldom using. If you need these products please contact us for details.





(c) SIZE-E



## 2.5 Daily Maintenance of Controller

Since the influence of ambient temperature, humidity, dust, and vibration, the components in controller may become aging and wearing, which will give rise to the occurrence of potential faults and reduce the life of controller. Therefore, it is quite necessary to do the work of daily maintenance of controller.



The filter capacitor still has high voltage after the power supply to the controller is switched off, so do not maintain or repair the controller until the bus voltage measured after 2 or 3 minutes with the multi-meter. The voltage must be lower than 36V.

**2.5.1 Daily Maintenance**

- 1) Daily checking items:
  - a) Check if there is any abnormal noise during the running of motor;
  - b) Check if there is any vibration of motor ;
  - c) Check if the installation environment of controller changes ;
  - d) Check if the cooling fan of controller works normally ;
  - e) Check if the controller is over heated.
- 2) Daily Cleaning:
  - a) Keep the controller in a clean status;
  - b) Clean the dust from the controller and prevent the dust especially the metal powder from entering the controller;
  - c) Clean the oil dirt in the cooling fan of the controller.

**2.5.2 Periodical Checking**

Periodically check the places that are hardly checked during the running.

- 1) Periodical Checking Items
  - a) Check the ventilation channels and clean them periodically;
  - b) Check if the screws are loosen;
  - c) Check if the controller is corroded;
  - d) Check if the input / output terminal has scratch marks;
  - e) Check the insulating in main circuit.

Note: Insulation test (use 500V Mega-Ohm-Meter) should be done separately after disconnecting the input power cables from the controller; or else, the controller will be damaged. Do not use the Mega-Ohm-Meter to test the insulation of control circuits. Dielectric strength test had been done at factory. Therefore, user need not do this test again.

**2) Replacement of Wearing Parts**

The wearing parts of controller mainly include the cooling fan and filtering

---

electrolytic capacitor. Their lifetime is closely related to the operating environment and maintenance.

General lifetime as follows:

| Component              | Lifetime    |
|------------------------|-------------|
| Fan                    | 2 ~ 3 years |
| Electrolytic capacitor | 4 ~ 5 years |

The user can determine the year of replacement according to the operating time.

1) Cooling fan

Possible damage causes: shaft bearing attrition and blade aging.

Criteria: no crack on fan blade, no abnormal vibration noise at start.

2) Filtering electrolytic capacitor

Possible damage causes: high ambient temperature, big pulsating current due to frequent load fluctuation, electrolyte aging.

Criteria: no liquid leak, no protrusion of safety valve, electrostatic capacitance measurement, and insulation resistance measurement.

### 2.5.3 Controller Storage

The following points must be noticed in controller storage:

1) It is recommended to store the controller in its original packing box.

2) Long-term storage will cause deterioration of electrolytic capacitor. Therefore, controllers not in service for a long time must be powered for at least once within 2 years for testing purpose, at least for 5 hours ; in the test , the input voltage must be boosted gradually with voltage regulator to the rated value.



## Installation and wiring

## Chapter 3 Installation and wiring

### 3.1 System Configure Introduction




Fig. 3-1

### 3.2 Mechanical Installation

NICE 1000 controller installation size requirements:




Fig. 3-2 controller installation size requirements

The unit in the figure is mm.

A shall be not smaller than 50mm for the controller of 22kW or above.

### 3.3 Electric Installation and Wiring

#### 3.3.1 Using of External Device

| Device            | Position  | Function  |
|-------------------|---|---|
| Air breaker       | Front-end of input circuit                                    | Cut off the power and provide short protection.   |
| Contactora        | between air breaker and controller                            | Switch on/off the controller; controlled by safe circuit.   |
| AC input reactor  | Controller input side   | Improving the power factor of the input side; eliminate high frequency humorous wave in input side; eliminate current unbalance due to input phase unbalance; |
| DC reactor        | Built-in as standard  | Improving the power factor of the input side; eliminate high frequency humorous wave in input side; eliminate current unbalance due to input phase unbalance; |
| AC output reactor | Between controller output side and motor, and near controller | If the distance between the vector driver and the motor is longer than 100m, it is recommended to install the AC output reactor.                              |

#### Selecting of External Device

| Model           | Air circuit breaker (MCCB) (A) | Contactora (A) | Conducting Wire of Main Circuit at the Input Side (mm <sup>2</sup> ) | Conducting Wire of Main Circuit at the Output Side (mm <sup>2</sup> ) | Conducting Wire of control circuit (mm <sup>2</sup> ) | Grounding wire (mm <sup>2</sup> ) |
|-----------------|--------------------------------|----------------|--|---|---|-----------------------------------|
| NICE-L-G/V-2002 | 20                             | 16             | 4  | 4   | 1   | 4                                 |
| NICE-L-G/V-2003 | 32                             | 25             | 6  | 4   | 1   | 4                                 |
| NICE-L-G/V-4002 | 16                             | 10             | 4  | 4   | 1   | 4                                 |
| NICE-L-G/V-4003 | 25                             | 16             | 4  | 4   | 1   | 4                                 |
| NICE-L-G/V-4005 | 32                             | 25             | 4  | 4   | 1   | 4                                 |
| NICE-L-G/V-4007 | 40                             | 32             | 6  | 6   | 1   | 4                                 |

| Model           | Air circuit breaker (MCCB) (A) | Contact (A) | Conducting Wire of Main Circuit at the Input Side (mm <sup>2</sup> ) | Conducting Wire of Main Circuit at the Output Side (mm <sup>2</sup> ) | Conducting Wire of control circuit (mm <sup>2</sup> ) | Grounding wire (mm <sup>2</sup> ) |
|-----------------|--------------------------------|-------------|--|---|---|-----------------------------------|
| NICE-L-G/V-4011 | 63                             | 40          | 6  | 6   | 1   | 4                                 |
| NICE-L-G/V-4015 | 63                             | 40          | 6  | 6   | 1   | 4                                 |
| NICE-L-G/V-4018 | 100                            | 63          | 10   | 10  | 1   | 4                                 |
| NICE-L-G/V-4022 | 100                            | 63          | 10   | 10  | 1   | 4                                 |
| NICE-L-G/V-4030 | 125                            | 100         | 16   | 16  | 1   | 4                                 |
| NICE-L-G/V-4037 | 160                            | 100         | 16   | 16  | 1   | 4                                 |
| NICE-L-G/V-4045 | 200                            | 125         | 25   | 25  | 1   | 4                                 |

### 3.3.2 Driving Brake Resistance (DBR)

NICE 1000 elevator integrated controller's motors with no more than 30 KW, have been equipped inside with driving brake unit. User just needs to connect external driving brake resistance. Motors with more than 30 KW need external driving brake unit and resistance.

| Model         | DBR Specification | Driving Brake Unit       |        |
|---------------|-------------------|--------------------------|--------|
| MCTC-DBR-2002 | 1100W,130Ω        | Standard<br>installation | Inside |
| MCTC-DBR-2003 | 1600W,90Ω         |                          |        |
| MCTC-DBR-4002 | 600W,220Ω         |                          |        |
| MCTC-DBR-4003 | 1100W,130Ω        |                          |        |
| MCTC-DBR-4005 | 1600W,90Ω         |                          |        |
| MCTC-DBR-4007 | 2500W,65Ω         |                          |        |
| MCTC-DBR-4011 | 3500W,43Ω         |                          |        |
| MCTC-DBR-4015 | 4500W,32Ω         |                          |        |
| MCTC-DBR-4018 | 5500W,25Ω         |                          |        |
| MCTC-DBR-4022 | 6500W,22Ω         |                          |        |
| MCTC-DBR-4030 | 9000W,16Ω         |                          |        |

**3.3.3 Electric wiring**

Electric wiring include two parts: Controller main circuit terminal wirings and main control board wirings.

1) Main circuit connection and terminal function

a) main circuit:




Fig. 3-3 Main Circuit Wiring

b) terminal function:

| Terminal | Name                                      | Description   |
|----------|---|---|
| R,S,T    | 3-phase power input terminal              | Input 3-phase AC380V  |
| (+),(-)  | Positive and negative terminals of DC bus | Terminal of external brake unit for controller above 37KW.      |
| P(+),PB  | Terminals for brake resistor              | For controller below 30kW(include 30kW) they are for brake unit |
| U,V,W    | controller output terminal                | Connect 3-phase motor   |
| PE       | Terminal for grounding                    | Grounding terminal  |

Note:

- ☆ Select the recommended resistor according to section 3.3.2.
- ☆ Controller output circuit grounding or short circuit is absolutely not permitted.
- ☆ Controller output cables of U, V and W should be in metal pipe with grounding, and divided or vertical with control circuit cables.
- ☆ If the cables between the motor and the controller are too long, electrical resonance may occur due to the distributed capacitance, which may result in damaging the motor insulation or big leakage

current that will make the controller go into protective status.

☆ Grounding terminal must be connected to earth reliably, the grounding cable should be thick and short, the recommended grounding cable should be special yellow-green cable above 4 mm<sup>2</sup> with several copper cores. And the grounding resistance shall be less than 4Ω. Do not share the earth end and neutral line of the main supply.

2) MCTC-MCB-A main control panel wiring instruction

a) main control panel installation location:




Fig. 3-4

b) indicator light instruction of MCB:

| Terminal | Name  | Instruction  |
|----------|---|--|
| ER       | Error indicator                             | when error, ER indicator lighten (red)   |
| OK       | OK indicator                                | when no error, OK indicator lighten (green)  |
| MOD      | MODBUS communication indicator              | when expansion board MODBUS communication well, indicator lighten (green)                  |
| X1~X24   | Input signal indicator                      | when external input, indicator lighten (green)   |
| L1~L20   | Button signal collective/Feedback indicator | When button input signal connected and responding signal output, indicator lighten (green) |

| Terminal         | Name                                     | Instruction  |
|------------------|--|--|
| Y0~Y3,<br>Y6~Y22 | Output signal indicator                  | when signal output, indicator lighten (green)  |
| J5,J6            | Communication interface selection jumper | J5, J6 synchronously connect with 232 two feet, selection serial communication function is main control board serial communication; J5, J6 synchronously connect with PRG two feet, selection serial communication function is program download.   |
| J8               | Program download jumper                  | Connected with ON two feet, main control board is in program download model; Connected with OFF two feet, main control board is in normal work model.<br>Note: In normal work state, J8 must be connected with OFF two feet, and J5, J6 must be connected synchronously with 232 two feet. |
| S1               | Well self-tuning button                  | Keep pressing the button for 3s, the lift shall get into well self-tuning automatically.   |

c) Main control board terminal list:





Fig. 3-5

d) Plug-in unit CN10 and CN11 instruction:

| Terminal | Name                                    | Terminal description  |
|----------|---|---|
| X1~X24   | digital signal input function selection | 1.photocoupler isolation input<br>2.input resistance : 4.7KΩ<br>3.input voltage range:10~30V<br>4.input current limit :5mA<br><br><b>NICE1000</b><br>Digital terminal function decided by F5-01~F5-24 |

e) Plug-in unit CN8 and CN10 power instruction:

| Terminal | Name                 | Description  |
|----------|----------------------|--|
| 24V      | External DC24V input | Provide MCTC-MCB-A main control board and MCTC-KZ-B expansion board with DC24V, for input, output circuit. |
| COM      |                      |  |

f) lug-in unit CN8 and CN9 output terminal instruction:

| Terminal | Name                      | Description  |
|----------|---------------------------|--|
| L1~L20   | Button function selection | Button input signal connection and button light outputting, output 24V for button lightening |

g) Plug-in unit CN3 output terminal instruction:

| Terminal | Name                 | Description  |
|----------|----------------------|--|
| XCM      | External power input | The shared contact by safety circuit and lock feedback circuit, can bear the voltage ranging from AC95V~AC125V |

## Monarch

| Terminal          | Name                            | Description  |
|-------------------|---------------------------------|--|
| X25<br>X26<br>X27 | Safety, lock feedback input     | Safety circuit and lock feedback circuit, corresponding function code set by F5-25~F5-27               |
| Y0~Y3             | Relay output                    | The relay outputs 5A, 250VAC or 5A, 30VDC, and corresponding function code is decided by F7-00 ~F7-03. |
| M0~M3             | Relay outputting shared contact | M0, M1, M2, and M3 are the shared contacts separately corresponding to Y0, Y1, Y2, and Y3              |

### h) Plug-in unit CN4 and CN5 output terminal instruction:

| Terminal | Name                            | Description  |
|----------|---------------------------------|--|
| Y6~Y22   | Relay outputting                | The relay outputs 5A, 250VAC or 5A, 30VDC, and corresponding function code is decided by F7-06 ~F7-22.               |
| YM1~YM3  | Relay outputting shared contact | YM1 is the shared contact by YM6~YM9, YM2 is the shared contact by Y10~Y16, and YM3 is the shared contact by Y17~Y22 |

### i) Plug-in unit CN2 encoder contact terminal instruction:

| Terminal | Name                       | Description   |
|----------|----------------------------|---|
| 12V      | DC12V output               | Provide DC15V for encoder, suit for incremental push-pull output or incremental plough collector output.  |
| PGM      |                            |   |
| PGA      | coding pulse input A phase | Incremental coding pulse signal inputting, frequency dividing signal input A phase and B phase in V motor, PG card..<br>The system will show the fault of encoder if A phase and B phase are wrongly connected. |
| PGB      | coding pulse input B phase |   |
| PGM      | DC12                       | Power 0V terminal   |
| PE       | Grounding terminal         | Encoder wire shield layer   |

CN1 is a panel terminal and CN6 is a master machine monitoring interface

### 3) MCTC-KZ-B expansion board electric wiring instruction

The expansion board is mainly used for floor input button expansion, relay output expansion, analog weighing expansion and MODBUS communication expansion.

#### a) Appearance and size of expansion board

The expansion board is equipped on the main control board through J11 contact. Appearance and size are as the following figure:




Fig. 3-6 MCTC-KZ-B appearance and size

#### b) Instruction for the expansion board's indicator and jumper

| Terminal   | Name   | Description  |
|------------|--|--|
| L21~L26    | Expansion button signal collective/Feedback indicator    | When the input signal of the expansion floor's button is connected, and responding signal outputted, the indicator lighten (green).  |
| Y4~Y5, Y23 | Expansion relay output signal indicator                  | When the system has expansion relay outputting, the indicator lighten (green).   |
| J4         | MODBUS communication terminal matching resistance jumper | Connected with ON, MODBUS communication terminal matching resistance is valid; Connected with OFF two feet, MODBUS communication terminal matching resistance is invalidation.     |
| J12, J13   | MODBUS communication enables jumper                      | MODBUS communication is valid when J12, J13 are connected with 485 synchronously.<br>Note: At that moment, all the jumpers of J5, J6 in the main control board must be turned off. |

c) Expansion board terminal plug-in unit list:

| CN12 |  | CN13 |  |
|------|--|------|--|
| L21  |  | Y4   |  |
| L22  |  | M4   |  |
| L23  |  | Y5   |  |
| L24  |  | M5   |  |
| L25  |  | Y23  |  |
| L26  |  | YM4  |  |
| MOD+ |  |      |  |
| MOD- |  |      |  |
| Ai   |  |      |  |
| M    |  |      |  |

Fig. 3-7 MCTC-KZ-B terminal definition

d) Instruction of expansion board plug-in unit CN12:

| Terminal   | Name                                | Description  |
|------------|-------------------------------------|--|
| L21~L26    | Expansion button function selection | Expansion button input signal connection and button light outputting, output 24V for button lightening |
| MOD+, MOD- | MODBUS communication signal wire    | Used for expansion MODBUS communication  |
| Ai, M      | Expansion analog input              | 0~10V analog input, M is the shared contact, can be used for analog weighing                           |

e) Instruction of expansion board plug-in unit CN13:

| Terminal | Name                        | Description   |
|----------|-----------------------------|---|
| Y4~Y5    | Relay output                | The relay outputs 5A, 250VAC or 5A, 30VDC, and corresponding function code is decided by F7-04 ~F7-05.    |
| M4~M5    | Relay output shared contact | M4 is the shared contact of Y4, and M5 is the shared contact of Y5.                                       |
| Y23      | Relay output                | The expansion relay outputs 5A, 250VAC or 5A, 30VDC, and corresponding function code is decided by F7-23. |
| YM4      | Relay output shared contact |   |

4) Encoder wiring

a) Following items should be noticed in encoder wiring:

- PG wire should be laid separately and keep distance from control circuit and driver circuit and forbidden to parallel with them.
  - PG wire should be shield wire, and shield layer should connect to PE near controller. (In order to avoid being disturbed, only one terminal connects to ground.)
  - PG wire should be pulled on pipe separately, and metal crust should be connected to ground reliably.
- b) Instruction of encoder wiring
- Encoder connection of increment push-pull output and plough collector output.

MCTC-MCB-G equipped with push-pull encoder trans-connection card, the encoder connection is as follows:




Fig. 3-8 connection of incremental push-pull output and plough collector output encoder


- Type U, V, W and SIN/COS encoder wiring

For NICE 1000, when it uses synchronous motor, SIN/COS is recommended to the users.

For UVW encoder, MCTC-PG-D is assorted with the system.


For SIN/COS encoder, MCTC-PG-E is assorted with the system.

MCTC-PG-D and MCTC-PG-E use DB15 connector and UVW encoder or SIN/COS encoder to connect. The pins' meaning of DB15 connector is listed as follows:

| model     | Pin's meaning of DB 15   | Applicable encoder |
|-----------|--|--------------------|
| MCTC-PG-D | <br>1: A+    2: A-    3: B+<br>4: B-    5: NC    6: NC<br>7: U+    8: U-    9: V+<br>10: V-    11: W+    12: W-<br>13: VCC 14: COM 15: NC | UVW encoder        |
| MCTC-PG-E | 1: B-    2: NC    3: Z+<br>4: Z-    5: A+    6: A-<br>7: COM    8: B+    9: VCC<br>10: C+    11: C-    12: D+<br>13: D-    14: NC    15: NC  | SIN/COS encoder    |

MCTC-PG-D and MCTC-PG-E can be installed on the main control board through the J11 connector on the board. Its size and appearance are as follows:

a) MCTC-PG-D



b) MCTC-PG-E




Fig. 3-9 Appearance and size of MCTC-PG-D and MCTC-PG-E  
Fig. a), MCTC-PG-D CN2 is the analog inputting terminal.



## Instruction of debugging tools

---

## Chapter 4 Instruction of debugging tools

### 4.1 Debugging tools for NICE 1000

Debugging tools of NICE1000 include three types: operation control and information display panel (operation panel for short), upper monitor motoring software of NICE 1000, and PDA monitoring software. This chapter is focus on the operation panel.

### 4.2 Operation Panel Description

Through operation panel, user can modify the parameter, monitor the working state, and control running (start and stop) when operation panel is working.

#### 4.2.1 The Appearance and Function Section of Operation Panel

The appearance as Fig. 4-1:

- 1) Instruction of function indicator lights:

RUN LED on indicates the controller is working.

LOCAL/REMOT Reserved.

FWD/REV Indicator of up and down. LED on indicates the elevator goes down; LED off, up.

TUNE/TC Indicator of tuning. LED on, tuning.

- 2) Digital display area

5-bit LED display, show the parameters of running speed, bus voltage, etc.


- 3) Units indicator instruction:

The units' indicator indicates the unit of the figure of the digital display area. When two LEDs are on, it indicates the central unit figure below the 2 LEDs.

Hz:  
Frequency unit

A: Current unit

V: Voltage unit








Fig. 4-2 3-level menu operational procedures

Instruction: When in 3rd menu, system can back to 2nd menu by pressing **PRG** or **ENTER**. The difference between the two ways is: it saves parameter after pressing **ENTER**, then back to next function code in 2nd menu; whereas it does not save parameter after pressing **PRG**, then keep staying at the current function code in 2nd menu.

Example: Change function code F0-06 from 50.00Hz to 15.00Hz (bold means flash bit).




Fig. 4-3 Example for Parameter Change

In the three-level menu, if the parameter has no flash bit, it means the function code cannot be changed and the possible reasons are:

- 1) This parameter of this function code cannot be changed, such as the actually detected parameter and running record parameter.
- 2) This function code cannot be changed in operating status and can only be changed when the controller is stopped.
- 2) To shift the status display parameters by key >>

Example:




Fig. 4-4 Example of Parameter Changing in Stopping State

In stopping and running status, the LED can display several status

parameters. Whether to display the status parameters depends on the bit setting of FA-01 (running parameter) and FA-02 (stopping parameter). Through key **>>**, user can shift the display in sequence and display the stopping or running status parameters circularly.

In stopping state, there are 12 status parameters for NICE1000, user can shift to display the parameters circularly by key **>>**. The parameters are: rated speed, bus voltage, current floor, current position, car load, rated decelerate distance, system state, input terminal 1 state, input terminal2 state, input terminal3 state, output terminal 1 state, output terminal 2 state. Users can select the desired parameters through the bit of FA-02.

In running state, there are 16 state parameters for NICE1000. Users can shift to display the parameters circularly by key **>>**. The parameters are: running speed, rated speed, bus voltage, output voltage, output current, output frequency, current floor, current position, car load, system state, pre-torque current, input terminal 1 state, input terminal 2 state, input terminal 3 state, output terminal 1 state, output terminal 2 state. Users can select the desired parameters through the bit of FA-01.

### 3) Error information reading

When error occurs in the controller, the error information will be displayed on the panel. It is convenient to find reasons for the error and rule out the error as soon as possible.

The controller can save the last 6 error codes. Users can read the first error code in the following way:




Fig. 4-5 Method of viewing error information

### 4.2.3 Password Setting

In order to protect the parameter more effectively, the controller provides the password protection.

The figures below show how to change the password to 12345 (bold shows flashing bit):




Fig. 4-9 Password setting procedure

When the user has set the password (the password parameter of FP-00 shouldn't be ZERO), the password protection function is valid once the user presses PRG, and the controller shall display "-----". The user can enter the menu only after inputting the user password. For factory setting parameters editing, the user still need to input the factory password. (Warning: do not change the factory setting parameter; if the parameter values are wrong, the controller will work abnormally, even be damaged.)

When the password protection is unlocked, user can change the password freely, and the last input number will be the user password.

If the user wants to cancel the password protection function, enter after inputting the password and set FP-00 as 0; when the power is on, the parameter will be protected by the password if FP-00 isn't set ZERO.



## Function parameters

---

## Chapter 5 Function parameters table

### 5.1 Description of function parameters

1. Function parameters are classified into 17 groups. Each group has several function codes. The function code uses 3-level menu with the format "F X-XX", which means "No. XX function code in group X". For example, F 8-08 means the No.8 function code in group F8.

In order to make functional code setting convenient, the function group number corresponds to first level menu, the function code number corresponds to second level menu, and function code parameters correspond to third level menu.

2. Contents in the function table:

Column 1 "function code", means the serial number for function parameter group and parameter;

Column 2 "name", means the complete name of the function parameter;

Column 3 "setting range", means the parameter setting range;

Column 4 "minimum unit", means the minimum unit of the parameter setting;

Column 5 "factory setting", means the original default;

Column 6 "operation", means the modification attributes of the parameters (whether to enable the modification and the modification requirements).

Instructions are listed below:

☆: the parameter can be modified while the NICE1000 is running or stopping;

★: the parameter can not be modified while the NICE1000 is running;

\* : the parameter cannot be modified for it is actually measured and recorded.

3. "Factory Default" means the numeric value after the function code parameter is refreshed when recovering the default parameter, but the actually measured value or recorded value will not be refreshed.

4. The controller provides password protection of function code to protect

the parameters effectively (details in Chapter 4.2.3).

**5.2 Function parameter table**

**5.2.1 Groups of function parameters**

Press PRG buttons and then UP/DOWN button, all of the displays are first level menu, which are group of function. Details as follows:

- F0——Basic parameter
- F1——motor parameter
- F2——vector control parameter
- F3——running control parameter
- F4——floor parameter
- F5——terminal input parameter
- F6——elevator basic parameter
- F7——terminal output parameter
- F8——buildup function parameter
- F9——time parameters
- FA——keyboard setting parameter
- FB——door function parameter
- FF——factory parameter
- FP——user parameter

**5.2.2 Function parameter table**

| Code                      | Name                           | Setting range                                  | Min. unit | Factory default value | Operation |
|---------------------------|--------------------------------|--|-----------|-----------------------|-----------|
| <b>F0 Basic parameter</b> |                                |  |           |                       |           |
| F0-00                     | Control mode                   | 0:open-loop vector<br>1:close-loop vector      | 1         | 1                     | ★         |
| F0-01                     | Command source selection       | 0 :operating panel control<br>1 :space control | 1         | 1                     | ★         |
| F0-02                     | Running speed of panel control | 0.050~F0-04                                    | 0.001m/s  | 00.050m/s             | ☆         |
| F0-03                     | Max. speed of elevator         | 0.200~F0-04                                    | 0.001m/s  | 0.480m/s              | ★         |

| Code                      | Name   | Setting range   | Min. unit     | Factory default value             | Operation |
|---------------------------|--|---|---------------|-----------------------------------|-----------|
| F0-04                     | Rated speed of elevator  | 0.200~1.000m/s  | 0.001m/s      | 0.500m/s                          | ★         |
| F0-05                     | Max. frequency   | 10.00Hz~99.00Hz                                       | 0.01Hz        | 50.00Hz                           | ★         |
| F0-06                     | Carrier frequency  | 0.5~16.0kHz   | 0.01kHz       | 6.0kHz                            | ☆         |
| <b>F1 Motor parameter</b> |  |   |               |                                   |           |
| F1-00                     | Encoder type selection   | 0:SIN/COS increment<br>1:UVW increment<br>2:push-pull | 1             | 2(asynchronous)<br>1(synchronous) | ★         |
| F1-01                     | Rated power  | 2.2~75.0kW  | 0.1kW         | model dependent                   | ★         |
| F1-02                     | Rated voltage  | 0~440V  | 1V            | 380V                              | ★         |
| F1-03                     | Rated current  | 0.00~655.00A  | 0.01A         | Model dependent                   | ★         |
| F1-04                     | Rated frequency  | 0.00~99.00Hz  | 0.01Hz        | 50.00Hz                           | ★         |
| F1-05                     | Rated rotate speed   | 0~3000rpm   | 1 rpm         | 1460rpm                           | ★         |
| F1-06                     | Stator resistance (asynchronous)<br>Initial rotation speed (synchronous) | 0.000~30.000Ω<br>0.0~359.9                            | 0.001Ω<br>0.1 | Model dependent                   | ☆         |
| F1-07                     | Rotor resistance   | 0.000~30.000Ω   | 0.001Ω        | Model dependent                   | ☆         |

| Code                                | Name                              | Setting range   | Min. unit | Factory default value | Operation |
|-------------------------------------|-----------------------------------|---|-----------|-----------------------|-----------|
| F1-08                               | Leakage inductance (asynchronous) | 0.01~300.00mH   | 0.01mH    | Model dependent       | ☆         |
|                                     | Wiring mode (synchronous)         | 0~15  | 1         |                       |           |
| F1-09                               | Mutual inductance(asynchronous)   | 0.1~3000.0mH  | 0.1mH     | Model dependent       | ☆         |
|                                     | Reserved(synchronous)             |   |           |                       |           |
| F1-10                               | No-load current                   | 0.01~300.00A  | 0.01A     | Model dependent       | ☆         |
| F1-11                               | Tuning selection                  | 0 :no operation<br>1:static tuning (asynchronous)<br>Initial angle tuning (synchronous)<br>2.no initial angle tuning(synchronous) | 1         | 0                     | ★         |
| F1-12                               | Pulse number per round of coder   | 0~10000   | 1         | 1024                  | ★         |
| F1-13                               | Fault detection time of encoder   | 0~10.0s<br>(if <1s, invalid)  | 0.1       | 2.1                   | ★         |
| <b>F2 Vector control parameters</b> |                                   |   |           |                       |           |
| F2-00                               | Proportional gain1 of speed loop  | 0~100   | 1         | 40                    | ☆         |

| Code                                | Name                               | Setting range   | Min. unit | Factory default value | Operation |
|-------------------------------------|------------------------------------|---|-----------|-----------------------|-----------|
| F2-01                               | Integration time 1 of speed loop   | 0.01~10.00s   | 0.01s     | 0.60s                 | ☆         |
| F2-02                               | Switching frequency 1              | 0.00~F2-05  | 0.01Hz    | 2.00Hz                | ☆         |
| F2-03                               | Proportional gain 2 of speed loop  | 0~100   | 1         | 35                    | ☆         |
| F2-04                               | Integration time 2 of speed loop   | 0.01~10.00s   | 0.01s     | 0.80s                 | ☆         |
| F2-05                               | Switching frequency 2              | F2-02~F0-05   | 0.01Hz    | 5.00Hz                | ☆         |
| F2-06                               | Proportional gain1 of current loop | 10~500%   | 1%        | 60%                   | ☆         |
| F2-07                               | Integration time 1 of current loop | 10~500%   | 0.1%      | 30%                   | ☆         |
| F2-08                               | Upper limit of torque filter       | 0.0~200.0%  | 0.1%      | 150.0%                | ☆         |
| F2-09                               | Reserved                           |   |           |                       | ☆         |
| F2-10                               | Running direction of elevator      | 0:The same direction<br>1:reversed direction:<br>2 The same direction<br>3.reversed | 1         | 0                     | ☆         |
| <b>F3 Running control parameter</b> |                                    |   |           |                       |           |
| F3-00                               | Startup speed                      | 0.000~0.030m/s  | 0.001m/s  | 0.000m/s              | ★         |
| F3-01                               | Holding time of startup time       | 0.000~0.500s  | 0.001s    | 0.000s                | ★         |

| Code  | Name                                | Setting range               | Min. unit             | Factory default value | Operation |
|-------|-------------------------------------|-----------------------------|-----------------------|-----------------------|-----------|
| F3-02 | Acceleration                        | 0.200~0.800m/s <sup>2</sup> | 0.001m/s <sup>2</sup> | 0.300m/s <sup>2</sup> | ★         |
| F3-03 | Inflexion acceleration time 1       | 0.300~4.000s                | 0.001s                | 2.500s                | ★         |
| F3-04 | Inflexion acceleration time 2       | 0.300~4.000s                | 0.001s                | 2.500s                | ★         |
| F3-05 | Deceleration                        | 0.200~0.800m/s <sup>2</sup> | 0.001m/s <sup>2</sup> | 0.300m/s <sup>2</sup> | ★         |
| F3-06 | Inflexion deceleration time 1       | 0.300~4.000s                | 0.001s                | 2.500s                | ★         |
| F3-07 | Inflexion deceleration time 2       | 0.300~4.000s                | 0.001s                | 2.500s                | ★         |
| F3-08 | Special deceleration                | 0.500~2.000m/s <sup>2</sup> | 0.001m/s <sup>2</sup> | 0.500m/s <sup>2</sup> | ★         |
| F3-09 | Stop distance allowance             | 0~90.0mm                    | 0.1mm                 | 0.0mm                 | ★         |
| F3-10 | Re-leveling speed                   | 0.000~0.800m/s              | 0.001m/s              | 0.040m/s              | ★         |
| F3-11 | Speed of slow running               | 0.100~0.500m/s <sup>2</sup> | 0.001m/s              | 0.250m/s              | ★         |
| F3-12 | Switch position of up force reducer | 0.000m~300.00m              | 0.01m                 | 0.00m                 | ★         |
| F3-13 | Switch position of up force reducer | 0.000m~300.00m              | 0.01m                 | 0.00m                 | ★         |
| F3-14 | Output time of starting zero speed  | 0.000~1.000s                | 0.001s                | 0.200s                | ★         |
| F3-15 | Delayed-time of                     | 0.000~1.000s                | 0.001s                | 0.200s                | ★         |

| Code                       | Name                         | Setting range                | Min. unit | Factory default value | Operation |
|----------------------------|------------------------------|------------------------------|-----------|-----------------------|-----------|
|                            | curve running                |                              |           |                       |           |
| F3-16                      | Delayed-time of stop running | 0.000~1.000s                 | 0.001s    | 0.300s                | ★         |
| <b>F4 Floor parameters</b> |                              |                              |           |                       |           |
| F4-00                      | Leveling adjusting           | 0~60mm                       | 1         | 30mm                  | ★         |
| F4-01                      | Current floor                | Lowest(F6-01)~highest(F6-00) | 1         | 1                     | ★         |
| F4-02                      | High bit of current floor    | 0~65535                      | 1         | 1                     | *         |
| F4-03                      | Low bit of current floor     | 0~65535                      | 1         | 34464                 | *         |
| F4-04                      | Length of flashboard1        | 0~65535                      | 1         | 0                     | ★         |
| F4-05                      | Length of flashboard2        | 0~65535                      | 1         | 0                     | ★         |
| F4-06                      | High bit of Floor 1          | 0~65535                      | 1         | 0                     | ★         |
| F4-07                      | Low bit of Floor 1           | 0~65535                      | 1         | 0                     | ★         |

| Code  | Name                | Setting range | Min. unit | Factory default value | Operation |
|-------|---------------------|---------------|-----------|-----------------------|-----------|
| F4-08 | High bit of Floor 2 | 0~65535       | 1         | 0                     | ★         |
| F4-09 | Low bit of Floor 2  | 0~65535       | 1         | 0                     | ★         |
| F4-10 | High bit of Floor 3 | 0~65535       | 1         | 0                     | ★         |
| F4-11 | Low bit of Floor 3  | 0~65535       | 1         | 0                     | ★         |
| F4-12 | High bit of Floor 4 | 0~65535       | 1         | 0                     | ★         |
| F4-13 | Low bit of Floor 4  | 0~65535       | 1         | 0                     | ★         |
| F4-14 | High bit of Floor 5 | 0~65535       | 1         | 0                     | ★         |
| F4-15 | Low bit of Floor 5  | 0~65535       | 1         | 0                     | ★         |
| F4-16 | High bit of Floor 6 | 0~65535       | 1         | 0                     | ★         |

| Code                                   | Name                | Setting range | Min. unit | Factory default value | Operation |
|--|---------------------|---------------|-----------|-----------------------|-----------|
| F4-17                                  | Low bit of Floor 6  | 0~65535       | 1         | 0                     | ★         |
| F4-18                                  | High bit of Floor 7 | 0~65535       | 1         | 0                     | ★         |
| F4-19                                  | Low bit of Floor 7  | 0~65535       | 1         | 0                     | ★         |
| F4-20                                  | High bit of Floor 8 | 0~65535       | 1         | 0                     | ★         |
| F4-21                                  | Low bit of Floor 8  | 0~65535       | 1         | 0                     | ★         |
| F4-22                                  | High bit of Floor 9 | 0~65535       | 1         | 0                     | ☆         |
| F4-23                                  | Low bit of Floor 9  | 0~65535       | 1         | 0                     | ☆         |
| F4-24                                  | Low bit of 10 floor | 0~65535       | 1         | 0                     | ★         |
| F4-25                                  | Low bit of 10 floor | 0~65535       | 1         | 0                     | ★         |
| F4-26                                  | Reserved            | 0~65535       | 1         | 0                     | *         |
| <b>F5 Terminal Function parameters</b> |                     |               |           |                       |           |

| Code  | Name                       | Setting range   | Min. unit | Factory default value | Operation |
|-------|----------------------------|---|-----------|-----------------------|-----------|
| F5-00 | Attendant automatic switch | 3~200   | 1         | 3                     | ★         |
| F5-01 | Function selection of X1   | 1~99(N.O.),<br>101~199(N.C.)  | 1         | 03                    | ★         |
| F5-02 | Function selection of X2   | 00: unused<br>01:leveling 1 signal  | 1         | 104                   | ★         |
| F5-03 | Function selection of X3   | 02: leveling 2 signal<br>03:area signal   | 1         | 105                   | ★         |
| F5-04 | Function selection of X4   | 04:running output feedback signal   | 1         | 109                   | ★         |
| F5-05 | Function selection of X5   | 05:brake output feedback 1 signal   | 1         | 10                    | ★         |
| F5-06 | Function selection of X6   | 06:brake output feedback 2 signal   | 1         | 11                    | ★         |
| F5-07 | Function selection of X7   | 07:self-locking feedback signal   | 1         | 12                    | ★         |
| F5-08 | Function selection of X8   | 08:door lock jump-out output feedback signal  | 1         | 14                    | ★         |
| F5-09 | Function selection of X9   | 09:examine signal<br>10:examine up signal<br>11:examine down signal<br>12:once fire information<br>13:reserved<br>14:lock step signal | 1         | 115                   | ★         |

| Code  | Name                       | Setting range | Min. unit | Factory default value | Operation |
|-------|----------------------------|---------------|-----------|-----------------------|-----------|
| F5-10 | Function selection of X10  |               | 1         | 116                   | ★         |
| F5-11 | Function selection of X11  |               | 1         | 117                   | ★         |
| F5-12 | Function selection of X12  |               | 1         | 118                   | ★         |
| F5-13 | Function selection of X 13 |               | 1         | 119                   | ★         |
| F5-14 | Function selection of X 14 |               | 1         | 22                    | ★         |
| F5-15 | Function selection of X 15 |               | 1         | 126                   | ★         |
| F5-16 | Function selection of X16  |               | 1         | 28                    | ★         |
| F5-17 | Function selection of X17  |               | 0.1%      | 30                    | ☆         |
| F5-18 | Function selection of X18  |               | 0.01      | 124                   | ☆         |

| Code  | Name   | Setting range  | Min. unit | Factory default value | Operation |
|-------|--|--|-----------|-----------------------|-----------|
| F5-19 | Function selection of X19                    |  | 1         | 00                    | ★         |
| F5-20 | Function selection of X20                    |  | 1         | 00                    | ★         |
| F5-21 | Function selection of X21                    |  | 1         | 00                    | ★         |
| F5-22 | Function selection of X22                    |  | 1         | 00                    | ★         |
| F5-23 | Function selection of X23                    |  | 1         | 00                    | ★<br>★    |
| F5-24 | Function selection of X24                    |  | 1         | 00                    | ★         |
| F5-25 | Strong power input function selection of X25 |  | 1~99      | 1                     | 01        |
| F5-26 | Strong power input function selection of X26 | 00:unused<br>01:security circuit signal<br>02:door circuit1 signal | 1         | 02                    | ★         |
| F5-27 | Strong power input function selection of X27 | 03:door circuit2 signal<br>04~99:reserved                          | 1         | 03                    | ★         |

| Code                                | Name  | Setting range                               | Min. unit | Factory default value | Operation |
|-------------------------------------|---|---|-----------|-----------------------|-----------|
| F5-28                               | State display 1 of input/output terminal      | -   | -         | -                     | *         |
| F5-29                               | State display of input/output terminal        | -   | -         | -                     | *         |
| F5-30                               | State display1 of floor input/output terminal | -   | -         | -                     | *         |
| F5-31                               | State display2 of floor input/output terminal | -   | -         | -                     | *         |
| <b>F6 Elevator basic parameters</b> |   |   |           |                       |           |
| F6-00                               | Highest floor                                 | Lowest floor (F6-01)~10                     | 1         | 5                     | ★         |
| F6-01                               | Lowest floor                                  | 1~highest floor(F6-00)                      | 1         | 1                     | ★         |
| F6-02                               | Parking main landing                          | Lowest floor (F6-01) ~ Highest floor(F6-00) | 1         | 1                     | ★         |
| F6-03                               | Fire main landing                             | Lowest floor (F6-01) ~ Highest floor(F6-00) | 1         | 1                     | ★         |
| F6-04                               | Lift lock main landing                        | Lowest floor (F6-01) ~ Highest floor(F6-00) | 1         | 1                     | ★         |
| F6-05                               | Service floor                                 | 0~1023                                      | 1         | 1023                  | ★         |
| F6-06                               | Reserved                                      |   |           |                       | ☆         |

| Code  | Name                        | Setting range  | Min. unit | Factory default value | Operation |
|-------|-----------------------------|--|-----------|-----------------------|-----------|
| F6-07 | Group control number        | 1~2  | 1         | 1                     | ★         |
| F6-08 | Elevator number             | 1~2  | 1         | 1                     | ★         |
| F6-09 | Random examine times        | 0~6000   | 1         | 0                     | ☆         |
| F6-10 | Enabled detection selection | Bit0:external-call enable<br>Bit1:open door                          | 1         | 0                     | ☆         |
| F6-11 | L1 function selection       | 00:unused<br>201~203(door1 on-off door)                              | 1         | 201                   | ★         |
| F6-12 | L2 function selection       | 204~209(reserved)<br>210~219(door1 internal call)                    | 1         | 202                   | ★         |
| F6-13 | L3 function selection       | 220~229(door1 up external call)<br>230~239(door1 down external call) | 1         | 203                   | ★         |
| F6-14 | L4 function selection       | 240~299(reserved)  | 1         | 00                    | ★         |
| F6-15 | L5 function selection       | 301~399(door 2)<br>201:open button of door 1                         | 1         | 211                   | ★         |
| F6-16 | L6 function selection       | 202:close button of door 1   | 1         | 212                   | ★         |

| Code  | Name                   | Setting range | Min. unit | Factory default value | Operation |
|-------|------------------------|---------------|-----------|-----------------------|-----------|
| F6-17 | L7 function selection  |               | 1         | 213                   | ★         |
| F6-18 | L8 function selection  |               | 1         | 214                   | ★         |
| F6-19 | L9 function selection  |               | 1         | 215                   | ★         |
| F6-20 | L10 function selection |               | 1         | 00                    | ★         |
| F6-21 | L11 function selection |               | 1         | 00                    | ★         |
| F6-22 | L12 function selection |               | 1         | 00                    | ★         |
| F6-23 | L13 function selection |               | 1         | 221                   | ★         |
| F6-24 | L14 function selection |               | 1         | 222                   | ★         |

| Code  | Name                   | Setting range | Min. unit | Factory default value | Operation |
|-------|------------------------|---------------|-----------|-----------------------|-----------|
| F6-25 | L15 function selection |               | 1         | 223                   | ★         |
| F6-26 | L16 function selection |               | 1         | 224                   | ★         |
| F6-27 | L17 function selection |               | 1         | 232                   | ★         |
| F6-28 | L18 function selection |               | 1         | 233                   | ★         |
| F6-29 | L19 function selection |               | 1         | 234                   | ★         |
| F6-30 | L20 function selection |               | 1         | 235                   | ★         |
| F6-31 | L21 function selection |               | 1         | 00                    | ★         |
| F6-32 | L22 function selection |               | 1         | 00                    | ★         |

| Code  | Name                   | Setting range   | Min. unit | Factory default value | Operation |
|---|------------------------|---|-----------|-----------------------|-----------|
| F6-33   | L23 function selection |   | 1         | 00                    | ★         |
| F6-34   | L24 function selection |   | 1         | 00                    | ★         |
| F6-35   | L25function selection  |   | 1         | 00                    | ★         |
| F6-36   | L26 function selection |   | 1         | 00                    | ★         |
| <b>F7 Terminal output function parameters</b> |                        |   |           |                       |           |
| F7-00   | Y0 function selection  | 00~99<br>00:unused<br>01~31: F7-01~F7-23<br>32:electricity off, emergency running valid<br>33~99:reserved | 1         | 00                    | ★         |
| F7-01   | Y1 function selection  | 01~05<br>00:unused<br>01:running  | 1         | 01                    | ★         |

| Code  | Name                   | Setting range  | Min. unit | Factory default value | Operation |
|-------|------------------------|--|-----------|-----------------------|-----------|
| F7-02 | Y2 function selection  | contactor output<br>02:brake contactor output  | 1         | 02                    | ★         |
| F7-03 | Y3 function selection  | 03:brake forced output<br>04:illumination and fan output<br>05:synchronous motor self-locking output | 1         | 04                    | ★         |
| F7-04 | Y4 function selection  | 06~31<br>00:unused   | 1         | 00                    | ★         |
| F7-05 | Y5 function selection  | 06:door1 open output   | 1         | 00                    | ★         |
| F7-06 | Y6 function selection  | 07:door1 close output<br>08:door2 open output  | 1         | 06                    | ★         |
| F7-07 | Y7 function selection  | 09:door2 close output  | 1         | 07                    | ★         |
| F7-08 | Y8 function selection  | 10:low 7 segment code a display output   | 1         | 08                    | ★         |
| F7-09 | Y9 function selection  | 11:low 7 segment b display output  | 1         | 09                    | ★         |
| F7-10 | Y10 function selection | 12: low 7  | 1         | 10                    | ★         |

| Code  | Name                   | Setting range | Min. unit | Factory default value | Operation |
|-------|------------------------|---------------|-----------|-----------------------|-----------|
| F7-11 | Y11 function selection |               | 1         | 11                    | ★         |
| F7-12 | Y12 function selection |               | 1         | 12                    | ★         |
| F7-13 | Y13 function selection |               | 1         | 13                    | ★         |
| F7-14 | Y14 function selection |               | 1         | 00                    | ★         |
| F7-15 | Y15function selection  |               | 1         | 00                    | ★         |
| F7-16 | Y16 function selection |               | 1         | 25                    | ★         |
| F7-17 | Y17 function selection |               | 1         | 17                    | ★         |
| F7-18 | Y18 function selection |               | 1         | 18                    | ★         |
| F7-19 | Y19 function selection |               | 1         | 19                    | ★         |
| F7-20 | Y20 function selection |               | 1         | 20                    | ★         |
| F7-21 | Y21 function selection |               | 1         | 21                    | ★         |

| Code                                  | Name  | Setting range  | Min. unit | Factory default value | Operation |
|---------------------------------------|---|--|-----------|-----------------------|-----------|
| F7-22                                 | Y22 function selection                                  |  | 1         | 22                    | ★         |
| F7-23                                 | Y23 function selection                                  |  | 1         | 00                    | ★         |
| F7-24                                 | Reserved  |  |           |                       |           |
| <b>F8 Enhance function parameters</b> |   |  |           |                       |           |
| F8-00                                 | weighing self-tuning setting                            | 0~100%   | 1%        | 0%                    | ★         |
| F8-01                                 | Pre-torque selection                                    | 0:pre-torque invalid<br>1:pre-torque valid<br>2:automatic calculate pre-torque | 1         | 0                     | ★         |
| F8-02                                 | Pre-torque excursion,<br>Zero servo current coefficient | 0.0%~100.0%<br>0.20~50.0   | 0.1%      | 50.0%                 | ★         |
| F8-03                                 | Drive side bias,<br>Zero servo speed loop KP            | 0.00~2.00  | 0.01      | 0.60                  | ★         |
| F8-04                                 | Braking side bias,<br>Zero servo speed loop TI          | 0.00~2.00  | 0.01      | 0.60                  | ★         |
| F8-05                                 | Reserved  |  |           |                       | ☆         |
| F8-06                                 | Car no-load setting                                     | 0~1023   | 1         | 0                     | ★         |
| F8-07                                 | Car full-load   | 0~1023   | 1         | 100                   | ★         |

| Code                      | Name                               | Setting range  | Min. unit | Factory default value | Operation |
|---------------------------|------------------------------------|--|-----------|-----------------------|-----------|
|                           | setting                            |  |           |                       |           |
| F8-08                     | Load weighing input selection      | 0:invalid<br>1:reserved<br>2:analogue sampling                             | 1         | 0                     | ★         |
| F8-09                     | Power off emergency save speed     | 0.000~0.100m/s   | 0.001m/s  | 0.05m/s               | ★         |
| F8-10                     | Power off emergency save selection | 0: no running of motor<br>1:UPS supply running<br>2:48V accumulator supply | 1         | 0                     | ★         |
| F8-11                     | Delayed-time of stop torque output | 0.200~1.500s   | 0.001s    | 0.200s                | ★         |
| <b>F9 Time parameters</b> |                                    |  |           |                       |           |
| F9-00                     | Time of free back to main landing  | 0 :invalid; 1~240  | 1min      | 10min                 | ☆         |
| F9-01                     | Fan(illumination ) off time        | 0:invalid, which means fan is running all the time; 1~240min               | 1min      | 12min                 | ☆         |
| F9-02                     | Max. interval of floor running     | 0~45s<br>Invalid if less than 3s   | 1         | 45                    | ★         |
| F9-03                     | Accumulative runtime               | 0~65535h   | 1         | 0                     | *         |
| F9-04                     | Reserved                           |  |           |                       | ☆         |
| F9-05                     | High bit o running times           | 0~9999<br>Note:1= 10000 actual   | 1         | 0                     | *         |

| Code                                  | Name                     | Setting range                           | Min. unit | Factory default value | Operation |
|---------------------------------------|--------------------------|---|-----------|-----------------------|-----------|
|                                       |                          | running times                           |           |                       |           |
| F9-06                                 | Low bit of running times | 0~9999                                  | 1         | 0                     | *         |
| <b>FA Keyboard setting parameters</b> |                          |   |           |                       |           |
| FA-00                                 | Baud rate setting        | 0~5:9600BPS<br>6:19200BPS<br>7:38400BPS | 1         | 5                     | ★         |

| Code  | Name            | Setting range  | Min. unit | Factory default value | Operation |
|-------|-----------------|--|-----------|-----------------------|-----------|
| FA-01 | Running display | 1-65535<br>Bit0:running speed<br>Bit1:rated speed<br>Bit2:bus voltage<br>Bit3:output voltage<br>Bit4:output current<br>Bit5:output frequency<br>Bit6:current floor<br>Bit7:current position<br>Bit8:car load<br>Bit9:system state<br>Bit10:pre-torque current (%)<br>Bit11: state of input terminal 1<br>Bit12: state of input terminal 2<br>Bit13: state of input terminal 3<br>Bit14: state of output terminal 1<br>Bit15:state of output terminal 2 | 1         | 65535                 | ☆         |
| FA-02 | Stop display    | 1-65535<br>Bit0:rated speed  | 1         | 65535                 | ☆         |

| Code                              | Name                                 | Setting range   | Min. unit | Factory default value | Operation |
|-----------------------------------|--------------------------------------|---|-----------|-----------------------|-----------|
|                                   |                                      | Bit1:bus current<br>Bit2:current floor<br>Bit3:current position<br>Bit4:car load<br>Bit5:rated step decelerate distance<br>Bit6:system state<br>Bit7: state of input terminal1<br>Bit8: state of input terminal2<br>Bit9: state of input terminal3<br>Bit10: state of output terminal 1<br>Bit11:state of output terminal 2 |           |                       |           |
| FA-03                             | Current angle of pulse wheel encoder | 0.0~360.0   | 0.1       | 0.0                   | *         |
| FA-04                             | Software edition (ZK)2               | 0~65535   | 1         | 0                     | *         |
| FA-05                             | Software edition (DSP) 3             | 0~65535   | 1         | 0                     | *         |
| FA-06                             | Radiator temperature                 | 0~100℃  | 1℃        | 0                     | *         |
| <b>FB Door function parameter</b> |                                      |   |           |                       |           |

| Code  | Name   | Setting range  | Min. unit | Factory default value | Operation |
|-------|--|--|-----------|-----------------------|-----------|
| FB-00 | Door machine number                                  | 1~2  | 1         | 1                     | ★         |
| FB-01 | Opposite door option                                 | 0~3  | 1         | 0                     | ★         |
| FB-02 | Door machine 1 service floor                         | 0~1023(set1~10, 1: normal open door; 0:forbid to open the door)  | 1         | 1023                  | ☆         |
| FB-03 | Manually operating open in right position delay time | 1~60s  | 1         | 5                     | ☆         |
| FB-04 | Door machine 2 service floor                         | 0~1023(set1~10, 1: normal open door; 0:forbid to open the door)<br>Only valid when door machine number is 2. | 1         | 1023                  | ☆         |
| FB-05 | Back floor parking delay                             | 0.00~2.00s   | 0.00      | 0.00                  | ☆         |
| FB-06 | Open door time protection                            | 5~99s<br>After the protection, the elevator will berth at the nearest floor and report open door fault.      | 1s        | 10s                   | ☆         |
| FB-07 | Program control option                               | Bit 0:reserved<br>Bit1:reserved<br>Bit2: reserved  | 1         | 0                     | ☆         |

| Code  | Name                       | Setting range  | Min. unit | Factory default value | Operation |
|-------|----------------------------|--|-----------|-----------------------|-----------|
|       |                            | Bit3: reserved<br>Bit4: slash valid when stop for 300MS current<br>Bit5: reserved<br>Bit6 reserved<br>Bit7 reserved<br>Bit8 no output when close the door in place, only judge door-locked loop 1.<br>Bit 9 reserved<br>Bit10 delay 1 second and no output when close the door in place(no judgment for door-locked loop)<br>Bit11 delay for 1s and no output when open door in place<br>Bit12 reserved<br>Bit13 high/low voltage signal test for 1.5s |           |                       |           |
| FB-08 | Close door time protection | 5~99s<br>After the protection, the elevator will close the door again and report close door fault.   | 1s        | 15s                   | ☆         |

| Code                                    | Name                                    | Setting range  | Min. unit | Factory default value | Operation |
|---|---|--|-----------|-----------------------|-----------|
| FB-09                                   | Open/close times                        | 0~20<br>0:invalid<br>After trial open/close times, the elevator will stop running, and report the fault. | 1         | 0                     | ☆         |
| FB-10                                   | State of parking main landing door      | 0:normal open door<br>1:wait to open door<br>2 door open in every floor                                  | 1         | 0                     | ☆         |
| FB-11                                   | Door holding time 1<br>(external call)  | 1-120s   | 1s        | 5s                    | ☆         |
| FB-12                                   | Door holding time 2<br>(internal call)  | 1~120s   | 1s        | 3s                    | ☆         |
| FB-13                                   | Door holding time 3<br>(delayed time)   | 10~1000s   | 1s        | 30s                   | ☆         |
| <b>FC Protection function parameter</b> |   |  |           |                       |           |
| FC-00                                   | Power on grounding short test selection | 0:forbid<br>1:permit   | 1         | 1                     | ★         |
| FC-01                                   | Over-load protection selection          | Bit0:over-load protection selection<br>0: Enabled  | 1         | 1                     | ☆         |

| Code  | Name                             | Setting range   | Min. unit | Factory default value | Operation |
|-------|----------------------------------|---|-----------|-----------------------|-----------|
|       |                                  | 1: Disabled<br>Bit1:output phase failure selection<br>0:phase failure protection<br>1:phase failure no-protection<br>Bit2:over-modulate function selection<br>0:valid<br>1:invalid  |           |                       |           |
| FC-02 | Over-load protection coefficient | 0.50~10.00  | 0.01      | 1.00                  | ☆         |
| FC-03 | Over-load precaution coefficient | 50~100%   | 1%        | 80%                   | ☆         |
| FC-04 | The first error information      | 0~3199<br>Note: The first two figures mean the floor's number, and the last two mean the error code. e.g. error 30 occurs in Floor1(the elevator's position is abnormal), the error information displays 0130.<br>0: No error | 1         | 0                     | *         |

| Code | Name | Setting range                 | Min. unit | Factory default value | Operation |
|------|------|-------------------------------|-----------|-----------------------|-----------|
|      |      | 1: Inverse unit protection    |           |                       |           |
|      |      | 2:Over current accelerated    |           |                       |           |
|      |      | 3:Over current decelerated    |           |                       |           |
|      |      | 4: Over current constant      |           |                       |           |
|      |      | 5:Over voltage accelerated    |           |                       |           |
|      |      | 6:Over voltage decelerated    |           |                       |           |
|      |      | 7: Over voltage constant      |           |                       |           |
|      |      | 8: Controller power fault     |           |                       |           |
|      |      | 9: Under voltage fault        |           |                       |           |
|      |      | 10: System overload           |           |                       |           |
|      |      | 11: Motor overload            |           |                       |           |
|      |      | 12: Input side phase failure  |           |                       |           |
|      |      | 13: Output side phase failure |           |                       |           |
|      |      | 14: Module overheated         |           |                       |           |
|      |      | 15: Reserved                  |           |                       |           |
|      |      | 16: Reserved                  |           |                       |           |

| Code | Name | Setting range   | Min. unit | Factory default value | Operation |
|------|------|---|-----------|-----------------------|-----------|
|      |      | 17: Contactor fault<br>18: Current detection fault<br>19: Motor tuning fault<br>20: rotary coder fault<br>21: Synchronous motor encoder wiring error<br>22: Leveling inductor signal is abnormal<br>23: Short circuit fault to ground<br>24: Door lock2 abnormal<br>25: Data storage error<br>26~28: Reserved<br>29: Synchronous self-locking contactor feedback is deviant<br>30: Lift position is deviant<br>31: Reserved<br>32: Reserved<br>33: Lift over speed error<br>34: Logic fault<br>35: Well self-tuning |           |                       |           |

| Code | Name | Setting range   | Min. unit | Factory default value | Operation |
|------|------|---|-----------|-----------------------|-----------|
|      |      | date is deviant<br>36:Contact feedback is deviant<br>37:Brake feedback is deviant<br>38:Controller encode signal is deviant<br>39: Reserved<br>40: Lift running condition is not satisfied<br>41: Safety circuit cut<br>42:Door lock cut when running<br>43:Upper limit signal cut when running<br>44:Lower limit signal cut when running<br>45: Up/Down force reducer switch cut<br>46: Re-leveling is deviant<br>47:Lock contactor is deviant<br>48: Door open fault<br>49: Door close fault<br>50:Reserved |           |                       |           |

| Code                                | Name                         | Setting range   | Min. unit | Factory default value | Operation |
|-------------------------------------|------------------------------|---|-----------|-----------------------|-----------|
|                                     |                              | 51: Reserved<br>52: Reserved<br>53: Lock jump out fault |           |                       |           |
| FC-05                               | The second error information | 0~3199  | 1         | 0                     | *         |
| FC-06                               | The third error information  | 0~3199  | 1         | 0                     | *         |
| FC-07                               | The fourth error information | 0~3199  | 1         | 0                     | *         |
| FC-08                               | The fifth error information  | 0~3199  | 1         | 0                     | *         |
| FC-09                               | The latest error information | 0~3199  | 1         | 0                     | *         |
| FC-10                               | The latest error speed       | 0.000~3.000m/s  | 0.001m/s  | 0.000m/s              | *         |
| FC-11                               | The latest error current     | 0.0~999.0A  | 0.1A      | 0.0A                  | *         |
| FC-12                               | The latest error bus voltage | 0~999V  | 0~999V    | 1V                    | *         |
| <b>FD Reserved parameter</b>        |                              |   |           |                       |           |
| FD-00                               | Reserved                     |   | 1         | 0                     | ☆         |
| <b>FE Elevator function setting</b> |                              |   |           |                       |           |
| FE-00                               | Selective mode               | 0:Full selective<br>1:Down selective<br>2:Up selective  | 1         | 0                     | ☆         |

| Code  | Name                           | Setting range  | Min. unit | Factory default value | Operation |
|-------|--------------------------------|--|-----------|-----------------------|-----------|
| FE-01 | Respective display of floor 1  | 0000~1999<br><br>Note: the first two numbers represent tens digit code of the floor; the last two represent first rank code. The first rank codes are as follows:<br>00:display"0"<br>01:display"1"<br>02:display"2"<br>03:display"3"<br>04:display"4"<br>05:display"5"<br>06:display"6"<br>07:display"7"<br>08:display"8"<br>09:display"9"<br>10~17:no display<br>18:display "_", or bigger<br>19: no display | 1         | 1901                  | ☆         |
| FE-02 | Respective display of floor 2  |  | 1         | 1902                  | ☆         |
| FE-03 | Respective display of floor 3  |  | 1         | 1903                  | ☆         |
| FE-04 | Respective display of floor 4  |  | 1         | 1904                  | ☆         |
| FE-05 | Respective display of floor 5  |  | 1         | 1905                  | ☆         |
| FE-06 | Respective display of floor 6  |  | 1         | 1906                  | ☆         |
| FE-07 | Respective display of floor 7  |  | 1         | 1907                  | ☆         |
| FE-08 | Respective display of floor 8  |  | 1         | 1908                  | ☆         |
| FE-09 | Respective display of floor 9  |  | 1         | 1909                  | ☆         |
| FE-10 | Respective display of floor 10 |  | 1         | 0100                  | ☆         |
| FE-11 | Reserved                       |  |           |                       | ☆         |

| Code  | Name                               | Setting range  | Min. unit | Factory default value | Operation |
|-------|------------------------------------|--|-----------|-----------------------|-----------|
| FE-12 | External call output selection     | 0:7 segment code<br>1:BCD code<br>2:reserved<br>3: binary code   | 1         | 1                     | ★         |
| FE-13 | Factory function setting selection | 0~65535<br><br>Select according to bit;<br>if this bit is 1, the function is valid.<br><br>Bit0:reserved<br><br>Bit1: no attendant responding to hall call<br><br>Bit2:re-leveling<br>Bit3:reserved<br><br>Bit4:reserved<br><br>Bit5: reserved<br><br>Bit6:inspection open the door by non-door area button<br><br>Bit7:inspection turn normal open the door once<br><br>Bi8:manually operate the opposite door in inspection/attendant state<br><br>Bit9:self running<br><br>Bit10: examine | 1         | 33795                 | ★         |

| Code  | Name                               | Setting range  | Min. unit | Factory default value | Operation |
|-------|------------------------------------|--|-----------|-----------------------|-----------|
|       |                                    | automatic close door<br>Bit11:door open for inside call<br>Bit12:reserved<br>Bit13:emergency automatic slide function<br>Bit14:emergency self-save overtime protection<br>Bit15:door lock short wiring examine function  |           |                       |           |
| FE-14 | Factory function setting selection | 0~65535<br>Select according to bit; if this bit is 1, the function is valid.<br>Bit0:reserved<br>Bit1:open door to the right position, keep open<br>Bit2:no close door during running<br>Bit3: manually operate door function selection<br>Bit4: reset of contact conglutination automatic | 1         | 2080                  | ★         |

| Code      | Name                                       | Setting range   | Min. unit | Factory default value | Operation |
|-----------|--|---|-----------|-----------------------|-----------|
|           |  | Bit5:forced decelerate switch conglutination test<br><br>Bit6:open the door delay time button continue to open the door<br><br>Bit7:reserved<br><br>Bit8:delay the close of brake when no order after running<br><br>Bit9: immediate stop when opposite leveling<br><br>Bit10:U,V,W jump contactor normally open output<br><br>Bit11:no close door command after light off<br><br>Bit12:lighting and fans normally closed output<br><br>Bit13:fire back to base .no output when lift run normally<br><br>Bit14:keep opening time extension when no call<br><br>Bit15:reserved |           |                       |           |
| <b>FF</b> | <b>Factory default parameter(reserved)</b> |   |           |                       |           |

| Code                     | Name             | Setting range  | Min. unit | Factory default value | Operation |
|--------------------------|------------------|--|-----------|-----------------------|-----------|
| <b>FP User parameter</b> |                  |  |           |                       |           |
| FP-00                    | User password    | 0-65535<br>0:no password   | 1         | 0                     | ☆         |
| FP-01                    | Parameter update | 0:none<br>1:restore to factory default value<br>2:clear memory information | 1         | 0                     | ★         |



## Functional parameter Specification

---

## Chapter 6 Functional parameter Specification

### 6.1 Group F0 Basic Function Group

|              |                     |                       |   |           |   |
|--------------|---------------------|-----------------------|---|-----------|---|
| <b>F0-00</b> | <b>Control mode</b> | Factory default value | 1 | Min. Unit | 1 |
|              | Setting Range       | 0,1                   |   |           |   |

Select the control mode of the system.

0: Open-loop vector. No speed sensor vector control. It is mainly applicable for low speed running in adjusting and fault judging in maintaining of asynchronous motor.

1: Closed-loop vector. Vector control with speed sensor. It's used for distance control in normal running.

NOTE: The synchronous motor can not run with open- loop. Please do motor tuning before lift inspection running.

|              |                                 |                       |   |           |   |
|--------------|---------------------------------|-----------------------|---|-----------|---|
| <b>F0-01</b> | <b>Command source selection</b> | Factory default value | 1 | Min. Unit | 1 |
|              | Setting Range                   | 0, 1                  |   |           |   |

It can set the lift running type with travel mode and speed command.

0: Operating panel command channel. Command control by pressing **RUN**, **STOP**. The running speed is decided by parameter F0-02(Panel controller running speed).

1: Distance control. It is used for NICE1000. It enables direct parking according to the distances from the current floor to the target floor while calculating running speed and curves automatically.

|              |                              |                       |           |           |          |
|--------------|------------------------------|-----------------------|-----------|-----------|----------|
| <b>F0-02</b> | <b>Operating panel speed</b> | Factory default value | 0.050 m/s | Min. Unit | 0.001m/s |
|              | Setting Range                | 0.050~F0-04           |           |           |          |

This function can only be used when function code is F0-01=0(operating panel command channel).

It sets the default of speed when lift is used by operating panel. You can modify this code to change speed of operating panel control

when traveling.

|              |                                |                       |          |           |          |
|--------------|--------------------------------|-----------------------|----------|-----------|----------|
| <b>F0-03</b> | <b>Lift Max. running speed</b> | Factory default value | 0.480m/s | Min. Unit | 0.001m/s |
|              | Setting Range                  | 0.200~F0-04           |          |           |          |

It can set the Max. running speed and it must below rated speed of the lift.

|              |                         |                       |           |           |          |
|--------------|-------------------------|-----------------------|-----------|-----------|----------|
| <b>F0-04</b> | <b>Lift rated speed</b> | Factory default value | 0.500 m/s | Min. Unit | 0.001m/s |
|              | Setting Range           | 0.200~1.000m/s        |           |           |          |

It means rated speed of nameplate of lift. This function parameter is decided by the machine and motor of the lift. The parameter F0-03 means the actual speed within the speed range of F0-04.

For example: One lift rated speed is 0.500m/s, but the actual maximum speed is 0.480 m/s. So F0-03 = 0.480 m/s; F0-04 = 0.500 m/s.

|              |                       |                       |         |           |        |
|--------------|-----------------------|-----------------------|---------|-----------|--------|
| <b>F0-05</b> | <b>Max. frequency</b> | Factory default value | 50.00Hz | Min. Unit | 0.01Hz |
|              | Setting Range         | 10.00~99.00Hz         |         |           |        |

It can set Max. Frequency of system output and the frequency must be higher than rated frequency of the motor.

|              |                          |                       |        |           |        |
|--------------|--------------------------|-----------------------|--------|-----------|--------|
| <b>F0-06</b> | <b>Carrier frequency</b> | Factory default value | 6.0kHz | Min. Unit | 0.1kHz |
|              | Setting Range            | 0.5~16.0kHz           |        |           |        |

The magnitude of carry frequency is closely related to the noise of motor running. The carry frequency is generally set upward 6 KHz to manage to travel without noise. To the best of noise allowing range, reduce the carry frequency

When the carrier frequency is low, the output current higher-harmonic component increases, the consumption and

temperature rise of the motor increase as well.

When the carrier frequency is high, the motor consumption declines and the motor temperature rise reduces, but the consumption, temperature rise and interference of the system increase.

To regulate the carrier frequency will exert influences on the following performances:

|                                 |       |   |       |
|---------------------------------|-------|---|-------|
| Carrier Frequency               | Low   | ~ | High  |
| Motor noise                     | Large | ~ | Small |
| Output Current Wave Form        | Poor  | ~ | Good  |
| Motor Temperature Rise          | High  | ~ | Low   |
| System Temperature Rise         | Low   | ~ | High  |
| Leakage Current                 | Small | ~ | Large |
| External Radiation Interference | Small | ~ | Large |

## 6.2 F1 Group Motor Parameters

| Function code | Name                   | Factory default value                         | Min. Unit | Setting Range                        |
|---------------|------------------------|---|-----------|--------------------------------------|
| F1-00         | Encoder type selection | 2(Asynchronous motor)<br>1(Synchronous motor) | 1         | 0: SIN/COS<br>1: UVW<br>2: Push-pull |
| F1-01         | Rated power            | Depending on the model                        | 0.1kW     | 1.1~75.0kW                           |
| F1-02         | Rated voltage          | 380V  | 1V        | 0~440V                               |
| F1-03         | Rated current          | Depending on the model                        | 0.01A     | 0.00~655.00A                         |
| F1-04         | Rated frequency        | 50.00Hz                                       | 0.01Hz    | 0.00~99.00Hz                         |
| F1-05         | Rated rotation speed   | 1460rpm                                       | 1rpm      | 0~3000rpm                            |

Please set according to the nameplate parameters of the motor.

The accurate motor parameters can ensure the excellent control performance of the vector. The system enables the parameters the automatic identification function. The accurate parameter identification is based on the correct setting of the motor rated parameters.

| Function code | Name  | Factory default value | Min. Unit | Setting Range            |
|---------------|---|-----------------------|-----------|--------------------------|
| F1-06         | Stator resistance<br>(Asynchronous motor)                         | Model dependent       | 0.001Ω    | 0.000~30.000Ω            |
|               | Initialized angle<br>(Synchronous motor)                          | Model dependent       | 0.1°      | 0~359.9°                 |
| F1-07         | Rotor resistance<br>(asynchronous)                                | Model dependent       | 0.001Ω    | 0.000~30.000Ω<br>0~359.9 |
|               | Current coder angle<br>before power off<br>(synchronous)          |                       | 0.00      |                          |
| F1-08         | Leakage inductance<br>(Asynchronous motor)                        | Model dependent       | 0.01mH    | 0.00~300.00mH            |
|               | Wiring connection<br>(Synchronous motor)                          | Model dependent       | 1         | 0~15                     |
| F1-09         | Mutual inductance<br>(asynchronous)<br>Reserved<br>( synchronous) | Model dependent       | 0.1mH     | 0.1~3000.0mH             |
| F1-10         | No-load<br>current(asynchronous)                                  | Model dependent       | 0.01A     | 0.01~300.00A             |
|               | Coder angle check<br>(synchronous)                                | 02                    | 00        | 00~02                    |

To ensure system performance, please set according to the system standard of the motor arrangement. If the motor power is very different from the standard motor power, the performance of system control may decline.

The parameter F1-06 stands for different meanings when applied to different motors. When it's used in asynchronous motor, it means the stator resistance. When it's used in synchronous motor, it means the encoder initialized angle. No matter which motor to be used in, this parameter can be created after NICE1000 tuning. And users can modify this parameter according to actual condition.

If the automatic tuning of the motor is completed normally, the setup values in F1-F6 to F1-F10 will update automatically.

When NICE1000 is used for asynchronous motor: the system can gain these parameters through complete tuning or static tuning. If the motor

cannot be tuned on the spot, the known parameters of the same kind of motors can be a reference for manual input. After modifying the asynchronous motor's rated power F1-01, the parameter values in F1-06 to F1-10 will automatically recover to the default standard motor parameters.

When NICE1000 is used for permanent-magnet synchronous motor: the system can gain parameters F1-06, F1-08 through initial angle tuning. After modifying the rated power F1-01, the parameter values in F1-06 to F1-10 will not automatically recover.

|              |                         |                       |   |           |   |
|--------------|-------------------------|-----------------------|---|-----------|---|
| <b>F1-11</b> | <b>Tuning selection</b> | Factory default value | 0 | Min. Unit | 1 |
|              | Setting Range           | 0, 1 ,2               |   |           |   |

Note: The correct motor rated parameters (F1-01~F1-05) must be set before tuning.

0: No tuning.

1: Static tuning (Asynchronous motor)

Loaded Initial angle tuning (Synchronous motor)

2:Non-load initial angle tuning (synchronous motor)

Note: If using the permanent-magnet synchronous motor, It is forbidden that travel the permanent-magnet synchronous motor before complete the initial angle tuning.

- Automatically tuning step of asynchronous motor is following:
  - 1) First, set F0-01 to 0: the control mode is selected to the operating panel control;
  - 2) Set F1-01,F1-02,F1-03,F1-04,F1-05 according to the nameplate of motor, and set F1- 00,F1-F2 according to the coder nameplate
  - 3) F1-11 selects 1(static tuning).Then press **RUN** of the operating panel and the motor can automatically run. The control automatically counts three parameters as follows: F1-06 (stator resistance), F1-07 (rotor resistance), and F1-08 (leakage inductance). It automatically counts the motor's F1-09 (mutual inductance), F1-10 (no-load excitation current). The motor tuning is

then over.

- Automatically tuning step of permanent-magnet synchronous non-load motor is following:
  - 1) First, set F0-01 as 0: the control mode selects the keyboard control.
  - 2) Set F1-00 by encoder type as 0: SIN/COS or 1: UVW. Then set F1-01, F1-02, F1-03, F1-04, F1-05 according to the nameplate parameters of motor.
  - 3) Completely separate the motor from the load (rope), the parameter F1-11 selects 1: Initial angle tuning (Synchronous motor). Then press RUN of the operation panel and the motor can automatically run. The controller automatically counts the F1-06 encoder initialized angle. The motor tuning is then over. Operate the tuning more than 3 times, then compare F1-06 encoder initialized angle already gained, make sure the error tolerance is within the range of  $\pm 5^\circ$ .
  - 4) After tuning, check the running direction and current directly through the inspection running. If motor isn't running right, please repeat step 1, 2, 3 after transposing direction of encode signal.
- Automatically tuning step of permanent-magnet synchronous loaded motor is following:
  - 1) The car is located in the central of the shaft
  - 2) Meet the requirements of the inspection running
  - 3) Set F1-00 by encoder type as 0: SIN/COS or 1: UVW. Then set F1-01, F1-02, F1-03, F1-04, F1-05 according to the nameplate parameters of motor. Then inspection running, the controller counts the F1-06 coder initial angle automatically. The motor tuning is then over. Operate the tuning more than 3 times, then compare F1-06 encoder initialized angle already gained, make sure the error tolerance is within the range of  $\pm 5^\circ$ .

|              |  |                       |      |           |   |
|--------------|--|-----------------------|------|-----------|---|
| <b>F1-12</b> | <b>Encoder pulse number per rotation</b> | Factory default value | 1024 | Min. Unit | 1 |
|--------------|--|-----------------------|------|-----------|---|

|  |               |         |
|--|---------------|---------|
|  | Setting Range | 0~10000 |
|--|---------------|---------|

It can set the pulse number of each rotation of the coder, according to the nameplate of coder.

**Note: The motor will work normally only after setting the coder pulse correctly under the closed-loop condition . If the asynchronous motor still cannot work normally after the encoder pulse number set correctly, please exchange the connection line between the phase A and B of the coder. The coder pulse number of permanent-magnet synchronous motor must be set according to the encode when adapt U,V,W coder, and the pulse number per rotation should be set according to the encoder nameplate.**

|       |                                  |                       |      |           |      |
|-------|----------------------------------|-----------------------|------|-----------|------|
| F1-13 | Encoder failure monitoring times | Factory default value | 3.0s | Min. Unit | 0.1s |
|       | Setting Range                    | 0.0~10.0s             |      |           |      |

It can set monitoring time when encode fault occurs. After lift starts running with speed of nonzero, the system begins to receive signal of encoder every time of F1-13 setting. If there's none signal input, the system will show E20 which means encoder failure. If it is < 1s , the inspection function is invalid.

### 6.3 Group F2 Vector Control Parameter

| Function code | Name                              | Factory Default value | Min. Unit | Setting Range |
|---------------|-----------------------------------|-----------------------|-----------|---------------|
| F2-00         | Proportional gain 1 of speed loop | 40                    | 1         | 0~100         |
| F2-01         | Integrate time 1 of speed loop    | 0.60s                 | 0.01s     | 0.01~10.00s   |
| F2-02         | Switching frequency 1             | 2.00Hz                | 0.01Hz    | 0.00~F2-05    |
| F2-03         | Proportional gain 2 of speed loop | 35                    | 1         | 1~100         |
| F2-04         | Integration time 2 of speed loop  | 0.80s                 | 0.01s     | 0.01~10.00s   |
| F2-05         | Switching frequency 2             | 5.00Hz                | 0.01Hz    | F2-02~F0-05   |

The parameters of F2-00 and F2-01 decide the dynamic response characteristic of the frequency that is smaller than the switching frequency 1 (F2-02), while the parameters of F2-03 and F2-04 decide the dynamic response characteristic of the frequency that is larger than the switching frequency 2 (F2-05). The dynamic response characteristic parameters of the frequency between the switching frequency 1 and switching frequency 2 equal to the weighted average value of two set of F2-00,F2-01 and F2-03,F2-04. As shown in Fig. 6-2:




Fig. 6-2 PI Parameters Schematic Diagram

It can regulate the speed dynamic response characteristic of the vector control by setting the proportional coefficient and integrating time of the speed regulator. It can accelerate the dynamic response of the speed loop by increasing the proportional gain or decreasing the integrating time. Too large proportional gain or too small integrating time will cause the system to vibrate.

The regulating methods are recommended as follows:

If the factory parameters cannot satisfy the requirements, conduct minor adjustment on the basis of the factory parameters:

Enlarge the proportional gain first to prevent the system from vibrating, and then diminish the integrating time to ensure that the system has fast response characteristic and small overshoot.

If switching frequency 1 and switching frequency 2 are set as 0 at the same time, only F2-03 and F2-04 are virtual value.

Note: Once the PI parameters are set inappropriately, it will cause large

overshoot speed and even voltage fault when the overshoot returns to the normal level.

|       |                                   |                              |     |           |    |
|-------|-----------------------------------|------------------------------|-----|-----------|----|
| F2-06 | Proportional gain of current loop | <b>Factory Default value</b> | 60% | Min. Unit | 1% |
|       | Setting Range                     | 100~500%                     |     |           |    |
| F2-07 | Integral gain of current loop     | <b>Factory Default value</b> | 30% | Min. Unit | 1% |
|       | Setting Range                     | 100~500%                     |     |           |    |

F2-06, F2-07 are current loop adjusting parameters in the vector control arithmetic of synchronous motor. The adjustment in the synchronous motor has a obvious effect on the feeling of comfort. Appropriate adjustment can restrain the vibration while the lift is running. The adjusting method is the similar with that of parameter of speed loop P1.

|       |                              |                              |        |           |      |
|-------|------------------------------|------------------------------|--------|-----------|------|
| F2-08 | <b>Upper limit of torque</b> | <b>Factory Default value</b> | 150.0% | Min. Unit | 0.1% |
|       | Setting Range                | 0.0~200.0%                   |        |           |      |

It can set upper limit of torque of motor. The setup 100% corresponds to the rated torque of the motor that matches the system.

|       |                          |                              |   |           |    |
|-------|--------------------------|------------------------------|---|-----------|----|
| F2-10 | <b>Running direction</b> | <b>Factory Default value</b> | 0 | Min. Unit | s1 |
|       | Setting Range            | 0,1                          |   |           |    |

0: the same direction

1: opposite direction, reversed position pulse

2: The same running direction, reserved position pulse

3: opposite running direction, same position pulse

#### 6.4 Group F3 Running Control Parameters

|       |                       |                              |          |           |          |
|-------|-----------------------|------------------------------|----------|-----------|----------|
| F3-00 | <b>Starting speed</b> | <b>Factory Default value</b> | 0.000m/s | Min. Unit | 0.001m/s |
|-------|-----------------------|------------------------------|----------|-----------|----------|

|              |                       |                              |        |           |        |
|--------------|-----------------------|------------------------------|--------|-----------|--------|
|              | Setting Range         | 0.000~0.030m/s               |        |           |        |
| <b>F3-01</b> | <b>Retention time</b> | <b>Factory Default value</b> | 0.000s | Min. Unit | 0.001s |
|              | Setting Range         | 0.000~0.500s                 |        |           |        |

Setting of starting speed can reinforce the ability to overcome the static friction. If the setting of starting speed is too big, it can generate impact feeling at starting time. The using of two parameters can smooth the lift starting.

|              |                                 |                              |                       |           |                       |
|--------------|---------------------------------|------------------------------|-----------------------|-----------|-----------------------|
| <b>F3-02</b> | <b>Acceleration</b>             | <b>Factory Default value</b> | 0.300m/s <sup>2</sup> | Min. Unit | 0.001m/s <sup>2</sup> |
|              | Setting Range                   | 0.200~0.800m/s <sup>2</sup>  |                       |           |                       |
| <b>F3-03</b> | <b>Inflexion speedup time 1</b> | <b>Factory Default value</b> | 2.500s                | Min. Unit | 0.001s                |
|              | Setting Range                   | 0.300~4.000s                 |                       |           |                       |
| <b>F3-04</b> | <b>Inflexion speedup time 2</b> | <b>Factory Default value</b> | 2.500s                | Min. Unit | 0.001s                |
|              | Setting Range                   | 0.300~4.000s                 |                       |           |                       |

The three function codes decide the S curve parameters of lift speedup running:

F3-02 is acceleration of S curve of lift speedup running.

F3-03 is the time which is cost from 0 to the parameter F3-02 of S curve speedup stage. The bigger this parameter is, the slower curve inflexion is.

F3-04 is the time which is taken from the change of acceleration from 0 to that of F3-02 in the S curve speedup stage. The bigger this parameter is, the slower the flatter the curve inflexion is.

|              |                     |                              |                       |           |                       |
|--------------|---------------------|------------------------------|-----------------------|-----------|-----------------------|
| <b>F3-05</b> | <b>Deceleration</b> | <b>Factory Default value</b> | 0.300m/s <sup>2</sup> | Min. Unit | 0.001m/s <sup>2</sup> |
|              | Setting Range       | 0.200~0.800m/s <sup>2</sup>  |                       |           |                       |

|              |                                   |                              |        |           |        |
|--------------|-----------------------------------|------------------------------|--------|-----------|--------|
| <b>F3-06</b> | <b>Inflexion slow-down time 1</b> | <b>Factory Default value</b> | 2.500s | Min. Unit | 0.001s |
|              | Setting Range                     | 0.300~4.000s                 |        |           |        |
| <b>F3-07</b> | <b>Inflexion slow-down time 2</b> | <b>Factory Default value</b> | 2.500s | Min. Unit | 0.001s |
|              | Setting Range                     | 0.300~4.000s                 |        |           |        |

The three function codes decide the S curve parameters of lift slow-down running:

F3-05 is deceleration of S curve of lift slow-down running.

F3-06 is the time which is taken from the change of deceleration from F3-05 to 0 in the S curve slow-down stage. The bigger this parameter is, the flatter the curve inflexion is.

F3-07 is the time which is taken from the change of deceleration from 0 to that of F3-05 in the S curve slow-down stage. The bigger this parameter is, the flatter the curve inflexion is.

The setting of S curve is as follows:




Fig. 6-3 Speed Curve Fig.

|              |                             |                              |                       |           |                       |
|--------------|-----------------------------|------------------------------|-----------------------|-----------|-----------------------|
| <b>F3-08</b> | <b>Special deceleration</b> | <b>Factory Default value</b> | 0.500m/s <sup>2</sup> | Min. Unit | 0.001m/s <sup>2</sup> |
|              | Setting Range               | 0.500~2.000m/s <sup>2</sup>  |                       |           |                       |

This parameter sets the deceleration of the lift forced reducer, and deceleration in the condition of shaft-tuning and maintaining. If pulse numbers are far different from the budget numbers as lift force reducer acting, lift speed-down to 0.1m/s by special deceleration and travel to leveling position.

The setting of this parameter is:  $F3-08 \geq \frac{(F0 - 03)^2}{2 \times (F3 - 13)}$ , adjust according to the actual situation.

|              |                                |                              |       |           |        |
|--------------|--------------------------------|------------------------------|-------|-----------|--------|
| <b>F3-09</b> | <b>Stop distance allowance</b> | <b>Factory Default value</b> | 0.0mm | Min. Unit | 0.00mm |
|              | Setting Range                  | 0~90.0mm                     |       |           |        |

It means the advanced distance of lift distance control when the lift is slow-down. It is used to clear up the influence of coder signal missing or leveling signal delaying. Generally needs no user's modification

|              |                          |                              |          |           |          |
|--------------|--------------------------|------------------------------|----------|-----------|----------|
| <b>F3-10</b> | <b>Re-leveling speed</b> | <b>Factory Default value</b> | 0.040m/s | Min. Unit | 0.001m/s |
|              | Setting Range            | 0.000~0.080m/s               |          |           |          |

It means the re-leveling speed when the lift is in the door zone. Because the length of leveling plate is different in different system, the parameter adjusting can assure the landing accuracy of re-leveling. It is used when there is the function of re-leveling of door-open.

|              |                          |                              |          |           |          |
|--------------|--------------------------|------------------------------|----------|-----------|----------|
| <b>F3-11</b> | <b>Low-speed running</b> | <b>Factory Default value</b> | 0.250m/s | Min. Unit | 0.001m/s |
|              | Setting Range            | 0.100~0.500m/s               |          |           |          |

It can set the low speed of running when the lift is running in inspection or shaft self-tuning.

|              |                           |                |       |           |       |
|--------------|---------------------------|----------------|-------|-----------|-------|
| <b>F3-12</b> | <b>Switch position of</b> | <b>Factory</b> | 0.00m | Min. Unit | 0.01m |
|--------------|---------------------------|----------------|-------|-----------|-------|

|              |   |                              |       |           |       |
|--------------|---|------------------------------|-------|-----------|-------|
|              | <b>the NO.1 up forced deceleration</b>                      | <b>Default value</b>         |       |           |       |
|              | Setting Range   | 0.00~300.00m                 |       |           |       |
| <b>F3-13</b> | <b>Switch position of the NO.1 down forced deceleration</b> | <b>Factory Default value</b> | 0.00m | Min. Unit | 0.01m |
|              | Setting Range   | 0.00~300.00m                 |       |           |       |

The system can automatically monitor the running speed when lift run to the switching position of forced deceleration, and prevent car and counterweight from resting the buffer and plate because of the abnormality speed.

This parameter of distance means the distance from switch position to the lowest floor. It can self-motion note according to the lift self-tuning.

S means the setting distance of switch of forced deceleration to leveling position. The distance S must be enough for the deceleration from F3-08 to 0. That means S must suffice following conditions:

$$S > \frac{V^2}{2 * F3 - 08}$$

If the distance of forced deceleration is too short, the system will alarm failure E45 after lift self-tuning .It can be solved through increasing the distance of switch position of forced deceleration or parameter F3-08.

Advised position : 1.5m

|              |  |                              |        |           |        |
|--------------|--|------------------------------|--------|-----------|--------|
| <b>F3-14</b> | <b>Time of starting output with zero speed</b> | <b>Factory Default value</b> | 0.200s | Min. Unit | 0.001s |
|              | Setting Range                                  | 0.000~1.000s                 |        |           |        |

To protect lift starting ride comfort, the lift control can run with zero speed before brake opening. At this time, motor is in excitation, and it outputs bigger starting torque.

|              |                                    |                              |        |           |        |
|--------------|------------------------------------|------------------------------|--------|-----------|--------|
| <b>F3-15</b> | <b>Delay time of curve running</b> | <b>Factory Default value</b> | 0.200s | Min. Unit | 0.001s |
|--------------|------------------------------------|------------------------------|--------|-----------|--------|

|  |               |              |
|--|---------------|--------------|
|  | Setting Range | 0.000~1.000s |
|--|---------------|--------------|

This parameter sets time that it takes from the system outputting open signal to the brake complete opening. It usually needs about 200ms. The system keeps up outputting with zero speed.

|       |                           |                       |         |           |        |
|-------|---------------------------|-----------------------|---------|-----------|--------|
| F3-16 | Delay time of end running | Factory Default value | 0.300 s | Min. Unit | 0.001s |
|       | Setting Range             | 0.000~1.000s          |         |           |        |

It means holding time of zero speed when the curve running ends. Generally needs no user's modification.

In running course, the connection of each signal with curve is as follows:




Fig. 6-4 Running time sequence Fig.

### 6.5 Group F4 Position Parameters

|       |                    |                       |      |           |     |
|-------|--------------------|-----------------------|------|-----------|-----|
| F4-00 | Leveling adjusting | Factory Default value | 30mm | Min. Unit | 1mm |
|       | Setting Range      | 0~60mm                |      |           |     |

It can display the landing accuracy of lift. If the position of leveling inductor isn't in the middle of inductor plate when the lift stops, adjust this parameter. If lift is over leveling when stops, reduce the value of F4-00. If

lift is under leveling when stops, increase it. The parameter is set by the length of leveling plate.

|              |                      |  |   |           |   |
|--------------|----------------------|--|---|-----------|---|
| <b>F4-01</b> | <b>Current floor</b> | <b>Factory Default value</b>                     | 1 | Min. Unit | 1 |
|              | <b>Setting Range</b> | The lowest floor(F6-01)~The highest floor(F6-00) |   |           |   |

It can display the current floor of car.

The system can self-motion recompose this parameter when lift is running. And the system can automatically revise this parameter at leveling position after touching switch of up or down forced deceleration. When lift is in non-bottom or non-top floor, users can hand recompose this parameter. But this parameter must accord with the current floor.

| Function code | Name                             | Factory default value | Min. Unit | Setting Range |
|---------------|----------------------------------|-----------------------|-----------|---------------|
| <b>F4-02</b>  | <b>High bit of current floor</b> | 1                     | 1         | 0~65535       |
| <b>F4-03</b>  | <b>Low bit of current floor</b>  | 34464                 | 1         | 0~65535       |

It can display the number of pulse that the current floor relative to the lowest leveling floor.

| Function code | Name                              | Factory default value | Min. Unit | Setting Range |
|---------------|-----------------------------------|-----------------------|-----------|---------------|
| <b>F4-04</b>  | <b>Length 1 of leveling plate</b> | 0                     | 1         | 0~65535       |
| <b>F4-05</b>  | <b>Length 2 of leveling plate</b> | 0                     | 1         | 0~65535       |

It can display the pulse number of leveling plate's practical length. It is noted when self-tuning in well. Users can adjust it according to practical status.

| Function code | Name                            | Factory default value | Min. Unit | Setting Range |
|---------------|---------------------------------|-----------------------|-----------|---------------|
| <b>F4-06</b>  | <b>High bit of floor high 1</b> | 0                     | 1         | 0~65535       |

| Function code | Name                     | Factory default value | Min. Unit | Setting Range |
|---------------|--------------------------|-----------------------|-----------|---------------|
| F4-07         | Low bit of floor high 1  | 0                     | 1         | 0~65535       |
| ⋮             | ⋮                        | ⋮                     | ⋮         | ⋮             |
| F4-22         | High bit of floor high 9 | 0                     | 1         | 0~65535       |
| F4-23         | Low bit of floor high 9  | 0                     | 1         | 0~65535       |

The bit of floor height means the pulse number of height between floor i leveling plate to floor (i+1) leveling plate. Every height corresponds to one number of 32 bit numbers in binary system. Among those, high 16 bit parallels high bit of this floor height, and low 16 bit parallels low bit of this floor height.

For example: the floor height from floor 4 to floor 5 is F4-12=6, F4-13=54321. In binary it shows as follows:

0000, 0000, 0000, 0110, 1101, 0100, 0011, 0001

Practical pulse number will be displayed as 447537 in decimal system.

Shaft parameter self-tuning, is applied to record the switch position of the shaft.

The shaft self-tuning should meet the following requirements:

1. The feedback of coder and leveling sensor is normal, the shaft switch installed properly
2. The lift is located in the lowest floor, and the forced deceleration switch is working
3. The lift is in the inspection state and can undergoing the inspection running
4. The highest and lowest floor is set properly
- 5 The NICE 1000 is not in the error warning state

User can set the lift into self-tuning state by pressing the S1 button for 1s.

## 6.6 F5 Group Terminal Input Function Parameters

| Function code | Name   | Factory default value | Min. Unit | Setting Range |
|---------------|--|-----------------------|-----------|---------------|
| F5-00         | Attendant control and automatic control switching time | 3s                    | 1         | 1~200s        |

When there's call from other floors in attendant state, it will turn to the normal state automatically after F5-00 time if no one operates; then return to attendant state after the running.

When the parameter of F5-00 is smaller than 5, the mentioned function is cancelled, then it's the same as the normal attendant function.

| Function code | Name                               | Factory default value | Min. Unit | Setting Range |
|---------------|------------------------------------|-----------------------|-----------|---------------|
| F5-01         | Function selection of terminal X1  | 03                    | 1         | 00~199        |
| F5-02         | Function selection of terminal X2  | 104                   | 1         | 00~199        |
| ⋮             | ⋮                                  | ⋮                     | ⋮         | ⋮             |
| F5-23         | Function selection of terminal X23 | 00                    | 1         | 00~199        |
| F5-24         | Function selection of terminal X24 | 00                    | 1         | 00~199        |

X1~X24 is switch input terminal, and they can select corresponding function codes 00~199. The same function code can't be used repeatedly. If the terminal X1 input signal is 24V, the signal light X1 of the main operation panel will light. The rest may be deduced by analogy. The code of every function is as follows:

00: Not in use

The controller does not respond even if the signal is inputted. Set the unused terminals as 00 to prevent error activation.

01: Leveling 1 signal    02: Leveling 2 signal    03: Door zone signal

The system can control lift leveling stopping by signal of leveling inductor. The system can support 3 leveling models: up level inductor + down level inductor, up level inductor + down level inductor + door zone inductor or only door zone level inductor. If the leveling inductor signal is deviant (conglutination or cut-off), the system will indicate E22 error.

04: Running output feedback signal05: Brake output feedback 1signal06: Brake output feedback 2signal

The system monitors the signal of running feedback and brake feedback after 2s when the running contactor is cut off. It's used to judge whether the contactor is picked-up or not.

07: U.V.W jump-out feedback signal

It controls the synchronous motor's U.V.W jump out contactor. When the lift is in power failure emergency running state, if the traction motor is permanent-magnet synchronous motor and is automatically emergency running, the brake opens, and relevant terminal outputs, which make the lift self-motion slide running to the nearest leveling and then open the door. Details are in chapter7. In addition, the function increases the safety when the lift stops in a normal state.

08: Door lock jump out output feedback signal

The system outputs the pick-up command for the door lock jump out contactor, to fulfill pre-opening, door lock jump-out and releasing control when leveling after opening.

09: Inspection signal    10: Inspection up signal11: Inspection down signal

When the "Auto/ Inspection" switch points to "Inspection", lift comes into inspection state, the system cancel all auto running include auto-door operation. When input inspection up or down running signal, lift will run with

inspection speed.

12: Once fire signal

When the “fire” switch is open, lift comes into fire state. The system will cancel all entered landing call and car call; the lift will park at the next land and pass the fire landing without opening the door. Lift won't open door for setting passengers free until arriving at the fire landing base.

13: Reserved

14: Lift lock signal

Lift lock signal input point, the signal is valid, the system gets into lift-lock state.

15: Up limit signal

16: Down limit signal

The signals of up limit and down limit are the terminal stopping switches for preventing car resting the buffer when the lift passed the leveling station of landing without stopping.

17: Up forced deceleration signal

18: Down forced deceleration signal

These functional codes set input point into N.O. input of forced deceleration, corresponding to the forced deceleration switch signal. NICE 1000 system records these positions of switches into parameters of F3 group.

19: Over loading signal

If the lift loading is over 110% of rated load, the system comes into over loading state. The over loading buzzer tweets, the car light of over loading lights and lift doesn't close the door. If the door lock is closed, the over loading signal is impotent. In the lift checking course, if the system need run with 110% over loading, it can set F6-10=4 to control.

20: Full loading signal

The lift loading among 80%~110% is full loading state, the land hall lantern shows full loading, the lift doesn't answer the hall call.

21: Urgent stop (Safety feedback) signal

Safety circuit is the core guarantee of the lift's reliable running.

22: Door 1 open limit signal

Relevant terminal is used to receive the open door arrival signal 1.

23: Door 2 open limit signal

Relevant terminal is used to receive the open door arrival signal 2.

24: Door 1 close limit signal

Relevant terminal is used to receive the close door arrival signal 1.

25: Door 2 close limit signal

Relevant terminal is used to receive the close door arrival signal 2.

26: Door 1 light curtain signal

This function code terminal setting is used for the light curtain 1 signal receiving.

27: Door 2 light curtain signal

This function code terminal setting is used for the light curtain 2 signal receiving.

28: Attendant signal

If the signal is valid, the lift will get into attendant operation state.

29: Direct arrival signal

In attendant state, if the direct arrival signal is valid, the lift won't respond to the external call.

30: Direction changing signal

In attendant state, if the signal is valid, the lift switches the running direction.

31: Independent running signal

If the signal is valid, the lift gets off parallel.

32: Door 2 selection signal

In the open-through door control, if door switch is controlled by car switch or button, corresponding input terminal will receive the signal. If the signal

is valid, the system will open and close door 2. If the signal is not valid, the system will open and close door 1.

### 33: UPS input valid

The corresponding input terminal is used to receive power failure emergency running signal.

### 34: Open button

The open command input signal

### 35: close button

Close command input signal

### 36: safety circuit

Safety circuit is the reliable guarantee for lift running

### 37: door lock circuit 1

Door lock ensure the close of hall door and car door when lift running

### 38: door lock circuit 2

Same function as circuit 1, convenient to distinguish the hall door signal and car door signal. The system will identify the door lock closed only when the 2 lock feedback signal are connected

### 39: half-loaded signal

The signal is valid when the car load is excess half . key signal to judge running direction in emergency running.

### 40-99 reserved

### 101~109

These 99 parameters are corresponding with parameters 01~99. The parameters 01~99 input terminal are set as N.O. input, but the parameters 101~199 are set as N.C. input.

| Function code | Name                            | Default | Min. Unit | Setting Range |
|---------------|---------------------------------|---------|-----------|---------------|
| F5-25         | X25 strong power input function | 01      | 1         | 00~99         |

| Function code | Name   | Default | Min. Unit | Setting Range |
|---------------|--|---------|-----------|---------------|
|               | <b>selection</b>                                 |         |           |               |
| <b>F5-26</b>  | <b>X26 strong power input function selection</b> | 02      | 1         | 00~99         |
| <b>F5-27</b>  | <b>X27 strong power input function selection</b> | 03      | 1         | 00~99         |

00: Not in use

The system won't respond even though there's signal inputted. Set the unused terminal as 00 in order to prevent from miss-action.

01: Safety circuit signal

Set the terminal of this function to detect safety circuit strong power feedback.

02: Door lock circuit 1 signal

Set the terminal of this function to detect door lock circuit strong power feedback. It can be used in hall door circuit and car door lock circuit.


03: Door lock circuit 2 signal

Set the terminal of this function to detect door lock circuit strong power feedback. It can be used in hall door circuit and car door lock circuit.

04~99: Reserved

| Function code | Name                                      | Default | Min. Unit | Setting Range |
|---------------|---|---------|-----------|---------------|
| <b>F5-28</b>  | Input and output terminal state display 1 |         |           |               |
| <b>F5-29</b>  | Input and output terminal state display 2 |         |           |               |

When users enter F5-28 menu, the tube on the keyboard shows the output terminal state at present. The keyboard tube order is 5, 4,3,2,1 from left to right. Every passage's definition is as follows:



F5-28 expresses the state 1 of the input or output terminal. Its meanings are listed in the following Fig.s:

| Tube sequence | Tube passage marker | Tube passage meaning                 | Tube passage "light" meaning                                  |
|---------------|---------------------|--------------------------------------|---|
| 1             | A                   | Not in use                           | Meaningless   |
|               | B                   | Leveling 1 signal                    | Leveling 1 signal availability                                |
|               | C                   | Leveling 2 signal                    | Leveling 2 signal availability                                |
|               | D                   | Door zone signal                     | Door zone signal availability                                 |
|               | E                   | Run output feedback signal           | Run output feedback signal availability                       |
|               | F                   | Brake output feedback 1 signal       | Brake output feedback 1 signal availability                   |
|               | G                   | Brake output feedback 2 signal       | Brake output feedback 2 signal availability                   |
|               | DP                  | U.V.W jump out feedback signal       | Synchronous motor U.V.W jump out feedback signal availability |
| 2             | A                   | Enclosed door output feedback signal | Enclosed door output feedback signal availability             |
|               | B                   | Inspection signal                    | Inspection signal availability                                |
|               | C                   | Inspection up signal                 | Inspection up signal availability                             |
|               | D                   | Inspection down signal               | Inspection down signal availability                           |
|               | E                   | Once fire signal                     | Once fire signal availability                                 |
|               | F                   | Reserved                             | Reserved  |
|               | G                   | Lock lift signal                     | Lock lift signal availability                                 |
|               | DP                  | Up limit signal                      | Up limit signal availability                                  |
| 3             | A                   | Down limit signal                    | Down limit signal availability                                |
|               | B                   | Up force reducer signal              | Up force reducer signal availability                          |
|               | C                   | Down force reducer signal            | Down force reducer signal availability                        |

| Tube sequence | Tube passage marker | Tube passage meaning                 | Tube passage "light" meaning                      |
|---------------|---------------------|--------------------------------------|---|
|               | D                   | Over load signal                     | Over load signal availability                     |
|               | E                   | Full load signal                     | Full load signal availability                     |
|               | F                   | Urgent stop (safety feedback) signal | Urgent stop (safety feedback) signal availability |
|               | G                   | Door 1 open limit signal             | Door 1 open limit signal availability             |
|               | DP                  | Door 2 open limit signal             | Door 1 open limit signal availability             |
| 4             | A                   | Door 1 close limit signal            | Door 1 close limit signal availability            |
|               | B                   | Door 2 close limit signal            | Door 2 close limit signal availability            |
|               | C                   | Door 1 light curtain signal          | Door 1 light curtain signal availability          |
|               | D                   | Door 2 light curtain signal          | Door 2 light curtain signal availability          |
|               | E                   | Motorman signal                      | Motorman signal availability                      |
|               | F                   | Direct arrival signal                | Direct arrival signal availability                |
|               | G                   | Direction changing signal            | Direction changing signal availability            |
|               | DP                  | Independent running signal           | Independent running signal availability           |
| 5             | A                   | Door 2 selection signal              | Door 2 selection signal availability              |
|               | B                   | UPS input valid                      | UPS input valid                                   |
|               | C                   | Open button                          | Open signal valid                                 |
|               | D                   | Close button                         | Close button valid                                |
|               | E                   | Door lock circuit1                   | Door circuit 1 valid                              |
|               | F                   | Door circuit 2                       | Door circuit 2 valid                              |
|               | G                   | Half load signal                     | Half load signal valid                            |
|               | DP                  | Not in use                           | Meaningless                                       |


F5-29 expresses the state 2 of the input or output terminal. Its meanings are listed in the following Fig.s:

| Tube sequence | Tube passage marker | Tube passage meaning                    | Tube passage "light" meaning                         |
|---------------|---------------------|---|--|
| 1             | A                   | Not in use                              | Meaningless  |
|               | B                   | Safety circuit signal                   | Safety circuit signal availability                   |
|               | C                   | Door lock circuit 1 signal              | Door lock circuit 1 signal availability              |
|               | D                   | Door lock circuit 2 signal              | Door lock circuit 2 signal availability              |
|               | E                   | Not in use                              | Meaningless  |
|               | F                   | Not in use                              | Meaningless  |
|               | G                   | Not in use                              | Meaningless  |
|               | DP                  | Not in use                              | Meaningless  |
| 2             | A                   | Y0 output                               | Y0 output availability                               |
|               | B                   | Running contactor output                | Running contactor output availability                |
|               | C                   | Brake contactor output                  | Brake contactor output availability                  |
|               | D                   | Brake forced output                     | Brake forced output availability                     |
|               | E                   | Illumination and fan output             | Illumination and fan output availability             |
|               | F                   | Synchronous motor U.V.W jump out output | Synchronous motor U.V.W jump out output availability |
|               | G                   | Door1 open output                       | Door1 open output availability                       |
|               | DP                  | Door1 close output                      | Door1 close output availability                      |
| 3             | A                   | Door2 open output                       | Door2 open output availability                       |
|               | B                   | Door2 close output                      | Door2 close output availability                      |
|               | C                   | Low 7 segment code a display output     | Low 7 segment code a display output availability     |
|               | D                   | Low 7 segment code b display output     | Low 7 segment code b display output availability     |
|               | E                   | Low 7 segment code c display output     | Low 7 segment code c display output availability     |
|               | F                   | Low 7 segment                           | Low 7 segment code d                                 |

| Tube sequence | Tube passage marker | Tube passage meaning                          | Tube passage "light" meaning                               |
|---------------|---------------------|---|--|
|               |                     | code d display output                         | display output availability                                |
|               | G                   | Low 7 segment code e display output           | Low 7 segment code e display output availability           |
|               | DP                  | Low 7 segment code f display output           | Low 7 segment code f display output availability           |
| 4             | A                   | Low 7 segment code g display output           | Low 7 segment code g display output availability           |
|               | B                   | Up arrowhead display output                   | Up arrowhead display output availability                   |
|               | C                   | Down arrowhead display output                 | Down arrowhead display output availability                 |
|               | D                   | Minus display output                          | Minus display output availability                          |
|               | E                   | Fire to main landing signal output            | Fire to main landing signal output availability            |
|               | F                   | Buzzer control output                         | Buzzer control output availability                         |
|               | G                   | Over load output                              | Over load output availability                              |
|               | DP                  | Arrival gong output                           | Arrival gong output availability                           |
| 5             | A                   | Full load output                              | Full load output availability                              |
|               | B                   | Inspection output                             | Inspection output availability                             |
|               | C                   | Illumination and fan Output 2                 | Illumination and fan Output 2 availability                 |
|               | D                   | Enclosed door contactor output                | Enclosed door contactor output availability                |
|               | E                   | BCD, Gray code , 7 block code high bit output | BCD, Gray code , 7 block code high bit output availability |
|               | F                   | Integrated running normal output              | Integrated running normal output                           |
|               | G                   | Not in use                                    | Meaningless  |
|               | DP                  | Not in use                                    | Meaningless  |

| Function code | Name  | Default | Min. Unit | Setting Range |
|---------------|---|---------|-----------|---------------|
| F5-30         | Floor input and output terminal state display 1 |         |           |               |
| F5-31         | Floor input and output terminal state display 2 |         |           |               |

When users enter F5-30 menu, the tube on the keyboard shows the output terminal state at present. The keyboard tube order is 5, 4,3,2,1 from left to right. Every passage's definition is as follows:



F5-30 expresses the state 1 of the floor input or output terminal. Its meanings are listed in the following Fig.s:

| Tube sequence | Tube passage marker | Tube passage meaning  | Tube passage "light" meaning   |
|---------------|---------------------|---|--|
| 1             | A                   | Door 1 open button input and output                                   | Door 1 open button input and output availability                                   |
|               | B                   | Door 1 close button input and output                                  | Door 1 close button input and output availability                                  |
|               | C                   | Door 1 open delaying button input and output                          | Door 1 open delaying button input and output availability                          |
|               | D                   | Internal call of door 1 on the 1 <sup>st</sup> floor input and output | Internal call of door 1 on the 1 <sup>st</sup> floor input and output availability |
|               | E                   | Internal call of door 1 on the 2 <sup>nd</sup> floor input and output | Internal call of door 1 on the 2 <sup>nd</sup> floor input and output availability |
|               | F                   | Internal call of door 1 on the 3 <sup>rd</sup> floor input and output | Internal call of door 1 on the 3 <sup>rd</sup> floor input and output availability |
|               | G                   | Internal call of door   | Internal call of door 1 on the 4 <sup>th</sup>                                     |

| Tube sequence | Tube passage marker | Tube passage meaning   | Tube passage "light" meaning  |
|---------------|---------------------|--|---|
|               |                     | 1 on the 4 <sup>th</sup> floor input and output                        | floor input and output availability   |
|               | DP                  | Internal call of door 1 on the 5 <sup>th</sup> floor input and output  | Internal call of door 1 on the 5 <sup>th</sup> floor input and output availability  |
| 2             | A                   | Internal call of door 1 on the 6 <sup>th</sup> floor input and output  | Internal call of door 1 on the 6 <sup>th</sup> floor input and output availability  |
|               | B                   | Internal call of door 1 on the 7 <sup>th</sup> floor input and output  | Internal call of door 1 on the 7 <sup>th</sup> floor input and output availability  |
|               | C                   | Internal call of door 1 on the 8 <sup>th</sup> floor input and output  | Internal call of door 1 on the 8 <sup>th</sup> floor input and output availability  |
|               | D                   | Internal call of door 1 on the 9 <sup>th</sup> floor input and output  | Internal call of door 1 on the 9 <sup>th</sup> floor input and output availability  |
|               | E                   | Internal call of door 1 on the 10 <sup>th</sup> floor input and output | Internal call of door 1 on the 10 <sup>th</sup> floor input and output availability |
|               | F                   | Reserved   | Reserved  |
|               | G                   | Not in use   | Meaningless   |
|               | DP                  | Not in use   | Meaningless   |
| 3             | A                   | Up call of door 1 on the 1 <sup>st</sup> floor input and output        | Up call of door 1 on the 1 <sup>st</sup> floor input and output availability        |
|               | B                   | Reserved   | Reserved  |
|               | C                   | Up call of door 1 on the 2 <sup>nd</sup> floor input and output        | Up call of door 1 on the 2 <sup>nd</sup> floor input and output availability        |
|               | D                   | Down call of door 1 on the 2 <sup>nd</sup> floor input and output      | Down call of door 1 on the 2 <sup>nd</sup> floor input and output availability      |
|               | E                   | Up call of door 1 on the 3 <sup>rd</sup> floor input and output        | Up call of door 1 on the 3 <sup>rd</sup> floor input and output availability        |

| Tube sequence | Tube passage marker | Tube passage meaning  | Tube passage "light" meaning   |
|---------------|---------------------|---|--|
|               | F                   | Down call of door 1 on the 3 <sup>rd</sup> floor input and output | Down call of door 1 on the 3 <sup>rd</sup> floor input and output availability |
|               | G                   | Up call of door 1 on the 4 <sup>th</sup> floor input and output   | Up call of door 1 on the 4 <sup>th</sup> floor input and output availability   |
|               | DP                  | Down call of door 1 on the 4 <sup>th</sup> floor input and output | Down call of door 1 on the 4 <sup>th</sup> floor input and output availability |
| 4             | A                   | Up call of door 1 on the 5 <sup>th</sup> floor input and output   | Up call of door 1 on the 5 <sup>th</sup> floor input and output availability   |
|               | B                   | Down call of door 1 on the 5 <sup>th</sup> floor input and output | Down call of door 1 on the 5 <sup>th</sup> floor input and output availability |
|               | C                   | Up call of door 1 on the 6 <sup>th</sup> floor input and output   | Up call of door 1 on the 6 <sup>th</sup> floor input and output availability   |
|               | D                   | Down call of door 1 on the 6 <sup>th</sup> floor input and output | Down call of door 1 on the 6 <sup>th</sup> floor input and output availability |
|               | E                   | Up call of door 1 on the 7 <sup>th</sup> floor input and output   | Up call of door 1 on the 7 <sup>th</sup> floor input and output availability   |
|               | F                   | Down call of door 1 on the 7 <sup>th</sup> floor input and output | Down call of door 1 on the 7 <sup>th</sup> floor input and output availability |
|               | G                   | Up call of door 1 on the 8 <sup>th</sup> floor input and output   | Up call of door 1 on the 8 <sup>th</sup> floor input and output availability   |
|               | DP                  | Down call of door 1 on the 8 <sup>th</sup> floor input and output | Down call of door 1 on the 8 <sup>th</sup> floor input and output availability |
| 5             | A                   | Up call of door 1 on the 9 <sup>th</sup> floor input and output   | Up call of door 1 on the 9 <sup>th</sup> floor input and output availability   |

| Tube sequence | Tube passage marker | Tube passage meaning   | Tube passage "light" meaning   |
|---------------|---------------------|--|--|
|               | B                   | Down call of door 1 on the 9 <sup>th</sup> floor input and output  | Down call of door 1 on the 9 <sup>th</sup> floor input and output availability |
|               | C                   | Reserved   | Reserved   |
|               | D                   | Down call of door 1 on the 10 <sup>th</sup> floor input and output | Down call of door 1 on the 10 <sup>th</sup> floor input and output             |
|               | E                   | Reserved   | Reserved   |
|               | F                   | Reserved   | Reserved   |
|               | G                   | Not in use   | Meaningless  |
|               | DP                  | Not in use   | Meaningless  |

F5-31 expresses the state 2 of the floor input or output terminal. Its meanings are listed in the following Fig.s:

| Tube sequence | Tube passage marker | Tube passage meaning  | Tube passage "light" meaning   |
|---------------|---------------------|---|--|
| 1             | A                   | Door 2 open button input and output                                   | Door 2 open button input and output availability                                   |
|               | B                   | Door 2 close button input and output                                  | Door 2 close button input and output availability                                  |
|               | C                   | Door 2 open delaying button input and output                          | Door 2 open delaying button input and output availability                          |
|               | D                   | Internal call of door 2 on the 1 <sup>st</sup> floor input and output | Internal call of door 2 on the 1 <sup>st</sup> floor input and output availability |
|               | E                   | Internal call of door 2 on the 2 <sup>nd</sup> floor input and output | Internal call of door 2 on the 2 <sup>nd</sup> floor input and output availability |
|               | F                   | Internal call of door 2 on the 3 <sup>rd</sup> floor input and output | Internal call of door 2 on the 3 <sup>rd</sup> floor input and output availability |
|               | G                   | Internal call of door 2 on the 4 <sup>th</sup> floor input and output | Internal call of door 2 on the 4 <sup>th</sup> floor input and output availability |
|               | DP                  | Internal call of door   | Internal call of door 2 on the 5 <sup>th</sup>                                     |

| Tube sequence | Tube passage marker | Tube passage meaning   | Tube passage "light" meaning  |
|---------------|---------------------|--|---|
|               |                     | 2 on the 5 <sup>th</sup> floor input and output                        | floor input and output availability   |
| 2             | A                   | Internal call of door 2 on the 6 <sup>th</sup> floor input and output  | Internal call of door 2 on the 6 <sup>th</sup> floor input and output availability  |
|               | B                   | Internal call of door 2 on the 7 <sup>th</sup> floor input and output  | Internal call of door 2 on the 7 <sup>th</sup> floor input and output availability  |
|               | C                   | Internal call of door 2 on the 8 <sup>th</sup> floor input and output  | Internal call of door 2 on the 8 <sup>th</sup> floor input and output availability  |
|               | D                   | Internal call of door 2 on the 9 <sup>th</sup> floor input and output  | Internal call of door 2 on the 9 <sup>th</sup> floor input and output availability  |
|               | E                   | Internal call of door 2 on the 10 <sup>th</sup> floor input and output | Internal call of door 2 on the 10 <sup>th</sup> floor input and output availability |
|               | F                   | Reserved   | Reserved  |
|               | G                   | Not in use   | Meaningless   |
|               | DP                  | Not in use   | Meaningless   |
| 3             | A                   | Up call of door 2 on the 1 <sup>st</sup> floor input and output        | Up call of door 2 on the 1 <sup>st</sup> floor input and output availability        |
|               | B                   | Reserved   | Reserved  |
|               | C                   | Up call of door 2 on the 2 <sup>nd</sup> floor input and output        | Up call of door 2 on the 2 <sup>nd</sup> floor input and output availability        |
|               | D                   | Down call of door 2 on the 2 <sup>nd</sup> floor input and output      | Down call of door 2 on the 2 <sup>nd</sup> floor input and output availability      |
|               | E                   | Up call of door 2 on the 3 <sup>rd</sup> floor input and output        | Up call of door 2 on the 3 <sup>rd</sup> floor input and output availability        |
|               | F                   | Down call of door 2 on the 3 <sup>rd</sup> floor input and output      | Down call of door 2 on the 3 <sup>rd</sup> floor input and output availability      |

| Tube sequence | Tube passage marker | Tube passage meaning  | Tube passage "light" meaning   |
|---------------|---------------------|---|--|
|               | G                   | Up call of door 2 on the 4 <sup>th</sup> floor input and output   | Up call of door 2 on the 4 <sup>th</sup> floor input and output availability   |
|               | DP                  | Down call of door 2 on the 4 <sup>th</sup> floor input and output | Down call of door 2 on the 4 <sup>th</sup> floor input and output availability |
| 4             | A                   | Up call of door 2 on the 5 <sup>th</sup> floor input and output   | Up call of door 2 on the 5 <sup>th</sup> floor input and output availability   |
|               | B                   | Down call of door 2 on the 5 <sup>th</sup> floor input and output | Down call of door 2 on the 5 <sup>th</sup> floor input and output availability |
|               | C                   | Up call of door 2 on the 6 <sup>th</sup> floor input and output   | Up call of door 2 on the 6 <sup>th</sup> floor input and output availability   |
|               | D                   | Down call of door 2 on the 6 <sup>th</sup> floor input and output | Down call of door 2 on the 6 <sup>th</sup> floor input and output availability |
|               | E                   | Up call of door 2 on the 7 <sup>th</sup> floor input and output   | Up call of door 2 on the 7 <sup>th</sup> floor input and output availability   |
|               | F                   | Down call of door 2 on the 7 <sup>th</sup> floor input and output | Down call of door 2 on the 7 <sup>th</sup> floor input and output availability |
|               | G                   | Up call of door 2 on the 8 <sup>th</sup> floor input and output   | Up call of door 2 on the 8 <sup>th</sup> floor input and output availability   |
|               | DP                  | Down call of door 2 on the 8 <sup>th</sup> floor input and output | Down call of door 2 on the 8 <sup>th</sup> floor input and output availability |
| 5             | A                   | Up call of door 2 on the 9 <sup>th</sup> floor input and output   | Up call of door 2 on the 9 <sup>th</sup> floor input and output availability   |
|               | B                   | Down call of door 2 on the 9 <sup>th</sup> floor input and output | Down call of door 2 on the 9 <sup>th</sup> floor input and output availability |

| Tube sequence | Tube passage marker | Tube passage meaning   | Tube passage "light" meaning                                       |
|---------------|---------------------|--|--|
|               | C                   | Reserved   | Reserved   |
|               | D                   | Down call of door 2 on the 10 <sup>th</sup> floor input and output | Down call of door 2 on the 10 <sup>th</sup> floor input and output |
|               | E                   | Reserved   | Reserved   |
|               | F                   | Reserved   | Reserved   |
|               | G                   | Not in use   | Meaningless  |
|               | DP                  | Not in use   | Meaningless  |

### 6.7 Group F6 Lift Basic Parameters

| Function code | Name              | Default | Min. Unit | Setting Range |
|---------------|-------------------|---------|-----------|---------------|
| F6-00         | The highest floor | 5       | 1         | F6-01~10      |
| F6-01         | The lowest floor  | 1       | 1         | 1~F6-00       |
| F6-02         | Parking floor     | 1       | 1         | F6-01~F6-00   |

When the system not in using time is over the F9-00 setting value, lift can return parking floor by itself.

|       |                 |  |   |           |   |
|-------|-----------------|--|---|-----------|---|
| F6-03 | Fire base floor | Default  | 1 | Min. Unit | 1 |
|       | Setting Range   | The lowest landing(F6-01)~The highest landing(F6-00) |   |           |   |

The lift will return to the landing when the system is in fire landing state.

|       |                 |  |   |           |   |
|-------|-----------------|--|---|-----------|---|
| F6-04 | locking landing | Default  | 1 | Min. Unit | 1 |
|       | Setting Range   | The lowest landing(F6-01)~The highest landing(F6-00) |   |           |   |

When lift is in locking state, it will return to this landing after completing control box command.

| Function code | Name          | Default | Min. Unit | Setting Range |
|---------------|---------------|---------|-----------|---------------|
| F6-05         | service floor | 1023    | 1         | 0~1023        |

F6-05 set what kind of floors' command the lift responds throughout the

floors.

The floor service is controlled by binary system number of 10 bit. The binary system number express the floor 1~10 from low bit to high bit, The setting relevant bit 1 express that lift responds to this floor's calling, and the setting relevant bit 0 express that lift doesn't respond to this floor's calling. For example, floors in need of service are listed as follows:

| Binary digit | Relevant floor | Service or not | Binary bit setting | Binary digit | Relevant floor | Service or not | Binary bit setting |
|--------------|----------------|----------------|--------------------|--------------|----------------|----------------|--------------------|
| Bit0         | Floor 1        | ON             | 1                  | Bit5         | Floor 6        | ON             | 1                  |
| Bit1         | Floor 2        | OFF            | 0                  | Bit6         | Floor 7        | ON             | 1                  |
| Bit2         | Floor 3        | ON             | 1                  | Bit7         | Floor 8        | OFF            | 0                  |
| Bit3         | Floor 4        | ON             | 1                  | Bit8         | Floor 9        | OFF            | 0                  |
| Bit4         | Floor 5        | ON             | 1                  | Bit9         | Floor 10       | ON             | 1                  |

The relevant binary digit setting is added in the list. The binary bit is 1001111101, and the relevant algorithm number is 637, so F6-05 should be set as 637.

|              |                                |         |   |           |   |
|--------------|--------------------------------|---------|---|-----------|---|
| <b>F6-09</b> | <b>Testing times at random</b> | Default | 0 | Min. Unit | 1 |
|              | Setting Range                  | 0~60000 |   |           |   |

It's used to test the lift's running. If the function is valid, the lift can select the floor at random to run automatically, until the setting times are completed.

|              |  |  |   |           |   |
|--------------|--|--|---|-----------|---|
| <b>F6-10</b> | <b>Selection of enabled function testing</b> | Default  | 0 | Min. Unit | 1 |
|              | Setting Range                                | Bit0: External call ignored function<br>Bit1: Open door enabled function<br>Bit2: Overloading enabled function<br>Bit3: Limit enabled function |   |           |   |

Bit0: External call ignored function. If the bit is set as 1, it won't respond to

the external call, and it returns to 0 automatically if power failure occurs in this bit.

Bit1: Open door enabled function. If the bit is set as 1, it won't open the door automatically, and it returns to 0 automatically if power failure occurs in this bit.

Bit2: Overloading enabled function. If the bit is set as 1, the function is invalidation, and it returns to 0 automatically if power failure occurs in this bit in order to facilitate 110% running.

Bit3: Limit enabled function. If the bit is set as 1, the function is invalidation, and it returns to 0 automatically if power failure occurs in this bit in order to facilitate test limit switch when testing. It can be only used once after setting.

Bit4~Bit15: Reserved

Note: F6-10 can only be used by the qualified persons, please pay special attention. It's claimed that setting person is responsible for the corresponding results. Please make sure that F6-10 is set as 0 when the lift is normally running.

| Function code | Name                   | Default | Min. Unit | Setting Range |
|---------------|------------------------|---------|-----------|---------------|
| F6-11         | L1 function selection  | 201     | 1         | 201~399       |
| F6-12         | L2 function selection  | 202     | 1         | 201~399       |
| ⋮             | ⋮                      | ⋮       | ⋮         | ⋮             |
| F6-35         | L25 function selection | 00      | 1         | 201~399       |
| F6-36         | L26 function selection | 00      | 1         | 201~399       |

Selection of the floors' button inputting:

201~203 (Door 1 switch the door)      204~209 (Reserved)

210~219 (Door 1 internal call)      220~229 (Door 1 up external call)

230~239 (Door 1 down external call)      240~299 (Reserved)

301~399 (Door2)

304 (door 2 selection button lamp output)

00: Not in use

201: Door 1 door opening button

202: Door 1 door closing button

203: Door 1 door opening delaying button

204 Door 2 selection button input

205~209: (Reserved)

210: Internal call of door 1 on the 10<sup>th</sup> floor

211: Internal call of door 1 on the 1<sup>st</sup> floor

212: Internal call of door 1 on the 2<sup>nd</sup> floor

213: Internal call of door 1 on the 3<sup>rd</sup> floor

214: Internal call of door 1 on the 4<sup>th</sup> floor

215: Internal call of door 1 on the 5<sup>th</sup> floor

216: Internal call of door 1 on the 6<sup>th</sup> floor

217: Internal call of door 1 on the 7<sup>th</sup> floor

218: Internal call of door 1 on the 8<sup>th</sup> floor

219: Internal call of door 1 on the 9<sup>th</sup> floor

220: (Reserved)

221: Up call of door 1 on the 1<sup>st</sup> floor

222: Up call of door 1 on the 2<sup>nd</sup> floor

223: Up call of door 1 on the 3<sup>rd</sup> floor

224: Up call of door 1 on the 4<sup>th</sup> floor

225: Up call of door 1 on the 5<sup>th</sup> floor

226: Up call of door 1 on the 6<sup>th</sup> floor

227: Up call of door 1 on the 7<sup>th</sup> floor

228: Up call of door 1 on the 8<sup>th</sup> floor

229: Up call of door 1 on the 9<sup>th</sup> floor

230: Down call of door 1 on the 10<sup>th</sup> floor

231: (Reserved)

232: Down call of door 1 on the 2<sup>nd</sup> floor

233: Down call of door 1 on the 3<sup>rd</sup> floor

234: Down call of door 1 on the 4<sup>th</sup> floor

235: Down call of door 1 on the 5<sup>th</sup> floor

236: Down call of door 1 on the 6<sup>th</sup> floor

237: Down call of door 1 on the 7<sup>th</sup> floor

238: Down call of door 1 on the 8<sup>th</sup> floor

239: Down call of door 1 on the 9<sup>th</sup> floor

240: (Reserved)

241~249: Reserved

### 6.8 Group F7 Terminal Output Function Parameter

| Function code | Name                  | Default | Min. Unit | Setting range |
|---------------|-----------------------|---------|-----------|---------------|
| F7-00         | Y0 function selection | 00      | 1         | 00~99         |

Y0 as the single relay output can select all the relay output function. When the lift need power failure emergency running function, F7-00 need be set as 32 in order to enable the lift automatically switch to power failure emergency running.

| Function code | Name                  | Default | Min. Unit | Setting range |
|---------------|-----------------------|---------|-----------|---------------|
| F7-01         | Y1 function selection | 01      | 1         | 00~05         |

| Function code | Name                  | Default | Min. Unit | Setting range |
|---------------|-----------------------|---------|-----------|---------------|
| F7-02         | Y2 function selection | 02      | 1         | 00~05         |
| F7-03         | Y3 function selection | 04      | 1         | 00~05         |

F7-01~F7-03 can only choose:

00: Not in use

No function in output terminal

01: Run contactor output

It controls the run contactor's pick-up and release.

02: Brake contactor output

It controls the brake contactor's pick-up and release.

03: Brake forced output

It keeps outputting for 4s when each time it opens the brake in order to control the brake's starting point's pressure.

04: Illumination and fan output

It controls illumination and fan output.

05: Synchronous motor U.V.W jump out output

It controls the U.V.W jump out contactor of the permanent-magnet synchronous motor. When the synchronous motor is in power failure emergency self slide running, the brake opens, and U.V.W jump out outputs, which enable the lift self slide runs to the nearest leveling to stop. It reinforce the safety of the lift.

| Function code | Name                  | Default | Min. Unit | Setting range |
|---------------|-----------------------|---------|-----------|---------------|
| F7-04         | Y4 function selection | 00      | 1         | 06~99         |
| F7-05         | Y5 function selection | 00      | 1         | 06~99         |
| F7-06         | Y6function selection  | 06      | 1         | 06~99         |
| ⋮             | ⋮                     | ⋮       | ⋮         | ⋮             |

| Function code | Name                  | Default | Min. Unit | Setting range |
|---------------|-----------------------|---------|-----------|---------------|
| F7-23         | Y23function selection | 00      | 1         | 06-99         |

00: Not in use

06: Door 1 open door output

07: Door 1 close door output

08: Door2 open door output

09: Door2 close door output

10: Low 7 block code a display output

11: Low 7 block code b display output

12: Low 7 block code c display output

13: Low 7 block code d display output

14: Low 7 block code e display output

15: Low 7 block code f display output

16: Low 7 block code g display output

17: Up arrowhead display output

18: Down arrowhead display output

19: Minus display output

20: Fire to main landing signal output

21: Buzzer control output

22: Overloading output

23: Arrival gong output

24: Full load output

25: Inspection output

26: Illumination and fan output 2

27: Closed door contactor output

28: BCD, Gray, 7 segment code high bit output

29: Integrated normal running output

30~99: Reserved

**6.9 Group F8 Reinforce Function Parameters**

|              |                             |         |    |           |    |
|--------------|-----------------------------|---------|----|-----------|----|
| <b>F8-00</b> | <b>Weighing self-tuning</b> | Default | 0% | Min. Unit | 1% |
|              | Setting Range               | 0~100%  |    |           |    |

When NICE1000 elevator integrated controller uses analog weighing, it needs expansion card to be added.

It means the weighing self-tuning setting. There are three steps of the weighing self-tuning:

1. Ensure F8-01 setting is 0 and F8-08 chooses 2. This means that the system allow the weighing self- tuning.
2. Let lift stop at any floor, car is in non-load state, input F8-00 by setting 0,and press ENTER to input.
3. Put N% load into the car, set F8-00=n, and press ENTER to input. For example: put 100Kg heavy into lift of the rated load 1000Kg, and input F8-00=10.

After weighing self-tuning, the data of non-load and full load are written into F8-06 and F8-07.User can input data by hand based on the fact.

**Note: please accord to this order. Otherwise the weighing self-tuning is invalidation.**

|              |                                |         |   |           |   |
|--------------|--------------------------------|---------|---|-----------|---|
| <b>F8-01</b> | <b>Preset torque selection</b> | Default | 0 | Min. Unit | 1 |
|              | Setting Range                  | 0,1,2   |   |           |   |

0: Preset torque is invalidation, weighing self-tuning is allowable.

1: Torque bias is available.

When use preset torque bias function, the system can output torque with suited load, to assure comfortable feeling of the lift. But output torque is limited by Upper limit of torque(F2-08).When load torque is over the upper limit of torque setting, the system output torque is the upper limit of torque.

2: Count pre-torque automatically

When the lift is used in no-weighing state, it will count the pre-torque compensation automatically.

|              |   |                         |              |              |      |
|--------------|---|-------------------------|--------------|--------------|------|
| <b>F8-02</b> | <b>Preset torque bias</b><br>Zero servo current coefficient | Default                 | 50.0%<br>15% | Min.<br>Unit | 0.1% |
|              | Setting Range   | 0.0~100.0%<br>0.2- 50%  |              |              |      |
| <b>F8-03</b> | <b>Drive gain</b><br>Zero servo speed loop KP               | Default                 | 0.60<br>0.5  | Min.<br>Unit | 0.01 |
|              | Setting Range   | 0.00~2.00<br>0.00- 1.00 |              |              |      |
| <b>F8-04</b> | <b>Brake gain</b><br>Zero servo speed loop TI               | Default                 | 0.60<br>0.6  | Min.<br>Unit | 0.01 |
|              | Setting Range   | 0.00~2.00<br>0.00- 2.00 |              |              |      |

The first line of functions of the F8-02~F8-04 are applied in analog weighing to adjust the lift's starting.

If it is in full loading, the lift runs up, the motor is in drive running state; the lift runs down, the motor is in brake running state.

If it is in non-loading state, the lift runs up , the motor is in brake running state; the lift runs down, the motor is in drive running state.

The parameters for the pre-torque bias are actually the balance coefficient of the lift and it is also the percentage of the weight in the car and the rated weight when the car is in balance with the counterweight; Drive gain and brake gain are the pre-torque coefficients when the motor is in driving or brake running. The larger the compensation of the pre-torque in starting, the larger the gain will be in the same condition. The controller can identify the driving and brake state according to the signals of weight conductor, and then work out desirable torque compensation values.

When the system uses analog weighing, these group parameters are used for adjusting starting. Details of adjusting ways are as follows:

When motor is in driving state, if the lift rolls back when starts, increase F8-03; if the lift rushes to start, reduce F8-03.

When motor is in brake state, if the lift rolls back when starts, increase F8-04; if the lift rushes to start, reduce F8-04.

The second line of functions of the F8-02~F8-04 are applied in no-weighing state to adjust the lift's starting.

- a) Gradually add the 0 servo current coefficient (F8-02) value. When the brake is open make the back slide is small enough and the motor is not shaking. Please use the (FA-06) as reference to judge the back slide( 1024 stands for distance of 1 teeth back slide). Generally the condition of within 1 teeth ( 1 person ) is acceptable.
- b) If the motor is shaking when the 0 servo speed loop T1 is smaller than 1.00,please 0 servo current coefficient (F8-02)
- c) 0 servo speed loop KP(F8-03) can remain the same ,do not being too large, otherwise the motor may shaking

|              |                              |         |     |           |   |
|--------------|------------------------------|---------|-----|-----------|---|
| <b>F8-06</b> | <b>Car no load setting</b>   | Default | 0   | Min. Unit | 1 |
|              | Setting Range                | 0~1023  |     |           |   |
| <b>F8-07</b> | <b>Car full load setting</b> | Default | 100 | Min. Unit | 1 |
|              | Setting Range                | 0~1023  |     |           |   |

This group function codes can set the AD sampling value of analog when the car is in no load and full load condition.

Note: If F8-06=F8-07, full load and over load is invalidation.

|              |                                 |         |   |           |   |
|--------------|---------------------------------|---------|---|-----------|---|
| <b>F8-08</b> | <b>Weighing input selection</b> | Default | 0 | Min. Unit | 1 |
|              | Setting Range                   | 0,1,2   |   |           |   |

0: Invalidation

The lift doesn't use weighing compensation.

1: Reserved

2: Analog sampling

The lift uses analog weighing compensation.

|              |   |                |          |           |          |
|--------------|---|----------------|----------|-----------|----------|
| <b>F8-09</b> | <b>Power failure emergency rescue speed</b> | Default        | 0.050m/s | Min. Unit | 0.001m/s |
|              | Setting Range                               | 0.000~0.100m/s |          |           |          |

When the lift is in the emergency state, it will run to leveling position in the speed. Please note that the speed shouldn't be too high in the rescue course, or it may affect the normal work of UPS. The speed is determined by the power of UPS.

|              |   |   |   |           |   |
|--------------|---|---|---|-----------|---|
| <b>F8-10</b> | <b>Power failure emergency rescue speed</b> | Default   | 0 | Min. Unit | 1 |
|              | Setting Range                               | 0: Motor isn't running<br>1: UPS power running<br>2: 48V batter power |   |           |   |

NICE 1000 supplies three ways of emergency rescue methods, details are in chapter 7.

|              |   |              |       |           |       |
|--------------|---|--------------|-------|-----------|-------|
| <b>F8-11</b> | <b>Car stopping torque output delay</b> | Default      | 0.200 | Min. Unit | 0.001 |
|              | Setting Range                           | 0.200~1.500s |       |           |       |

After setting the commands of outputting brake close when the lift stops running, time for zero speed running depends on the brake.

### 6.10 Group F9 Time Parameters

|              |                                    |          |       |           |      |
|--------------|------------------------------------|----------|-------|-----------|------|
| <b>F9-00</b> | <b>Free return main floor time</b> | Default  | 10min | Min. Unit | 1min |
|              | Setting Range                      | 0~240min |       |           |      |

It can set the time of back to the main floor when it is free. When lift doesn't receive car call, hall call or any other commands, the lift will return to the main floor.

0: This function is invalid.

|              |                                 |          |      |           |      |
|--------------|---------------------------------|----------|------|-----------|------|
| <b>F9-01</b> | <b>Fan and light close time</b> | Default  | 2min | Min. Unit | 1min |
|              | Setting Range                   | 0~240min |      |           |      |

When lift is in automatic state, no run command, the system will cut off fan and light power after this setting time.

0: This function is invalid.

|              |  |         |     |           |    |
|--------------|--|---------|-----|-----------|----|
| <b>F9-02</b> | <b>Longest interval time of running in the floor</b> | Default | 45s | Min. Unit | 1s |
|              | Setting Range  | 0~45s   |     |           |    |

When lift running time is over the F9-02 setting time at border upon floors (There's no leveling signal then), lift will come into protection. When this parameter setting is less than 3s, this function is invalidation.

| Function code | Name                             | Setting Range | Default | Min. Unit |
|---------------|----------------------------------|---------------|---------|-----------|
| <b>F9-03</b>  | <b>Accumulative working time</b> | 0~65535h      | 0       | 1         |
| <b>F9-05</b>  | <b>RUN times high bit</b>        | 0~9999        | 0       | 1         |
| <b>F9-06</b>  | <b>RUN times low bit</b>         | 0~9999        | 0       | 1         |

They are total accumulative actual lift working time and running times. These function parameters are read only and user isn't allowed to change them. The lift's accumulative running time is precise by hour. Lift accumulative run times = run times high bit ×10000 + run times low bit.

### 6.11 Group FA Keyboard Setting Parameters

| Function code | Name              | Setting Range                           | Default | Min. Unit |
|---------------|-------------------|---|---------|-----------|
| <b>FA-00</b>  | Baud rate setting | 0~5:9600BPS<br>6:19200BPS<br>7:38400BPS | 5       | 1         |

FA-00 sets the baud rate of the serial communication. Setting 0~5 means choose 9600BPS; Setting 6 means choose 19200BPS; Setting 7 means choose 38400BPS.

|              |                    |         |       |           |   |
|--------------|--------------------|---------|-------|-----------|---|
| <b>FA-01</b> | <b>Run display</b> | Default | 65535 | Min. Unit | 1 |
|              | Setting Range      | 0~65535 |       |           |   |

This function code is made up of a binary number with 16 digits that display 16 kinds of running state parameters. Each parameter is controlled by one binary number, "1" expresses that display this parameter, "0" expresses that don't display this parameter. If want to display parameter as the following list, relevant binary number should be set as follows:

| Binary bit | Parameter        | Display or not | Binary bit setting | Binary bit | Parameter                  | Display or not | Binary bit setting |
|------------|------------------|----------------|--------------------|------------|----------------------------|----------------|--------------------|
| Bit0       | Running speed    | Display        | 1                  | Bit8       | Car load                   | Not display    | 0                  |
| Bit1       | Rated speed      | Display        | 1                  | Bit9       | System state               | Not display    | 0                  |
| Bit2       | Bus voltage      | Display        | 1                  | Bit10      | Pre-torque current (%)     | Not display    | 0                  |
| Bit3       | Output voltage   | Not display    | 0                  | Bit11      | State of input terminal 1  | Display        | 1                  |
| Bit4       | Output current   | Display        | 1                  | Bit12      | State of input terminal 2  | Not display    | 0                  |
| Bit5       | Output frequency | Display        | 1                  | Bit13      | State of input terminal 3  | Not display    | 0                  |
| Bit6       | Current floor    | Not display    | 0                  | Bit14      | State of output terminal 1 | Display        | 1                  |
| Bit7       | Current position | Not display    | 0                  | Bit15      | State of output terminal 2 | Not display    | 0                  |

The setting binary number is 010010000110111, the corresponding algorithm number is 18487, and FA-01 should be set as 18487. These displaying parameter can be switched by shift key in control keyboard.

|              |                     |         |       |           |   |
|--------------|---------------------|---------|-------|-----------|---|
| <b>FA-02</b> | <b>Stop display</b> | Default | 65535 | Min. Unit | 1 |
|              | Setting Range       | 0~65535 |       |           |   |

This function code is made up of binary numbers with 16 bit that displays 12 kinds of stopping state parameters. The displaying parameters can be switched by shift key on the control keyboard in the following list. The setting way is the same with FA-01.

|      |                                  |       |                            |
|------|----------------------------------|-------|----------------------------|
| Bit0 | Rated speed                      | Bit6  | System state               |
| Bit1 | Bus voltage                      | Bit7  | State of input terminal 1  |
| Bit2 | Current floor                    | Bit8  | State of input terminal 2  |
| Bit3 | Current position                 | Bit9  | State of input terminal 3  |
| Bit4 | Car load                         | Bit10 | State of output terminal 1 |
| Bit5 | Rated lift's decelerate distance | Bit11 | State of output terminal 2 |

The stopping and running parameters are useful and important reference for the technician when adjusting the lift. The specific meaning of each variable is described as follows:

Running speed: is the actual speed when the lift is running. It's the feedback speed of rotation encoder whose maximum value is the fasted speed (F0-03) of the lift, with the unit m/s.

Setting speed: is the speed of NICE1000 when it's running. It's gained by the theoretical calculations with the unit m/s.

Bus voltage: is the value of DC bus voltage with the unit V.

Output voltage: is the valid value of equivalent voltage when NICE1000 outputs PWM wave form, with the unit V.

Output current: is the valid value of the actual current when NICE1000 drive motor is running, with the unit A.

Output frequency: is the actual frequency when the motor is running with the unit Hz. This parameter is fixed corresponding with the running speed.

Current floor: the information for physic floor where the lift stays when it's running. Its content is the same with F4-01.

Current position: It reflects the absolute position of the car to the leveling plate of the first floor. The unit is M.

Car load: according to the information from the sensor, it's the percentage of car load to rated load, with the unit %.

Pre-torque current: It reflects the percentage of compensational pre-torque current to the rated current when the lift is starting, with the unit %.

State of input terminal 1: It shows the meaning of the terminals by bit. If the bit is "1", the signal is valid. There is 16 bit whose meanings are as follows:

| Binary bit | Meaning                        | Binary bit | Meaning                            |
|------------|--------------------------------|------------|------------------------------------|
| Bit0       | Reserved                       | Bit8       | Closed door output feedback signal |
| Bit1       | Leveling 1 signal              | Bit9       | Inspection signal                  |
| Bit2       | Leveling 2 signal              | Bit10      | Inspection up signal               |
| Bit3       | Door zone signal               | Bit11      | Inspection down signal             |
| Bit4       | Run output feedback signal     | Bit12      | Once fire signal                   |
| Bit5       | Brake output feedback 1 signal | Bit13      | Reserved                           |
| Bit6       | Brake output feedback 2 signal | Bit14      | Lock lift signal                   |
| Bit7       | U.V.W jump out feedback signal | Bit15      | Up limit signal                    |

State of input terminal 2: It shows the meaning of the terminals by bit. If the bit is "1", the signal is valid. There is 16 bit whose meanings are as follows:

| Binary bit | Meaning                              | Binary bit | Meaning                     |
|------------|--------------------------------------|------------|-----------------------------|
| Bit0       | Down limit signal                    | Bit8       | Door 1 close limit signal   |
| Bit1       | Up force reducer signal              | Bit9       | Door 2 close limit signal   |
| Bit2       | Down force reducer signal            | Bit10      | Door 1 light curtain signal |
| Bit3       | Over load signal                     | Bit11      | Door 2 light curtain signal |
| Bit4       | Full load signal                     | Bit12      | Motorman signal             |
| Bit5       | Urgent stop (safety feedback) signal | Bit13      | Direct arrival signal       |
| Bit6       | Door 1 open limit signal             | Bit14      | Direction changing signal   |
| Bit7       | Door 2 open limit signal             | Bit15      | Independent running signal  |

State of input terminal 3: It shows the meaning of the terminals by bit. If the bit is "1", the signal is valid. There is 16 bit whose meanings are as follows:

| Binary bit | Meaning                            | Binary bit | Meaning                                     |
|------------|------------------------------------|------------|---|
| Bit0       | Door 2 selection signal            | Bit8       | Reserved                                    |
| Bit1       | UPS input availability             | Bit9       | Safety circuit signal(AC 110V signal)       |
| Bit2       | Open button                        | Bit10      | Door lock circuit 1 signal(AC 110V signal)  |
| Bit3       | Close button                       | Bit11      | Door lock circuit 2 signal (AC 110V signal) |
| Bit4       | Safety circuit(DC 24V signal)      | Bit12      | Reserved                                    |
| Bit5       | Door lock circuit 1(DC 24v signal) | Bit13      | Reserved                                    |
| Bit6       | Door lock circuit 2(DC 24V signal) | Bit14      | Reserved                                    |
| Bit7       | Half-load signal                   | Bit15      | Reserved                                    |

State of output terminal 1: It shows the meaning of the terminals by bit. If the bit is "1", the signal is valid. There is 16 bit whose meanings are as follows:

| Binary bit | Meaning                                 | Binary bit | Meaning                             |
|------------|---|------------|-------------------------------------|
| Bit0       | Y0 output                               | Bit8       | Door2 open output                   |
| Bit1       | Running contactor output                | Bit9       | Door2 close output                  |
| Bit2       | Brake contactor output                  | Bit10      | Low 7 segment code a display output |
| Bit3       | Brake forced output                     | Bit11      | Low 7 segment code b display output |
| Bit4       | Illumination and fan output             | Bit12      | Low 7 segment code c display output |
| Bit5       | Synchronous motor U.V.W jump out output | Bit13      | Low 7 segment code d display output |
| Bit6       | Door1 open output                       | Bit14      | Low 7 segment code e display output |
| Bit7       | Door1 close output                      | Bit15      | Low 7 segment code f display output |

State of output terminal 2: It shows the meaning of the terminals by bit. If the bit is "1", the signal is valid. There is 16 bit whose meanings are as follows:

| Binary bit | Meaning                             | Binary bit | Meaning                                      |
|------------|-------------------------------------|------------|--|
| Bit0       | Low 7 segment code g display output | Bit8       | Full load output                             |
| Bit1       | Up arrowhead display output         | Bit9       | Inspection output                            |
| Bit2       | Down arrowhead display output       | Bit10      | Illumination and fan Output 2                |
| Bit3       | Minus display output                | Bit11      | Door lock jump out contactor output          |
| Bit4       | Fire to main landing signal output  | Bit12      | BCD, Gray code. 7 block code high bit output |
| Bit5       | Buzzer control output               | Bit13      | Integrated running normal output             |
| Bit6       | Over load output                    | Bit14      | Reserved                                     |
| Bit7       | Arrival gong output                 | Bit15      | Reserved                                     |

System state: It shows the meaning by bit. If the bit is "1", the signal is valid. There is 16 bit whose meanings are as follows:

| Binary bit | Meaning                                      | Binary bit | Meaning   |
|------------|--|------------|---|
| Bit0       | System light curtain state 1                 | Bit8       | Car state:<br>1: door open;<br>2: door open keeping;<br>3: door close<br>4: door open arrival<br>5: running |
| Bit1       | System light curtain state 2                 | Bit9       |   |
| Bit2       | Lock lift                                    | Bit10      |   |
| Bit3       | Fire   | Bit11      |   |
| Bit4       | Lift state:<br>0: inspection; 1:well         | Bit12      |   |
| Bit5       | self-learning;<br>3:fire arrival main floor; | Bit13      | System over load  |
| Bit6       | 4:firemen; 6: motorman ;                     | Bit14      | Reserved  |

| Binary bit | Meaning  | Binary bit | Meaning  |
|------------|----------|------------|----------|
| Bit7       | 7:normal | Bit15      | Reserved |

|              |  |            |      |           |      |
|--------------|--|------------|------|-----------|------|
| <b>FA-03</b> | <b>Pulse wheel encoder currently angle</b> | Default    | 0.0° | Min. Unit | 0.1° |
|              | Setting Range                              | 0.0~360.0° |      |           |      |

It displays the synchronous motor's current factual angle of the encoder. User cannot modify it.

| Function code | Name                            | Setting Range | Default | Min. Unit |
|---------------|---------------------------------|---------------|---------|-----------|
| <b>FA-04</b>  | <b>Software version (ZK) 2</b>  | 0~65535       | 0       | 1         |
| <b>FA-05</b>  | <b>Software version (DSP) 3</b> | 0~65535       | 0       | 1         |
| <b>FA-06</b>  | <b>Radiator temperature</b>     | 0~100℃        | 0       | 1℃        |

It displays the software edition NICE1000 is using. FA-06 displays radiator's current temperature.

### 6.12 Group FB Door Function Parameters

|              |                            |         |   |           |   |
|--------------|----------------------------|---------|---|-----------|---|
| <b>FB-00</b> | <b>door machine number</b> | Default | 1 | Min. Unit | 1 |
|              | Setting Range              | 1~2     |   |           |   |

It can set the number of door machine. User can set this function parameter by actual using number of door machine.

|              |                                    |         |   |           |   |
|--------------|------------------------------------|---------|---|-----------|---|
| <b>FB-01</b> | <b>Open-through door selection</b> | Default | 1 | Min. Unit | 1 |
|              | Setting Range                      | 0~3     |   |           |   |

The function can only be valid when the selection of FB-00 is 2.

0: Open-through door synchronous control (Open door, close door, call, button displays are totally the same.)

1: Call consistency, manual control open-through door (Door1 call and door 2 call are coincident, when arriving the destination, if both two doors can

operate, the switch of door1 and door 2 is controlled by the car button.)

2: Call independent, manual control open-through door (Door1 responds to door1's external call; door2 responds to door2's external call. When it arrives to the destination, if both two doors can operate, the switch of door1 and door 2 is controlled by the car button.)

3: Call independent, automatically control open-through door (In this condition, there must be two operation boxes separately corresponding to two doors. Door1 responds to door1's external call; door2 responds to door2's external call. When it arrives to the destination, if both two doors can operate, the switch of door1 and door2 is determined by their operation boxes.)

Details are listed in chapter 7.

|       |                                     |                        |      |           |   |
|-------|-------------------------------------|------------------------|------|-----------|---|
| FB-02 | <b>Door machine 1 service floor</b> | Default                | 1023 | Min. Unit | 1 |
|       | Setting Range                       | 0~1023(set 1~10 floor) |      |           |   |

This function code is made up of binary numbers with 10 emic that control those floors allowing door1 to open normally within floor 1 to floor 10. Every floor door is controlled by one binary number.

1: Relevant floor's front door can be open.

0: Forbidden relevant floor's front door open.

Its setting way is the same with F6-05; details are shown in section 6.7.

**Notice: this parameter shouldn't clash with F6-05 when user's setting! It's required to ensure that door machine's service floor is the system service floor.**

|        |   |         |   |    |
|--------|---|---------|---|----|
| FB- 03 | <b>Hand-pull door open arrival delay time</b> | Default | 5 | 1s |
|        | Setting range                                 | 1-60s   |   |    |

This function is valid when the hand-pull door function is active

|       |                            |                        |      |           |   |
|-------|----------------------------|------------------------|------|-----------|---|
| FB-04 | <b>Door2 service floor</b> | Default                | 1023 | Min. Unit | 1 |
|       | Setting Range              | 0~1023(set 1~10 floor) |      |           |   |

This function code is made up of binary numbers with 10 emic that control those floors allowing door2 to open normally within floor 1 to floor 10. Every floor door is controlled by one binary number.

1: Relevant floor’s back door can be open.

0: Forbidden relevant floor’s back door open.

Its setting way is the same with F6-05; details are shown in section 6.7. The function parameter can only be valid when the door number of FB-00 is 2.

|       |                                    |           |      |           |      |
|-------|------------------------------------|-----------|------|-----------|------|
| FB-05 | Back<br>-leveling<br>landing delay | Default   | 0.00 | Min. unit | 0.01 |
|       | Setting range                      | 0.00-2.00 |      |           |      |

|       |                                   |         |     |           |    |
|-------|-----------------------------------|---------|-----|-----------|----|
| FB-06 | <b>Open door time protection</b>  | Default | 10s | Min. Unit | 1s |
|       | Setting Range                     | 5~99s   |     |           |    |
| FB-08 | <b>Close door time protection</b> | Default | 15s | Min. Unit | 1s |
|       | Setting Range                     | 5~99s   |     |           |    |
| FB-09 | <b>Door open/close times</b>      | Default | 0   | Min. Unit | 1  |
|       | Setting Range                     | 0~20    |     |           |    |

The open/close door time protection means: When the system outputs open/close door command but doesn’t receive open/close door arrival feedback after the time of FB-06 and FB-08, the door machine turns to close/open door at once. This is once for door open and close. When it reaches the times FB-09 (open/close door times) setting of open/close door, the system will warn E48 door open error or E 49 door close error.

If FB=09=0, the open/close protection is invalid. The system will repeat the open(close) action.

|       |                           |         |   |           |   |
|-------|---------------------------|---------|---|-----------|---|
| FB-07 | Program control selection | Default | 0 | Min. unit | 1 |
|-------|---------------------------|---------|---|-----------|---|

|  |               |   |
|--|---------------|---|
|  | Setting range | Bit 0 reserved<br>Bit 1 reserved<br>Bit 2 reserved<br>Bit 3 reserved<br>Bit 4 landing 300MS current bias valid<br>Bit 5 reserved<br>Bit 6 reserved<br>Bit 7 reserved<br>Bit 8 no "close" output after close arrival just judge lock circuit 1<br>Bit 9 reserved<br>Bit 10 no "close" output when close arrival (no lock judgment) delay 1s<br>Bit 11 no "open " output when after open arrival and delay 1s<br>Bit 12 reserved<br>Bit 13 high/low voltage 1.5s inspection<br>Bit 14 reserved<br>Bit 15 reserved |
|--|---------------|---|

Applications of some special function:

**No "close door" output after close door arrival (no judgment of lock) delay 1s**

When FE-14 set to 1(no "close door "output after close door arrival) and also FB-07 BIT 10 set as 1,the lift close door arrival and delay for 1s then stop close output(no judgment about lock)

Attention: Only when set FE-14 BIT as 1,and the lift close arrival ( lock is active),stop close door output

**No "open door "output after open door arrival, delay 1s**

When FE-14 bit 1 set as 0: the function of open door arrival and hold opening is invalid. When set FB-07 as 1,the lift open door arrival and delay for 1s,then stop open signal output

**High/low voltage 1.5s inspection:** if (safety, lock 1, lock 2 ) high voltage and low voltage input signal's interval time longer than 1.5s,the input signal





output pre-warning signal.

| Function code | Name                         | Setting Range  | Default | Min. Unit |
|---------------|------------------------------|----------------|---------|-----------|
| FC-04         | The 1st error information    | 0~3199         | 0       | 1         |
| FC-05         | The 2nd error information    | 0~3199         | 0       | 1         |
| FC-06         | The 3rd error information    | 0~3199         | 0       | 1         |
| FC-07         | The 4th error information    | 0~3199         | 0       | 1         |
| FC-08         | The 5th error information    | 0~3199         | 0       | 1         |
| FC-09         | The latest error information | 0~3199         | 0       | 1         |
| FC-10         | The latest error speed       | 0.000~3.000m/s | 0.000   | 0.001m/s  |
| FC-11         | The latest error current     | 0.0~999.9A     | 0.0     | 0.1A      |
| FC-12         | The latest error bus voltage | 0~999V         | 0       | 1V        |

This group function codes can note the latest 6 times error code. The error information is made up of 4 bit, the higher 2 bit mean the car stopping floor when error occurs, and the lower 2 bit mean error code. For example: If the latest error information noted by FC-09 is 0135, it means that the latest error code is Err35 and the latest error floor is the first floor. FC-10~FC-12 record the outputting current, bus voltage and the current running speed when the latest error happens. The error's type and meaning refers to chapter 8.

**6.14 FD Group Reserved Parameters**

**6.15 FE Group Lift Function Setting Parameters**

|              |                                  |         |   |           |   |
|--------------|----------------------------------|---------|---|-----------|---|
| <b>FE-00</b> | <b>collective selective mode</b> | Default | 0 | Min. Unit | 1 |
|              | Setting Range                    | 0,1,2   |   |           |   |

0: Full selective, lift responds to up call and down call.

1: Down selective, lift only responds to hall down call and doesn't respond to hall up call.

2: Up selective, lift only responds to hall up call and doesn't respond to hall down call.

| Function code | Name                           | Setting Range | Min. Unit | Default |
|---------------|--------------------------------|---------------|-----------|---------|
| <b>FE-01</b>  | Floor 1 corresponding display  | 0000~1999     | 1         | 1901    |
| <b>FE-02</b>  | Floor 2 corresponding display  |               | 1         | 1902    |
| <b>FE-03</b>  | Floor 3 corresponding display  |               | 1         | 1903    |
| <b>FE-04</b>  | Floor 4 corresponding display  |               | 1         | 1904    |
| <b>FE-05</b>  | Floor 5 corresponding display  |               | 1         | 1905    |
| <b>FE-06</b>  | Floor 6 corresponding display  |               | 1         | 1906    |
| <b>FE-07</b>  | Floor 7 corresponding display  |               | 1         | 1907    |
| <b>FE-08</b>  | Floor 8 corresponding display  |               | 1         | 1908    |
| <b>FE-09</b>  | Floor 9 corresponding display  |               | 1         | 1909    |
| <b>FE-10</b>  | Floor 10 corresponding display |               | 1         | 0100    |

This group function code can set hall displaying content of the opposite floor. Its value is made up of 4 bit. The higher 2 bit express the tens digit of floor displaying, and the lower 2 bit express the first rank of floor displaying. The higher 2 bit's and lower 2 bit's meaning are as follows:

| Code | Display | Code | Display    |
|------|---------|------|------------|
| 00   | 0       | 06   | 6          |
| 01   | 1       | 07   | 7          |
| 02   | 2       | 08   | 8          |
| 03   | 3       | 09   | 9          |
| 04   | 4       | 18   | -          |
| 05   | 5       | 19   | No display |

For example:

| Actual floor | Required displaying | Higher 2 bit setting                 | Lower 2 bit setting          | Corresponding function code setting |
|--------------|---------------------|--------------------------------------|------------------------------|-------------------------------------|
| Basement 1   | -1                  | '-'<br>corresponding code 18         | '1'<br>corresponding code 01 | 1801                                |
| Floor 1      | 1                   | No display,<br>corresponding code 19 | '1'<br>corresponding code 01 | 1901                                |
| Floor 2      | 2                   | No display,                          | '2'                          | 1902                                |

| Actual floor | Required displaying | Higher 2 bit setting              | Lower 2 bit setting       | Corresponding function code setting |
|--------------|---------------------|-----------------------------------|---------------------------|-------------------------------------|
|              |                     | corresponding code 19             | corresponding code 02     |                                     |
| Floor 3      | 3                   | No display, corresponding code 19 | '3' corresponding code 03 | 1903                                |

|              |                                       |         |   |           |   |
|--------------|---------------------------------------|---------|---|-----------|---|
| <b>FE-12</b> | <b>External call output selection</b> | Default | 1 | Min. Unit | 1 |
|              | Setting Range                         | 0~3     |   |           |   |

0: 7 segment code

1: BCD code

2: Reserved

3: Binary bit code

It's set by the encoding way of external call display panel. The system default is BCD code. If select the 7 segment code, please set F7-14~F7-16 output as 7 segment code corresponding output.

|              |   |         |       |           |   |
|--------------|---|---------|-------|-----------|---|
| <b>FE-13</b> | <b>Lift factory function selection1</b> | Default | 33795 | Min. Unit | 1 |
|              | Setting Range                           | 0~65535 |       |           |   |
| <b>FE-14</b> | <b>Lift factory function selection2</b> | Default | 2080  | Min. Unit | 1 |
|              | Setting Range                           | 0~65535 |       |           |   |

These function codes set the lift factory required functions. Each function is controlled by one binary number,"1" expresses this function allowable,"0" expresses this function forbidden.

The keyboard operation of F3-13 and FE-14 is by the bit which is different from that of other function codes. These two parameters divide the digital tube into two parts. The first part is two digital tubes in the left indicating the current displaying bit, and the second part is a digital tube in the right indicating the value of the current displaying bit. Two tubes in the middle is

meaningless and no displaying. Press the right-moving key >> to choose the fourth or the fifth bit digital tube. Press the up or down key to change the bit needs checking or modifying. The first digital tube displays the current bit's state as 0 or 1 with the change of the bit. Meanwhile, press the right-moving key to the first bit digital tube, and press up or down key to change the state as 0 or 1. Then press Enter key to store current state to the current bit. Each changing of a bit needs storing, and after the storing, it will display the state of following bit as a default. Press down key when it displays the state of the first bit, or press up key or Enter key when it displays the state of the fifteenth bit, both operations will display the value of the function parameter.

The function of each bit of FE-13 is listed as follows:

| Binary bit | Function                                   | Binary bit | Function   |
|------------|--|------------|--|
| Bit0       | Reserved                                   | Bit8       | Manual control the opposite door in Inspection/ATT state |
| Bit1       | Attendant do not response to the hall call | Bit9       | Independent running                                      |
| Bit2       | Re-leveling                                | Bit10      | Inspection automatically close the door                  |
| Bit3       | Reserved                                   | Bit11      | Current floor call open                                  |
| Bit4       | Reserved                                   | Bit12      | Reserved   |
| Bit5       | reserved                                   | Bit13      | Emergency self slide running function                    |
| Bit6       | Open in non-door zone when inspecting      | Bit14      | Emergency self-rescue overtime protection                |
| Bit7       | Open once after inspection become normal   | Bit15      | Door lock short wiring examine function                  |

The function of each bit of FE-14 is listed as follows:

| Binary bit | Function         | Binary bit | Function   |
|------------|------------------|------------|--|
| Bit0       | Fast brake check | Bit8       | N.C output of synchronous motor U,V,W jump out contactor |

| Binary bit | Function   | Binary bit | Function   |
|------------|--|------------|--|
| Bit1       | Open door to the right position, keep open                 | Bit9       | Return leveling immediate stop                           |
| Bit2       | No close door during running                               | Bit10      | Reserved   |
| Bit3       | Hand-pull door selection                                   | Bit11      | No close door command when the lights in the car are off |
| Bit4       | Automatic reset of contact conglutination                  | Bit12      | Illumination and fan N.C. output                         |
| Bit5       | Forced decelerate switch conglutination test               | Bit13      | Fire back base floor normal running no output            |
| Bit6       | Synchronous motor U,V,W jump out contactor stops to output | Bit14      | Open time extension when no call                         |
| Bit7       | Reserved   | Bit15      | Reserved   |

In order to make it convenient for lift factories to do the value added setting, several functions of NICE 1000 is chosen through FE-13, FE-14. The functions mentioned above are described as follows:

**Attendant do not response to the hall call: the system do not response to the hall call in the ATT state, but inform the attendant by the inside floor lamp; no auto closing in ATT state.**

**Re-leveling:** in the condition of high floor or heavy- load lift, the car will higher (or lower) than the sill because of the sudden change of load. The lift will re-leveling in low speed when door open after select this function.

**Open in non-door zone :** when inspection: when lift under inspection, the door can automatically open by open button after select this function

**Open once after inspection become normal:** the door will automatically open/close once after the inspection is over and state is normal in the door zone.

**Manual control the opposite door in Inspection/ATT state :** this function

can be realized by the front/back door switching button

**Independent running:** It gets into the independent running condition through the independent running switch in the car cage. At the moment, the lift doesn't respond to the hall call and the door operation is the same with that in motorman condition, which means there's no automatic door closing and it opens the door automatically if it fails to complete closing the door. If it's in the parallel state, the system will get off the parallel automatically.

**Maintenance automatic close door:** When the machine room is in the maintenance operation, if the car cage's door isn't closed, it will cause the lift's door lock block and the lift can't travel. If choose this function, press UP and DOWN button, the lift will close the door automatically when it's in maintenance. There's no close door signal outputting if you don't press UP and DOWN button.

**Current floor inside call open function: the inside call can re-open the door in the normal state.**

**Emergency self slide running:** While it uses permanent-magnet synchronous motor, the lift can fulfill self slide running through the U,V,W jump-out contactor when there's power failure and it opens the door when it slides to the leveling position. This function enables the economical emergency rescue realize.

**Emergency self-rescue overtime protection:** If the car cage is in balance load or the rescue driving power's capacity is not adequate, it will cause long emergency rescue time and even dangers occur. This function enables to stop rescuing when self slide running rescue time is over 100s, and rescue driving time is over 50s.

**Door lock short wiring examine function:** If door lock jump-out is found after door open arrival, the system alarms E53 when the lift is running in normal condition.

**Open door to the right position, keep open:** If choose this function, the lift keep outputting open door signal when there's door opening arrival.

**Close door to the right position, no output door closing:** If choose this function, the lift doesn't output close door signal when it is running or close door to the right position.

**Contactors conglutination recover automatically:** Detect the brake, and

traveling contactors' feedback contacts, alarm E36, E37 if the contacts are deviant, and it can't recover automatically. If the two errors occur, this function enables to recover automatically no more than three times as long as these errors disappear.

**Force reducer switch conglutination inspection:** This function enables to monitor the force reducer switch all the time when the lift is running. If conglutination is detected, it's forced to deceleration.

**Open extension button when close the door :** the door can be re-open by open extension button when closing the door.

**Brake off delay when no running command after starting**

**Return leveling immediate stop:** immediate stop when receive the door zone signal in return leveling state

**Synchronous motor enclosed star contactor outputs when it stops:** Synchronous motor KFX can assure that there won't be fast speed slide running even when the brake doesn't work. Under this function, NICE 1000 output terminal selection 05 (synchronous motor U,V,W jump-out output) can output in self-motion when the lift stops. If choose the feedback contact input (some function codes set as 07 or 107 in function codes F5-01~F5-24), NICE 1000 will monitor the KFX feedback contact in the application of synchronous motor, and alarm E29 if anything deviant occur.

**N.C. of synchronous motor KFX:** In synchronous motor, synchronous motor KFX control usually adapt N.C. switch.

**P.S. KFX stands for the U,V,W jump-out contactor**

**No close door command when the lights in the car are off:** It stops outputting close door command when the lights in the car are off.

**Fire back to base floor normal running no output: the lift normal function off when fire back to the base floor.**

**Open time extension when no call: the system will keep open as set extension time when no call command.**

**6.16 Group FE Factory Parameters (Reserved)**

**6.17 Group FP User Parameters**

|              |                      |         |   |           |   |
|--------------|----------------------|---------|---|-----------|---|
| <b>FP-00</b> | <b>User password</b> | Default | 0 | Min. Unit | 1 |
|              | Setting Range        | 0~65535 |   |           |   |

Set any number but zero, the password protection function is valid.

00000: Clear the password value setting by previous user, and make the password protection function invalid.

After the user password is set and become valid, when it gets into the parameter setting state, you can't check or modify the parameters if the password is not correct. Details of password setting measures are listed in chapter 4.

Please firmly remember your setting password, and contact with the factory if you miss-set or forget.

|              |                            |         |   |           |   |
|--------------|----------------------------|---------|---|-----------|---|
| <b>FP-01</b> | <b>Parameter resetting</b> | Default | 0 | Min. Unit | 1 |
|              | Setting Range              | 0,1,2   |   |           |   |

0: None;

1: Return to factory parameters. All the values of other function parameters but motor parameter, floor parameter and error record parameter, will return to factory parameters. Please operate with caution!

2: Clear memory parameter. It will clear all the recorded error information.



## Typical system application & adjusting

---

## Chapter Typical system application & adjusting

### 7.1 Elevator adjusting



**When the lift is in adjusting state, please keep smooth in shaft, and pay attention to the safety of workers.**

In order to be convenient for adjusting, this chapter was written according to the normal sequence of lift adjustment. When the periphery circuit and machine installed are finished completely, you can finish the elevator's basic adjustment.




Fig. 7-1 adjusting process

## 7.2 System typical application

### 7.2.1 Full selection typical application

- 1) Terminal connection sketch of main door control board and setting parameters




Fig. 7-2 Main control board terminal connection sketch

According to the connection mode of above graph, the terminal input/output and floor input /output are default parameters.

**7.2.2 Up selection typical application**

- 1) Terminal connection sketch of main control board and setting parameter.




Fig. 7-3 Up selection terminal connection sketch

When the NICE adopts to up selection, it can get to the eighth floor if having no expansion board, or it can get to tenth floor with it. The above graph is an example which doesn't have expansion board. Button input and output connection is accordant to figure 7-2. It mostly changes the input/output connection floor button. You can revise the corresponding function code according to the very requirement, and detailed information is listed below.

| Function code | default | modified | Function code | default | modified |
|---------------|---------|----------|---------------|---------|----------|
| F6-15         | 211     | 211      | F6-23         | 221     | 221      |
| F6-16         | 212     | 212      | F6-24         | 222     | 232      |
| F6-17         | 213     | 213      | F6-25         | 223     | 233      |
| F6-18         | 214     | 214      | F6-26         | 224     | 234      |
| F6-19         | 215     | 215      | F6-27         | 232     | 235      |
| F6-20         | 00      | 216      | F6-28         | 233     | 236      |
| F6-21         | 00      | 217      | F6-29         | 234     | 237      |
| F6-22         | 00      | 218      | F6-30         | 235     | 238      |
| FE-00         | 0       | 1        | F6-00         | 5       | 8        |

User can reduce the button input/output terminal connection by the actual floor NO. It is valid when the door operator NO. is 2.

**7.2.3 Open-through door typical application**

- 1) Open-through door recommending connection drawing of main control board and relevant parameter setting.



| Function code | Default | Modified | Function code | Default | Modified |
|---------------|---------|----------|---------------|---------|----------|
| F6-19         | 215     | 312      | F6-29         | 234     | 332      |
| F6-20         | 00      | 313      | F6-30         | 235     | 333      |
| F6-00         | 5       | 3        |               |         |          |
| FB-00         | 1       | 2        | FB-01         | 0       | 1, 2     |

Users can add floor button input and output connection by reducing the number of open-through doors. It only can be used when there are two mainframes.

2) Setting the function selection of the open-through door

NICE1000 open-through door's function contains 3 kinds of practice-model, get set via FB-01.

| FB-01 | Meanings   | Instruction of wire connection  |
|-------|--|---|
| 0     | The operation of open-through door is consistent. All the response is the same. It contains internal call, external call open the door. Close the door about Door 1 and Door 2. Open-close door's operation is the same too.   | The calling button or the open-close door button of Door 1 and Door 2 in the same floor can be joined, and it connects to the input-output terminal in the same floor. And it could increase the running max floor.   |
| 1     | The response of Door 1 and Door 2 call is the same. After getting to the destination floor, system would select opening which door by input state of Door 2 selects signal. If input high level signal, the lift would open the Door 2, contrarily, the lift will open the Door 1. This signal would connect to the car's button, and the people inside the car will control it. | The external calling button or the open-close door button of Door 1 and Door 2 in the same floor can be joined, and it connects to the input-output terminal in the same floor. And it could increase the running max floor. If you choose this way, the x-input terminal needs to select the Door 2 selection-signal's function. Otherwise, the lift only can open the Door. |
| 2     | The response of Door 1 outside hall call is independence. After getting to the destination floor. System would select opening which the door by input state of Door 2 selects signal. If input high level  | The external hall calling button of Door 1 or Door 2 in the same floor can connect to the input-output terminal in the different floors. If you choose this way, the X-input terminal   |

| FB-01 | Meanings  | Instruction of wire connection   |
|-------|---|--|
|       | signal, the lift would open the Door 2, contrarily, the lift will open the Door 1. This signal would connect to the car's button, and the people inside the car will control it.                                | needs to select the Door 2 selection-signal's button. Otherwise, the lift only can open Door 1.  |
| 3     | The response of Door 1 and Door 2 outside hall call is independence. After getting to destination floor. System would automatically select opening which door by this response is Door 1 inside call of Door 2. | The external-car and internal-car's calling button of Door 1 and Door 2 should connect to the input-output terminal respectively in the different floors. Otherwise, the lift may open the Door 1 and Door 2 at the same time. |

#### 7.2.4 Power failure emergency running typical application

NICE1000 power failure emergency running contains 3 kinds of model:

##### Auto-slide :

It means that opening the brake, and the prevent-force limits the car's running by permanent-magnet synchronous motor jumps out stator coil. That is a rescue-way's which the car is running slowly to get to the level. After the Nice 1000 receives a power-failure-rescue signal, u should jump the U, V, W's wire of permanent-magnet synchronous motor, and open brake. The lift would auto-slide. During the process you should monitor the lift's speed, till leveling. When the speed is slowly.(The car is balance load or the load variation's number is small) u can close braking, and stop operation.

##### 48V battery supply of power to run:

The main circuit of NICE1000 has adopted 48V battery supply of power. The power of other part would adopt UPS supply which is greater than 220V. Do it, the motor can run normally by store battery's power, and the work power's capacity will be small. After NICE1000 chooses the way which is power failure rescue, it would run with emergency speed (F8-09). The direction is the same to the running direction of lift light-load. Keep surveillance the speed of elevator in this period, and then output the passenger and stop running.

##### UPS supply of power:


Both the main circuit and work-power of Nice 1000 have adopted UPS power to power failure emergency run. After NICE1000 chooses the way of power failure rescue, it would run by emergency speed, the direction is the same to run direction of lift light-load run. When detecting signal, it will open the door and stop working.

You can see their characteristic via the following Fig.:


| Mode                               | Motor power source                                   | Working-power of NICE1000                              | Working-power of the lift's safety circuit             | Range  | Other  |
|------------------------------------|--|--|--|--|--|
| <b>Auto-slide car</b>              | Permanent-magnet synchronous motor jumps stator coil | Using the UPS which is greater than 220V (or inverter) | Using the UPS which is greater than 220V (or inverter) | Permanent-magnet synchronous motor                 | Need self-locking contact or to jump out U,V,W |
| <b>UPS supply of power</b>         | 220V UPS applies of power                            | 220V UPS applies of power                              | 220V UPS applies of power                              | Permanent-magnet synchronous or asynchronous motor |  |
| <b>48V battery supply of power</b> | 48V store battery                                    | Using the UPS which is greater than 220V(or inverter)  | Using the UPS which is greater than 220V(or inverter)  | Permanent-magnet synchronous or asynchronous motor |  |

We mainly introduce typical application of auto-running by the following Fig.. If use other way (include rescue automatically switch). You can contact with us MNK.

- 1) Self-slide emergency running sketch



a) Main circuit wiring diagram



b) UPS power circuit diagram




Fig. 7-5 power failure emergency system

c) main control board wiring diagram

Instruction of above graph: 1)-3), JYX is the output wiring contactor; JYJ is the star-closure contactor of synchronous motor; JUP is power failure rescue run manual switch; JAQ is safety signal. In this case, UPS will supply power to door operation, safety circuit, brake and so on.

2) Instruction of power failure emergency run

a) Time sequence diagram




Fig. 7-6 self-running time sequence

b) Function code setting

According to 7-5 wiring diagram, the NICE1000 auto-slide power failure emergency run need set the following parameter:


| Function code | Default | Modified                | Function code | Default | modified |
|---------------|---------|-------------------------|---------------|---------|----------|
| F5-19         | 00      | 33                      | F7-00         | 00      | 32       |
| FE-13         | 33792   | 41984<br>Bit13 is set 1 |               |         |          |

c) Attention items

- During the auto-slide, the NICE1000 can't control the motor drive, the power of life auto-running is come from self-supply power of synchronous motor;
- During the auto-slide, if the lift's speed is more than 1/2 rated speed, the NICE1000 will adopt alarm protect (E33), don't be controlled by auto-running, and at the same time the jump contactor of synchronous motor maybe get abnormality;

- This way is only applied to synchronous motor, and never be applied to asynchronous motor, otherwise, it will be very dangerous;
  - This way need some gap between load in the car and load of lift balance; otherwise, the lift run-speed will be slow.
- d) Manual switching way

Normality, the KUP should have disconnected. When the UPS is charging, the system's power comes from main power supply. When the main power is cut, user can control system emergency by KUP, and the KUP is close, UPS power is supplied to system power. When NICE1000 receives the UPS input signal, and make sure the mode is power failure emergency run, close Y0, then open brake, the lift will auto-running; at the same time monitor lift speed, till leveling.



## Faults – Causes - Remedies

---

## Chapter 8 Faults – Causes - Remedies

### 8.1 Fault Classification

The system controller has almost 60 pieces of alarm information or protection functions. NICE1000 monitors all kinds of input signal, running condition, exterior feedback information. If some abnormal error happens, relevant fault protection functions will act and the system controller will display the fault code.

Error information produced by NICE1000 can be divided into 5 sorts according to their influence to the system. Different fault has different disposal mode. And the respective relationship is listed as the following table:

| Fault sort    | Relevant disposal  | Remark   |
|---------------|--|--|
| Level 1       | Display fault code   | Any kind of working condition will not be influenced.                  |
| Level 2       | Display fault code;<br>Sever lift group control (parallel) system;   | Can operate normal running.  |
| Level 3       | Display fault code;<br>Stop at the nearest landing when in distance control, then stop running;<br>Stop running at once in other work condition.   | After stop, the system will close off output at once, and close brake. |
| Level 4       | Display fault code;<br>When in distance control, the system will close off output at once and close brake; after stop, low speed running (such as return leveling, inspection) is allowed. | The elevator can run in low speed in condition of fault code.          |
| Level 5 fault | Express fault code;  | Running forbidden.   |

| Fault sort | Relevant disposal  | Remark |
|------------|--|--------|
|            | The system blank off output at once, and close brake;<br>Running forbidden |        |

### 8.2 Fault details & Remedies

If fault alarm information appears, the system will dispose by their fault code. At this time, user can analyze fault on basis of suggestive information in this chapter, to spy fault cause, and find out remedies

| Operate panel display | Digital tube display | Fault description        | Probable cause  | Remedy   | Sort |
|-----------------------|----------------------|--------------------------|---|--|------|
| Err01                 | E01                  | Invert unit protection   | 1.Main circuit output is grounding or short wiring;<br>2.The connection of traction machine is too long;<br>3.Work condition is too hot;<br>4.The connections inside the controller become loose; | 1.Obviate exterior problems such as connection;<br>2.Add reactor or output filter;<br>3.Inspect the wind channel and fan;<br>4.Please contact with agent or factory; | 5    |
| Err02                 | E02                  | Accelerated over-current | 1.Main circuit output is grounding or short wiring;<br>2.If the motor has done parameter tuning of not;<br>3.Load is too heavy;   | 1.Obviate exterior problems such as connection;<br>2.Motor parameter tuning;<br>3.Lighten sudden adding load;  | 5    |
| Err03                 | E03                  | Decelerated over-        | 1.Main circuit output is grounding or short   | 1.Obviate exterior problems such as  | 5    |

| Operate panel display | Digital tube display | Fault description           | Probable cause   | Remedy  | Sort |
|-----------------------|----------------------|-----------------------------|--|---|------|
|                       |                      | current                     | wiring;<br>2.If the motor has done parameter tuning of not;<br>3.Load is too heavy;<br>4.Decelerate curve is too steep;  | connection;<br>2.Motor parameter tuning;<br>3.Lighten sudden adding load;<br>4.Adjust the curve parameter;  |      |
| Err04                 | E04                  | Constant speed over-current | 1.Main circuit output is grounding or short wiring;<br>2.If the motor has done parameter tuning of not;<br>3.Load is too heavy;<br>4.Pulse wheel encoder interference is too strong; | 1.Obviate exterior problems such as connection;<br>2.Motor parameter tuning;<br>3.Lighten sudden adding load;<br>4.Select proper encoder, and adopt shielded cable; | 5    |
| Err05                 | E05                  | Accelerated over-voltage    | 1.Input voltage is too high;<br>2.Lift inverse pull is serious;<br>3.Brake resistance is too much, or brake unit is abnormal;<br>4.Accelerate curve is too steep;                    | 1.Adjust input voltage;<br>2.Adjust the elevator startup time sequence;<br>3.Select proper brake resistance;<br>4.Adjust curve parameter;                           | 5    |
| Err06                 | E06                  | Deceleration over-volt      | 1.Input voltage is too high;   | 1.Adjust input voltage;<br>2.Select proper brake  | 5    |

| Operate panel display | Digital tube display | Fault description           | Probable cause   | Remedy  | Sort |
|-----------------------|----------------------|-----------------------------|--|---|------|
|                       |                      | age                         | 2.Brake resistance is too much, or brake unit is abnormal;<br>3.Accelerate curve is too steep;     | resistance;<br>3.Adjust curve parameter;  |      |
| Err07                 | E07                  | Constant speed over-voltage | 1.Input voltage is too high;<br>2.Brake resistance is too much, or brake unit is abnormal;         | 1.Adjust input voltage;<br>2.Select proper brake resistance;                    | 5    |
| Err08                 | E08                  | Controller power fault      | 1.Input voltage is too high;<br>2.Drive control panel is abnormal;                                 | 1.Adjust input voltage;<br>2.Please contact with agent or factory;              | 3    |
| Err09                 | E09                  | Under-voltage fault         | 1.Transient power cut exists;<br>2.Input voltage is too low;<br>3.Drive control panel is abnormal; | 1.Obviate exterior problem of power;<br>2.Please contact with agent or factory; | 5    |
| Err 10                | E10                  | System overload             | 1.Brake circuit is abnormal;<br>2.Load is too heavy;   | 1.Inspect brake loop and power supply;<br>1.Lighten load;                       | 4    |
| Err 11                | E11                  | Motor overload              | 1.FC-02 setting is unsuitable;<br>2.Brake loop is abnormal;<br>3.Load is too heavy;                | 1.Adjust parameter;<br>2.Inspect brake loop and power supply;                   | 3    |

| Operate panel display | Digital tube display | Fault description         | Probable cause  | Remedy   | Sort |
|-----------------------|----------------------|---------------------------|---|--|------|
| Err 12                | E12                  | Input side phase failure  | 1.Input power asymmetry;<br>2.Diver control panel is abnormal;  | 1.Adjust input power;<br>2.Please contact with agent or factory;   | 4    |
| Err 13                | E13                  | Output side phase failure | 1.The connections of main circuit output become loose;<br>2.Motor is broken;  | 1.Inspect connection;<br>2.Obviate motor fault;  | 4    |
| Err 14                | E14                  | Module overheat ed        | 1.The temperature of working environment is too high;<br>2.The fan is broken;<br>3.The wind channel is blocked;     | 1.Reduce the environmental temperature;<br>2.Clear the wind channel;<br>3.Change the fan;  | 5    |
| Err 17                | E17                  | Contacto r fault          | 1.Bus voltage is abnormal;<br>2.Drive control panel is abnormal;  | Please contact with agent or factory;  | 5    |
| Err 18                | E18                  | Current detectio n fault  | Diver control panel is abnormal;  | Please contact with agent or factory;  | 5    |
| Err 19                | E19                  | Motor tuning fault        | 1.Motor parameter setting is wrong;<br>2.Parameter tuning is overtime;<br>3.Synchronous rotate encoder is abnormal; | 1.Input the right motor parameter;<br>2.Detect motor lead wire;<br>3.Detect the rotate encoder wiring, and make sure the pulse number per round is | 5    |

| Operate panel display | Digital tube display | Fault description                                  | Probable cause  | Remedy  | Sort |
|-----------------------|----------------------|--|---|---|------|
|                       |                      |  |   | well set.   |      |
| Err 20                | E20                  | Rotary encoder fault                               | 1.Rotary encoder model is suited or not;<br>2.Encoder connection error; | 1 .Asynchronous motor can select push-pull output or open-collector encoders; synchronous motor can select UVW or SIN/COS.<br>2.Obviate connection problem; | 5    |
| Err 21                | E21                  | Synchronous encoder wiring fault                   | Error occurs to the wiring of synchronous encoder;                      | Please detect the wiring;   | 5    |
| Err 22                | E22                  | Leveling and door area signal conglutination fault | Leveling/door area signal is conglutination or cut off;                 | Please detect the leveling/door area inductor and main control panel input point.   | 1    |
| Err 23                | E23                  | Short circuit fault to ground                      | Output short circuit to ground;   | Please contact with agent or factory;   | 5    |
| Err 25                | E25                  | Stored data abnormality                            | The stored data of main control panel is abnormal;                      | Please contact with agent or factory;   | 5    |

| Operate panel display | Digital tube display | Fault description   | Probable cause  | Remedy  | Sort |
|-----------------------|----------------------|---|---|---|------|
| Err 29                | E29                  | Synchronous U,V,W jump out contactor feedback abnormality | The feedback of synchronous U,V,W jump out contactor is abnormal;   | Detect relevant wiring;   | 5    |
| Err 30                | E30                  | Elevator position abnormality                             | <p>1.Encoder feedback position deviation when lift is automatic running;</p> <p>2.Levelling signal is cut or conglutinate when lift is automatic running;</p> <p>3.Steel wire skid or motor locked-rotor;</p> | <p>1.Detect leveling inductor and flashboard;</p> <p>2.Detect leveling signal wire connecting;</p> <p>3.Ensure encoder is used right;</p>                               | 4    |
| Err 33                | E33                  | Lift speed abnormality                                    | <p>1.Actual speed is 15% over the highest running speed;</p> <p>2.Low speed running is 20% over the setting speed;</p> <p>3. Inspection switch acts when lift automatic running;</p>                          | <p>1.Ensure encoder is used right;</p> <p>2.Detect motor nameplate parameter setting;</p> <p>3.Retune motor;</p> <p>4.Detect the inspection switch and signal wire;</p> | 4    |

| Operate panel display | Digital tube display | Fault description                  | Probable cause  | Remedy  | Sort |
|-----------------------|----------------------|------------------------------------|---|---|------|
| Err 34                | E34                  | Logic fault                        | The control panel redundancy judge, logic fault.  | Please contact with agent or factory to replace control panel.  | 5    |
| Err 35                | E35                  | Shaft self-tuning data abnormality | 1.The startup place is not the lowest floor;<br>2.Continuous run time is more than 45 seconds without signal input;<br>3.The interval of floors is too short;<br>4.The highest metrical floor is different with the setting value;<br>5.The floor pulse record is abnormal;<br>6.When in self-tuning, the system is not in examine state; | 1.Ensure up/down force reducer switch and signal;<br>2.Detect leveling inductor and flashboard setting;<br>3.Detect leveling signal wire connecting;<br>4.Make sure that the system is in examining state.<br>5.Carry through shaft self-tuning again when lift reaches the lowest floor; | 4    |
| Err 36                | E36                  | Contact feedback abnormality       | 1.Running contactor is not pulled in when the brake is open;<br>2.When lift continuously runs over 1 second, the contact feedback signal is lost;   | 1.Detect contactor and feedback contact;<br>2.Detect that the controller output wire U,V,W is natural or not;<br>3.Detect that the circuit power of contact controlling is  | 5    |

| Operate panel display | Digital tube display | Fault description                          | Probable cause  | Remedy   | Sort |
|-----------------------|----------------------|--|---|--|------|
|                       |                      |  | <p>3.The contactor feedback signal conglutinates;</p> <p>4.No feedback signal after the contact closed;</p>   | natural or not;  |      |
| Err 37                | E37                  | Brake feedback abnormally                  | The brake output is not consistent with the feedback signal.  | <p>1.Detect that the brake coil and feedback contact;</p> <p>2.Notarize the signal character of the feedback contact (N.O. or N.C.);</p> <p>3.Detect that the circuit power of brake coil controlling is natural or not;</p> | 5    |
| Err 38                | E38                  | Controller rotary encode signal abnormally | <p>1.No input encode pulse when lift is automatic running;</p> <p>2.The direction of input encode signal is wrong when lift is automatic running;</p> <p>3.Set to open-loop (F0-00) when in distance control;</p> | <p>1.Ensure encoder using right;</p> <p>2.Replce encoder's A,B phase;</p> <p>3.Detect the setting of F0-00, and change to close-loop control;</p>  | 5    |
| Err 40                | E40                  | Lift run overtime                          | The setting time of lift running is up.   | <p>1.Lift speed is too low or the floor is too high;</p> <p>2.The lift is used for a</p>   | 4    |

| Operate panel display | Digital tube display | Fault description                | Probable cause  | Remedy  | Sort |
|-----------------------|----------------------|----------------------------------|---|---|------|
|                       |                      |                                  |   | long time and needs maintenance;  |      |
| Err 41                | E41                  | Safety circuit off               | The signal of safety circuit is cut.                                    | 1.Detect safety circuit, and look over its state;<br>2.Detect that exterior power supply is natural or not;   | 5    |
| Err 42                | E42                  | Door lock cut in running         | The door lock feedback is cut when lift is running.                     | Detect that the door lock contact is natural or not.  | 5    |
| Err 43                | E43                  | Up limit signal off in running   | The signal of up limit is cut when lift is up running.                  | Detect that the up limit switch contact is natural or not.  | 4    |
| Err 44                | E44                  | Down limit signal off in running | The signal of down limit is cut when lift is down running.              | Detect that the down limit switch contact is natural or not.  | 4    |
| Err 45                | E45                  | Up/Down slowdown switch off      | Up and down slowdown switch is cut at one time when the elevator stops. | 1.Detect 1st up/down slowdown switch;<br>2. Ensure 1st up/down slowdown signal characteristic (N.O. or N.C.); | 4    |
| Err 46                | E46                  | Re-leveling abnormality          | 1.The speed of re-leveling is over 0.1m/s;<br>2.Re-leveling             | 1.Detect the primary , secondary circuit connection of lock relay.  | 1    |

| Operate panel display | Digital tube display | Fault description                           | Probable cause   | Remedy  | Sort |
|-----------------------|----------------------|---|--|---|------|
|                       |                      |   | position is not in the leveling area;<br><br>3.The door lock feedback is abnormal when in running. | 2.Detect that the door lock feedback function is selected or not, and signal is natural or not;<br><br>2.Ensure the rotary encoder is used right; |      |
| Err 47                | E47                  | Door lock jump out contactor conglutination | Contactors are conglutinated when having advance open door and re-leveling.                        | Detect door lock jump out contactor   | 5    |
| Err 48                | E48                  | Door open fault                             | The door continuous non-arrival open times are over the setting value of FB-09.                    | 1.Detect that the door machine is working natural or not;<br><br>2.Detect the car top control panel is right or not;                              | 5    |
| Err 49                | E49                  | Door close fault                            | The door continuous non-arrival close times are over the setting value of FB-09.                   | 1.Detect that the door machine is working natural or not;<br><br>2.Detect that the car top control panel is right or not;                         | 5    |
| Err 53                | E53                  | Lock jump fault                             | When in automatic running state, the stop has no door lock cut process;                            | Detect the lock signal circuit.   | 4    |