

**Instruction Bulletin**

**50006-360-02B**

**May, 1995**

Replaces 50006-360-02A dated 1/94

**ALTIVAR™ 16**

## **Display / Adjustment Options**

**VW3-A16101, VW3-A16102,  
VW3-A16103**

**for ALTIVAR 16 Drive Controllers**

## NOTE

On earlier models, the DC bus terminals, designated J8- and J9+ in the Bus Voltage Measurement Procedure, are designated as follows:

| Catalog No. | J8-  | J9+  |
|-------------|------|------|
| ATV16U09M2  | J211 | J212 |
| ATV16U18M2  |      |      |
| ATV16U29M2  | J104 | J105 |
| ATV16U18N4  |      |      |
| ATV16U29N4  |      |      |
| ATV16U41M2  | J110 | J112 |
| ATV16U41N4  |      |      |
| ATV16U54N4  |      |      |
| ATV16U72N4  |      |      |

### Revision Notice

Display/Adjustment Options manufactured after March, 1994 (date code 9414) have the addition of the **LF<sub>r</sub>** parameter as described in this manual.

### Trademark Notice

**ALTIAR**™ is a trademark of Square D.

### Copyright Notice

© 1994 Square D. All rights reserved. This document may not be copied in whole or in part, or transferred to any other media, without the written permission of Square D.

### Please Note

Electrical equipment should be serviced only by qualified electrical maintenance personnel, and this document should not be viewed as sufficient instruction for those who are not otherwise qualified to operate, service or maintain the equipment discussed. Although reasonable care has been taken to provide accurate and authoritative information in this document, no responsibility is assumed by Square D for any consequences arising out of the use of this material.

|   |    |
|---|----|
| Introduction .....  | 1  |
| VW3-A16101 .....  | 1  |
| VW3-A16102 .....  | 2  |
| VW3-A16103 .....  | 2  |
| Mounting .....  | 3  |
| Local .....   | 3  |
| Remote .....  | 4  |
| Parameter Summary .....                                   | 5  |
| Switch Settings .....                                     | 6  |
| Switch 1 (VW3-A16102 Only) .....                          | 6  |
| Switch 2 (VW3-A16101 and VW3-A16102) .....                | 6  |
| Operation of the Push Buttons .....                       | 8  |
| Set-up Mode .....   | 9  |
| Adjustment Lockout Mode .....                             | 10 |
| Configuration Parameters .....                            | 10 |
| <i>UnS</i> : Nominal Motor Voltage .....                  | 10 |
| <i>FrS</i> : Nominal Motor Frequency .....                | 10 |
| <i>fFr</i> : Maximum Drive Output Frequency .....         | 11 |
| <i>UFt</i> : Type of Volts/Frequency Ratio .....          | 11 |
| <i>brR</i> : Deceleration Ramp Adaptation .....           | 12 |
| <i>SLP</i> : Automatic Slip Compensation .....            | 12 |
| <i>StE</i> : Start/Stop in Adjustment Lockout Mode .....  | 13 |
| <i>StS</i> : Start/Stop in Set-up Mode .....              | 13 |
| <i>rES</i> : Reset Fault .....                            | 13 |
| Adjustment Parameters .....                               | 14 |
| <i>Rcc</i> : Acceleration Ramp Time .....                 | 14 |
| <i>dEc</i> : Deceleration Ramp Time .....                 | 14 |
| <i>LSP</i> : Low Speed .....                              | 15 |
| <i>HSP</i> : High Speed .....                             | 15 |
| <i>UFr</i> : Volts/Frequency Ratio .....                  | 15 |
| <i>FLG</i> : Frequency Loop Gain .....                    | 16 |
| <i>Ith</i> : Motor Thermal Protection .....               | 16 |
| <i>LFr</i> : Reference Frequency in Hz .....              | 17 |
| Display Parameters .....                                  | 17 |
| Additional Parameters .....                               | 18 |
| VW3-A16201 Option Card set for General Use .....          | 18 |
| VW3-A16201 Option Card Set for Material Handling .....    | 19 |
| VW3-A16202 Variable Torque Option Card .....              | 21 |
| VW3-A16203 High Speed Motor Option Card .....             | 22 |
| VW3-A16204 General Use / 3-Wire Control Option Card ..... | 23 |
| Operation Assistance .....                                | 24 |
| Procedure 1: Checking Supply Voltage .....                | 24 |
| Bus Voltage Measurement Procedure .....                   | 25 |
| Procedure 2: Checking the Peripheral Equipment .....      | 26 |
| Fault Codes .....   | 27 |

**List of Figures**

|           |  |    |
|-----------|--|----|
| Figure 1  | Display/Adjustment Option VW3-A16101 .....               | 1  |
| Figure 2  | Display/Adjustment/Local Control Option VW3-A16102 ..... | 2  |
| Figure 3  | Mounting Option VW3-A16101 or VW3-A16102 .....           | 3  |
| Figure 4  | Remote Mounting with Kit VW3-A16103 .....                | 4  |
| Figure 5  | Parameter Summary .....                                  | 5  |
| Figure 6  | Set-up Mode .....  | 9  |
| Figure 7  | Adjustment Lockout Mode .....                            | 10 |
| Figure 8  | Voltage/Frequency Operation .....                        | 11 |
| Figure 9  | Deceleration Ramp Adaptation .....                       | 12 |
| Figure 10 | Automatic Slip Compensation .....                        | 12 |
| Figure 11 | Acceleration Ramp .....                                  | 14 |
| Figure 12 | Deceleration Ramp .....                                  | 14 |
| Figure 13 | Low Speed/High Speed .....                               | 15 |
| Figure 14 | Volts/Frequency Ratio .....                              | 15 |
| Figure 15 | Preset Speeds .....                                      | 19 |
| Figure 16 | Brake Control Logic .....                                | 20 |
| Figure 17 | Measuring Bus Capacitor Voltage .....                    | 25 |

**List of Tables**

|         |                                      |    |
|---------|--------------------------------------|----|
| Table 1 | Set-Up Mode .....                    | 7  |
| Table 2 | Adjustment Lockout Mode .....        | 7  |
| Table 3 | Key Operation .....                  | 8  |
| Table 4 | Nominal Motor Voltage Settings ..... | 10 |
| Table 5 | Fault Codes .....                    | 27 |

## INTRODUCTION

This instruction bulletin covers installation and operation of the three Display/Adjustment options available for use with the Altivar 16 family of drive controllers:

- VW3-A16101: Display/Adjustment Option
- VW3-A16102: Display/Adjustment/Local Control Option
- VW3-A16103: Remote Mounting Kit

It also describes the various parameters and fault codes accessible with the options. Each option is described in the following sections.

### VW3-A16101

Option VW3-A16101 mounts on the front of the drive controller. It includes three seven-segment displays, one program LED, and four push buttons for programming the drive controller. Its features are illustrated in Figure 1.

For a summary of the parameters accessible with this and the other two display options, see Figure 5 on page 5. The codes displayed in the event of a fault are listed in Table 5 on page 27.




Figure 1 Display/Adjustment Option VW3-A16101

## VW3-A16102

Option VW3-A16102 also mounts on the front of the drive controller. It provides the same features as option VW3-A16101, but adds the ability to start and stop the drive controller from the option if a direction command (FW/RV) is present, and the ability to adjust the speed of the drive controller and to reset the drive controller from the option. LEDs indicate when the drive is in local control and whether the motor has been commanded to rotate in forward or reverse. Option VW3-A16102 is illustrated in Figure 2.




Figure 2 Display/Adjustment/Local Control Option VW3-A16102

## VW3-A16103


Option VW3-A16103 is a kit for remote mounting of option VW3-A16101 or VW3-A16102 to a NEMA Type 1, 4 or 12 enclosure. The kit consists of an interface box which mounts on the front of the drive controller, a 3-meter connection cable and a plastic keypad cover.

## MOUNTING

### Local


Options VW3-A16101 and VW3-A16102 can be connected while the drive controller is powered up. To mount either option (refer to Figure 3):

1. Using a screwdriver, remove programming cover plate from front of drive controller as shown. Do not remove any other cover.

|  |
|--|
|  <b>WARNING</b>   |
| <b>HAZARDOUS VOLTAGE.</b><br><b>Do not remove any other cover besides programming cover plate when installing the option.</b><br>Failure to observe this precaution can cause shock or burn, resulting in severe personal injury or death. |

2. Plug option into drive controller. Use screwdriver to secure option.

*Note: Removal of option VW3-A16102 when it is set to local mode (Switch 1 set to On, see page 6) and when the drive controller is powered up (with or without the motor running) will cause the drive controller to fault.*




**Figure 3**      **Mounting Option VW3-A16101 or VW3-A16102**

## Remote

When mounted with kit VW3-A16103 on a NEMA Type 1, 4 or 12 enclosure, options VW3-A16101 and VW3-A16102 have a protection rating of IP65. To remotely mount the options (refer to Figure 4):


1. Using a screwdriver, remove programming cover plate from front of drive controller. Do not remove other covers.

 **WARNING**

**HAZARDOUS VOLTAGE.**  
**Do not remove any other cover besides programming cover plate when installing the option.**

Failure to observe this precaution can cause shock or burn, resulting in severe personal injury or death.

2. Plug interface box provided with kit into front of drive controller. Use screwdriver to secure interface box.
3. Connect display unit (VW3-A16101 or VW3-A16102) to interface box with cable provided in kit.
4. Mount display unit on front of enclosure. Information concerning cut-out size is found in the instruction guide which accompanies option VW3-A16103.



**Figure 4 Remote Mounting with Kit VW3-A16103**

## PARAMETER SUMMARY

Figure 5 lists the parameters accessible through the Display/Adjustment options along with their valid ranges.




Figure 5 Parameter Summary

*Note: Value of input line voltage, **ULn**, is valid only when the drive controller is in ready mode (**rdy**). In addition, the value displayed may be incorrect if the input line voltage is subject to waveform distortion.*

## SWITCH SETTINGS

Use the switches on back of the Display/Adjustment options as described in the following sections. Refer to Tables 1 and 2 for a summary of switch settings.

For location of the switches on option VW3-A16101, see Figure 1 on page 1. For location of switches on option VW3-A16102, see Figure 2 on page 2.

*Note: In Table 1 and Table 2, Drive Ready indicates that power is applied to the drive controller, but no Run command is present.*

### Switch 1 (VW3-A16102 Only)

Switch 1, used on option VW3-A16102 **only**, selects local control. When Switch 1 is set to On, the drive controller is in Local mode. With the presence of a direction command (FW/RV) and reference frequency set with the **LFr** parameter, the drive controller may be started, stopped and reset from the Display/Adjustment option, depending on settings of the **rES**, **StS** and **StE** parameters (see page 13).



When Switch 1 is set to Off, the drive controller is run only with the presence of a direction command (FW/RV) and reference signal at AIV or AIC.

### Switch 2 (VW3-A16101 and VW3-A16102)



Switch 2 is used on both options to determine the mode of the Display/Adjustment option. When Switch 2 is set to On, the option is in **Set-up mode**. Set-up mode permits modification of parameters when the drive controller is ready or the motor is running. See Table 1 for further explanation.

When Switch 2 is set to Off, the option is in **Adjustment Lockout mode**. No modification of parameters is possible in this mode. See Table 2 for further explanation.

**Table 1 Set-Up Mode**

| Switch Position  | Option                   | Drive Ready   | Motor Running  |
|--|--------------------------|---|--|
|   | VW3-A16101<br>VW3-A16102 | <ul style="list-style-type: none"> <li>• Drive controller can be started and stopped with presence of direction command (FW/RV) and reference signal at AIV or AIC.</li> <li>• Display of display parameters</li> <li>• Display and modification of adjustment parameters</li> <li>• Display and modification of configuration parameters</li> <li>• Display of fault codes</li> <li>• Prog LED lit</li> </ul>  | <ul style="list-style-type: none"> <li>• Display of display parameters</li> <li>• Display and modification of adjustment parameters</li> <li>• Display of configuration parameters; no modification of configuration parameters</li> </ul>   |
|  | VW3-A16102 only          | <ul style="list-style-type: none"> <li>• Display of display parameters</li> <li>• Display and modification of adjustment parameters</li> <li>• Display and modification of configuration parameters</li> <li>• Display of fault codes</li> <li>• Prog LED lit</li> <li>• Enables local command push buttons: <b>Reset</b> if <b>rE5</b> is set to On. <b>Start/Stop</b> if <b>5t5</b> is set to On and with presence of a direction command (FW/RV) and reference frequency set with <b>LFr</b> parameter.</li> <li>• Local LED lit (flashes if <b>rE5</b>, <b>5t5</b> and <b>5tE</b> are set to Off).</li> </ul> | <ul style="list-style-type: none"> <li>• Same as above</li> <li>• Enables local command push buttons: <b>Reset</b> if <b>rE5</b> is set to On. <b>Start/Stop</b> if <b>5t5</b> is set to On and with presence of a direction command (FW/RV) and reference frequency set with <b>LFr</b> parameter.</li> <li>• Local LED lit.</li> </ul> |





**Table 2 Adjustment Lockout Mode**

| Switch Position   | Option                   | Drive Ready or Motor Running  |
|---|--------------------------|---|
|  | VW3-A16101<br>VW3-A16102 | <ul style="list-style-type: none"> <li>• Drive controller can be started and stopped with presence of direction command (FW/RV) and a reference signal at AIV or AIC.</li> <li>• Display of display parameters</li> <li>• Display of adjustment parameters</li> <li>• Display of fault codes</li> <li>• Configuration parameters not displayed</li> <li>• No modifications possible</li> </ul>  |
|  | VW3-A16102 only          | <ul style="list-style-type: none"> <li>• Display of display parameters</li> <li>• Display of adjustment parameters</li> <li>• Display of fault codes</li> <li>• Configuration parameters not displayed</li> <li>• No modifications possible</li> <li>• Enables local command push buttons: <b>Reset</b> if <b>rE5</b> was set to On in Set-up mode. <b>Start/Stop</b> if <b>5tE</b> was set to On in Set-up mode and with presence of a direction command (FW/RV) and a reference frequency set with <b>LFr</b> parameter.</li> <li>• Local LED lit (flashes if <b>rE5</b>, <b>5t5</b> and <b>5tE</b> are set to Off).</li> </ul> |

## OPERATION OF THE PUSH BUTTONS

Figures 6 and 7 illustrate operation of the Display/Adjustment option push buttons. Refer to Table 3 for key operation. For key operation with the **LFr** parameter, refer to page 17.

**Table 3 Key Operation**

| Key   | Operation                                |  |
|---|--|--|
|   | When parameter name is displayed         | When parameter value is displayed                            |
|    | Steps forward through list of parameters | Increases parameter value                                    |
|    | Steps back through list of parameters    | Decreases parameter value                                    |
|  | Displays parameter value                 | Displays parameter name or cancels change to parameter value |
|  |  | Saves change to parameter value                              |

## Set-up Mode

Figure 6 illustrates how to change and save adjustment and configuration parameter values in Set-up mode (Switch 2 set to On).




Figure 6 Set-up Mode

## Adjustment Lockout Mode

Figure 7 illustrates how to scroll through the available parameters and display their values in Adjustment Lockout mode.




Figure 7 Adjustment Lockout Mode

## CONFIGURATION PARAMETERS

The following sections describe the configuration parameters available on options VW3-A16101 and VW3-A16102.

### Un5: Nominal Motor Voltage

Nominal motor voltage is based on the motor nameplate. Refer to Table 4 for appropriate settings.

Table 4 Nominal Motor Voltage Settings

| Choice of Nominal Voltage at 50 or 60 Hz: | Factory Setting:   |
|---|--|
| ATV16...M2: 208, 220, 230, 240 V          | 230 V  |
| ATV16...N4: 380, 400, 415, 460 V          | 400 or 460 V depending on position of Switch 1 on drive controller |


### Fr5: Nominal Motor Frequency

Selection of nominal motor frequency is based on nominal motor voltage and is indicated on the motor nameplate. Setting this parameter from the display overrides setting of the volts/frequency ratio switch on the drive controller. Factory setting is 50 or 60 Hz depending on the position of Switch 1 on the drive controller. Range is 40 to 200 Hz. Note that with the variable torque option card VW3-A16202 installed, the range of **Fr5** is 40 to 70/80 Hz. With the high speed option card VW3-A16203 installed, the range of **Fr5** is 40 to 400 Hz.



### **brR: Deceleration Ramp Adaptation**

Possible settings are On and Off.




**On:** Deceleration ramp time ( $dEc$ ) is automatically adjusted to compensate for load inertia and to avoid overbraking fault ( $ObF$ ).

**Off:** Deceleration ramp time ( $dEc$ ) is not automatically adjusted. If the motor is unable to follow deceleration ramp, drive controller will trip on overbraking fault ( $ObF$ ).

**Figure 9 Deceleration Ramp Adaptation**

### **SLP: Automatic Slip Compensation**

Possible settings are On and Off.



**On:** Automatic slip compensation enabled. Use this setting for running at constant speed as the load changes.

**Off:** Automatic slip compensation disabled. Use this setting for applications with high inertia, variable torque or external speed regulation.

**Figure 10 Automatic Slip Compensation**

## **StE, StS, rES**

Three additional configuration parameters are available with option VW3-A16102. These are used to start, stop and reset the drive controller from the display option when in Local mode (Switch 1 set to On) and when a direction command (FW/RV) and reference frequency set with **LFr** are present. When not in Local mode (Switch 1 set to Off), these parameters are not used and the drive controller is run with the presence of a direction command and reference signal at AIV or AIC.

### **StE: Start/Stop in Adjustment Lockout Mode**

When **StE** is set to On and the display is in Adjustment Lockout mode, with the presence of a direction command (FW/RV) and a reference frequency set with **LFr**, the drive controller is started and stopped from the display option. When a direction command is present, the FWD or REV LED will flash to indicate that the drive controller can be started from the display option. When started, the FWD or REV LED will be lit. If the direction command is removed while the drive controller is running, the drive controller will stop. If a direction command (FW or RV) is restored, the drive controller will restart. When **StE** is set to Off and the display is in Adjustment Lockout mode, the drive controller cannot be started even if a direction command and reference frequency are present.

### **StS: Start/Stop in Set-up Mode**

When **StS** is set to On and the display is in Set-up mode, with the presence of a direction command (FW/RV) and reference frequency set with **LFr**, the drive controller is started and stopped from the display option. When a direction command is present, the FWD or REV LED will flash to indicate that the drive controller can be started from the display option. When started, the FWD or REV LED will be lit. If the direction command is removed while the drive controller is running, the drive controller will stop. If a direction command (FW or RV) is restored, the drive controller will restart. When **StS** is set to Off and the display is in Set-up mode, the drive controller cannot be started, even if a direction command and reference frequency are present.

### **rES: Reset Fault**

The reset fault function is not dependent on whether the display option is in Adjustment Lockout or Set-up mode. When **rES** is set to On, the drive controller can be reset after the **OSF**, **OLF**, **DBF**, **DBF.**, **SPF**, **SPF.** or **SLF** faults (see pages 23 and 24) by pressing the Stop/Reset push button, if the cause of the fault has been corrected. When **rES** is set to Off, after these faults the drive controller must be reset by removing power. If the cause of the **PhF**, **USF** or **DPE** faults is corrected, the drive controller automatically resets.

## ADJUSTMENT PARAMETERS

The following sections describe the adjustment parameters available on both options VW3-A16101 and VW3-A16102.

### $R_{cc}$ : Acceleration Ramp Time

Acceleration ramp time can range from 0.1 to 600 s. The factory setting is 3 s. Acceleration ramp time is automatically extended when the maximum transient output current of the drive controller is reached.




Figure 11 Acceleration Ramp

### $dE_c$ : Deceleration Ramp Time

Deceleration ramp time can range from 0.1 to 600 s. The factory setting is 3 s. If deceleration ramp adaptation ( $brR$ ) is set to On, the deceleration time is automatically extended to avoid overbraking fault ( $ObF$ ).




Figure 12 Deceleration Ramp

**LSP: Low Speed**  
**HSP: High Speed**

The factory settings for low speed (**LSP**) and high speed (**HSP**) are 0 Hz and 50 Hz respectively. When **LSP** is 0, the drive stays ready as long as reference speed is less than 0.1 Hz. **HSP** is limited by the value of maximum drive output frequency (**EFr**).




Figure 13 Low Speed/High Speed

**UFR: Volts/Frequency Ratio**

**UFR** is factory set to **n20**, **L20** or **P20**, depending on the setting of **UFL** (i.e, n, P or L). The factory settings are suitable for most applications; however, if the torque is insufficient, increase the setting gradually from **00** to **100**.




Figure 14 Volts/Frequency Ratio

## FLG: Frequency Loop Gain

Frequency loop gain can range from **00** to **99** or **nFL**. The factory setting is **33**. For machines with high resistant torque or high inertia, reduce the gain gradually to a value between **33** and **00**. For machines with fast cycles, low resistant torque or low inertia, increase the gain gradually from **33** to **99**. Note that too much gain can cause instability. A value of **nFL** suppresses frequency loop gain. This can cause the motor to stall if the required torque is too high.



### CAUTION

#### **MOTOR MAY STALL.**

**Inhibiting this function can cause motor to stall if required torque is too high.**

Failure to observe this precaution can result in equipment damage.

## lth: Motor Thermal Protection

Motor thermal protection can range from 0.45 to 1.05 times the nominal drive controller rated output current. Factory setting is 0.9 times the drive controller rated output current. Adjust **lth** to the current value shown on the motor nameplate. To suppress motor thermal protection, increase the value of **lth** to the maximum and provide external thermal protection.



### CAUTION

#### **LOSS OF MOTOR OVERLOAD PROTECTION.**

**When using external overload relays connected to the drive controller output, the overload relay must be capable of operation over the expected range of drive controller output frequencies (including direct current).**

**When DC injection braking is used:**

- **The overload relay must be suitable for operation with direct current flowing in the motor.**
- **Do not use overload relays equipped with current transformers for sensing the motor current.**

Failure to observe this precaution can result in equipment damage.




 **CAUTION**

**MOTOR OVERHEATING.**

**This drive controller does not provide direct thermal protection for the motor. Use of a thermal sensor in the motor may be required for protection at all speeds and loading conditions. Consult motor manufacturer for thermal capability of motor when operated over desired speed range.**

Failure to observe this precaution can result in equipment damage.

### ***LFr*: Reference Frequency in Hz**

When the display/adjustment keypad is in local command mode (Switch 1 On), this parameter appears in place of *F<sub>rh</sub>* and is used to adjust the reference frequency. In Set-up mode, *StS* must be set to On and in Adjustment Lockout mode, *StE* must be set to On for this parameter to take effect. To change the value of *LFr*, press  and  or  simultaneously. If the motor is running, the change is immediately taken into account.

## **DISPLAY PARAMETERS**

The values of the Display parameters, available on both option VW3-A16101 and VW3-A16102, are obtained by pressing the DATA push button.

- *rdy*: Drive ready (no run command)
- *F<sub>rh</sub>*: Reference frequency in Hz. If the displayed value flashes, it is because the drive is adjusting its acceleration or deceleration ramp, or because the drive is at current limit.
- *L<sub>cr</sub>*: Motor current in Amps
- *UL<sub>n</sub>*: Input line voltage in volts

## ADDITIONAL PARAMETERS

Additional parameters appear on the display with the option cards. These are described in the following sections.

### VW3-A16201 Option Card set for General Use

#### Adjustable Parameter

**JoG**: Jog operation. The LI3 input on the VW3-A16201 option card is factory set for Jog operation when the option card is configured for general use. With LI3 at state 1, the direction command (FW/RV) input is used to jog the drive controller at the frequency set by the Jog parameter. Factory set for 5 Hz, it can be adjusted between 0.1 and 10 Hz. When jogging, the acceleration and deceleration ramp rates are 0.1 s.

#### Configurable Parameters

**REr**: Automatic restart. Enables the drive controller to automatically restart following an overvoltage (**OSF**), overload (**OLF**) or overbraking (**ObF**) fault. For the **OSF** and **ObF** faults, the drive controller remains disabled for 1 minute after the fault appears causing the fault relay of the drive controller to engage, then it restarts automatically if the fault has disappeared. If the cause of the fault is present at the end of 1 minute, the drive controller must be manually reset. The drive controller will attempt five automatic restarts (one every minute) before it must be manually reset. For the **OLF** fault, the restart is effective as soon as the thermal state drops below 100%, usually about seven minutes after the fault occurs. Factory set to **Off**, can be configured to **On**.



## WARNING

### UNINTENDED EQUIPMENT ACTION.

- **Automatic restart and catching a spinning load can only be used for machines or installations that present no danger in the event of automatic restarting, either for personnel or equipment.**
- **Equipment operation must conform with national and local safety regulations.**

Failure to observe these precautions can result in equipment damage or severe personal injury.

**FLr**: Catching a spinning load. Allows smooth restarting of motor after a brief input line undervoltage. If the reference signal and a direction command are maintained, the motor accelerates back up to speed without starting at zero. Factory set to **Off**, can be configured to **On**.

## VW3-A16201 Option Card Set for Material Handling

### Configurable Parameter


**5tP**: Controlled stop on loss of input power. Factory set to **Off**, can be configured to **On**. When set to **On**, deceleration follows a self-adjusting ramp which is a function of the regenerated energy. When set to **Off**, motor coasts to a stop at loss of input power.

### Adjustable Functions

**Preset speeds**: Preset Speed 1 is Low Speed (**LSP**) or the value of the reference signal. Preset Speed 2 is High Speed (**HSP**). The display allows adjustment of Preset Speeds 3 and 4.


**3SP**: Preset Speed 3. Input LI2 is factory set for Preset Speed 3. The drive controller will run at Preset Speed 3 when LI2 is at state 1 and a direction command is present (FWD or REV). Factory set at 5 Hz, Preset Speed 3 can be adjusted between **LSP** and **HSP**.

**4SP**: Preset Speed 4. Input LI3 is factory set for Preset Speed 4. The drive controller will run at Preset Speed 4 when LI3 is at state 1 and a direction command (FWD or REV) is present. Factory set at 25 Hz, Preset Speed 4 can be adjusted to a value between **LSP** and **HSP**.



**Figure 15** Preset Speeds

**Brake control:** The S2A-S2B relay on the VW3-A16201 option card is set for brake control. The release and engaging of the mechanical brake follows the graph below. When the brake release frequency threshold and the brake release current threshold (*ibr*) are reached, the S2A-S2B relay closes. During a time delay of  $t_1$ , the acceleration ramp is inhibited. This ensures that the motor develops the necessary torque before the actual release of the brake. For the brake to engage, when the deceleration ramp reaches the brake engage frequency threshold, the S2A-S2B relay opens. The brake engages after a time delay of  $t_1$ .



**Figure 16 Brake Control Logic**

**Factory settings:**

Brake release frequency threshold = Low speed setting (*LSP*)

Brake release current threshold (*ibr*) = 0. See *ibr* below.

Brake release time delay = 0 s

Brake engage frequency threshold = Low speed setting (*LSP*)

***ibr***: Brake release current threshold. Current threshold initiates closing of S2A-S2B brake control relay activating the brake release. Factory set to 0, brake release current threshold can be adjusted from 0 to 1.05 drive controller rated output current.

## VW3-A16202 Variable Torque Option Card

### Adjustable Parameters

**JF 1**: Jump (skip) frequency 1 with bandwidth of 2 Hz. Factory set at 0 Hz (not used); can be adjusted to a value between **LSP** and **HSP**.

**JF 2**: Jump (skip) frequency 2 with bandwidth of 2 Hz. Factory set at 0 Hz (not used), can be adjusted to a value between **LSP** and **HSP**.

### Configurable Parameters

**AR**: Automatic restart. Enables the drive controller to automatically restart following an overvoltage (**OSF**), overload (**OLF**) or overbraking (**ObF**) fault. For the **OSF** and **ObF** faults, the drive controller remains disabled for 1 minute after the fault appears, causing the fault relay of the drive controller to engage, then it restarts automatically if the cause of the fault has disappeared. If the cause of the fault has not disappeared at the end of 1 minute, the drive controller must be manually reset. The drive controller will attempt 5 automatic restarts (one every minute) before it must be manually reset. For the **OLF** fault, the restart is effective as soon as the thermal state drops below 100%, usually about 7 minutes after the fault occurs. Factory set to **Off**, can be configured to **On**.



## WARNING

### UNINTENDED EQUIPMENT ACTION.

- **Automatic restart and catching a spinning load can only be used for machines or installations that present no danger in the event of automatic restarting, either for personnel or equipment.**
- **Equipment operation must conform with national and local safety regulations.**

Failure to observe these precautions can result in equipment damage or severe personal injury.

**FLR**: Catching a spinning load. Allows smooth restarting of the motor after a brief input line undervoltage. If the reference signal and a direction command are maintained, the motor accelerates back up to speed without starting at zero. Factory set to **Off**, can be configured to **On**.

**SEP**: Controlled stop on loss of input power. Factory set to **Off**, can be configured to **On**. When set to **On**, deceleration follows a self-adjusting ramp which is a function of the regenerated energy. When set to **Off**, motor coasts to a stop at loss of input power.

## VW3-A16203 High Speed Motor Option Card

### Adjustable Parameters

**$Rc2$** : Acceleration ramp 2. LI2 is factory set as Switch to Ramp 2. When this input is at state 1, drive controller will accelerate according to  **$Rc2$** . Factory set to 12 s, it can be adjusted between 0.1 and 600 s.

**$dE2$** : Deceleration ramp 2. LI2 is factory set as Switch to Ramp 2. When this input is at state 1, drive controller will decelerate according to  **$dE2$** . Factory set to 12 s, it can be adjusted between 0.1 and 600 s.

**$Idc$** : DC current level. DC injection occurs when frequency drops to a value less than 0.1 Hz. Factory set to 0.7 times  **$Ith$** , it can be adjusted between 0.5 and 1.5 times  **$Ith$** .

**$tdc$** : DC current time. Amount of time for which DC is injected when frequency drops to a value less than 0.1 Hz. Factory set at 0.5 s, it can be adjusted from 0 to 5 s or to be permanently injected (setting is  **$dcb$** ).



### WARNING

#### NO HOLDING TORQUE.

- **DC injection braking does not provide holding torque at zero speed.**
- **DC injection braking does not function during loss of power or drive controller fault.**

**When required, use separate brake function for holding torque.**

Failure to observe this precaution can result in equipment damage, severe personal injury or death.



### CAUTION

#### MOTOR OVERHEATING.

**Application of DC injection braking for long periods of time can cause motor overheating and damage. Protect motor from extended periods of DC injection braking.**

Failure to observe this precaution can result in equipment damage or personal injury.

**$FLr$** : Catching a spinning load. Allows smooth restarting of the motor after a brief input line undervoltage. If the reference signal and a direction command are maintained, the motor accelerates back up to speed without starting at zero. Factory set to **Off**, can be configured to **On**.

## VW3-A16204 General Use / 3-Wire Control Option Card

### Adjustable Functions

**Jog:** Jog operation. The LI3 input on the VW3-A16204 option card is factory set for Jog operation. Jog is factory set for 5 Hz and can be adjusted between 0.1 and 10 Hz. When jogging, the acceleration and deceleration ramp rates are 0.1 s. For information on wiring the Jog input, refer to the instruction manual for the VW3-A16204 option card.

**Idc:** DC current level. DC injection occurs when frequency drops to a value less than 0.1 Hz. Factory set to 0.7 times  $I_{th}$ , it can be adjusted between 0.5 and 1.5 times  $I_{th}$ .

**t<sub>dc</sub>:** DC current time. Amount of time for which DC is injected when frequency drops to a value less than 0.1 Hz. Factory set at 0.5 s, it can be adjusted from 0 to 5 s or to be permanently injected (setting is **dcb**).



### WARNING

#### NO HOLDING TORQUE.

- **DC injection braking does not provide holding torque at zero speed.**
- **DC injection braking does not function during loss of power or drive controller fault.**

**When required, use separate brake function for holding torque.**

Failure to observe this precaution can result in equipment damage, severe personal injury or death.



### CAUTION

#### MOTOR OVERHEATING.

**Application of DC injection braking for long periods of time can cause motor overheating and damage. Protect motor from extended periods of DC injection braking.**

Failure to observe this precaution can result in equipment damage or personal injury.

**FLr:** Catching a spinning load. Allows smooth restarting of the motor after a brief input line undervoltage. If the reference signal and a direction command are maintained, the motor accelerates back up to speed without starting at zero. Factory set to **Off**, can be configured to **On**.

## OPERATION ASSISTANCE

Table 5 on page 27 lists the fault codes accessible on the Display/Adjustment options, the probable causes of the faults and associated corrective action. When taking corrective action, follow the two procedures outlined on pages 24-26.

**⚠ DANGER**

**HAZARDOUS VOLTAGE.**

- **Read and understand these procedures before servicing AC drive controllers. Installation, adjustment, repair and maintenance of these drive controllers must be performed by qualified personnel.**
- **Many parts in this drive controller, including printed wiring boards, operate at line voltage. DO NOT TOUCH. Use only electrically insulated tools while making adjustments.**

Failure to observe these precautions will cause shock or burn, resulting in severe personal injury or death.

The following procedures are intended for use by qualified electrical maintenance personnel and should not be viewed as sufficient instruction for those who are not otherwise qualified to operate, service or maintain the equipment discussed.

### Procedure 1: Checking Supply Voltage

Before checking supply voltage, disconnect all power and measure DC bus capacitor voltage by following the procedure below.

DC bus capacitor voltage is measured between the J9+ and J8- terminals of the drive controller. The DC bus capacitors are discharged when input power is removed from the drive controller. To ensure the capacitors are fully discharged, always disconnect all power, wait 1 minute, then test with a DC voltmeter (1000 VDC scale) before wiring, troubleshooting or working inside the drive controller. If no reading is shown on the voltmeter, reduce scale and test again.

## ⚠ DANGER

### HAZARDOUS VOLTAGE.

- **Read and understand Bus Voltage Measurement Procedure before performing procedure. Measurement of bus capacitor voltage must be performed by qualified personnel.**
- **DO NOT short across capacitors or touch unshielded components or terminal strip screw connections with voltage present.**
- **Many parts in this drive controller, including printed wiring boards, operate at line voltage. DO NOT TOUCH. Use only electrically insulated tools.**

Failure to observe these precautions will cause shock or burn, resulting in severe personal injury or death.

The J9+ and J8- terminals are located on the power board, in the general area shown in Figure 17. To measure the bus capacitor voltage, follow the Bus Voltage Measurement Procedure below.

### Bus Voltage Measurement Procedure

1. Disconnect all power from drive controller.
2. Wait 1 minute to allow the DC bus to discharge.
3. Remove all covers.
4. Set the voltmeter to the 1000 VDC scale. Measure the bus capacitor voltage between the J9+ and J8- terminals to verify the DC voltage is less than 45 V. **Do not short across capacitor terminals with voltage present!**
5. If the bus capacitors are not fully discharged, contact your local Square D representative – **do not operate the drive controller.**
6. Replace all covers.




Figure 17 Measuring Bus Capacitor Voltage

After measuring DC bus capacitor voltage, check supply voltage by following the procedure below:

1. Attach meter leads to L1 and L2. Set voltmeter to the 600V AC scale.
2. Reapply power. Voltage should be as follows:  
ATV16U••M2: 187.2 VAC < V < 264 VAC  
ATV16U••N4: 340.0 VAC < V < 529 VAC
3. Remove power and repeat procedure for L2 and L3, and L1 and L3 if wired for three phase.
4. When all phases have been measured, remove power. Remove leads, reinstall covers.

## Procedure 2: Checking the Peripheral Equipment

The following equipment may need to be checked. Follow the manufacturers' procedures when checking this equipment.

1. A protective device such as fuses or circuit breaker may have tripped.
2. A switching device such as a contactor may not be closing at the correct time.
3. Conductors may require repair or replacement.
4. Connection cables to the motor or high resistance connections to ground may need to be checked. Follow NEMA standard procedure WC-53.
5. Motor insulation may need to be checked. Follow NEMA standard procedure MG-1. Do not apply high voltage to U, V or W. Do not connect the high potential dielectric test equipment or insulation resistance tester to the drive controller since the test voltages used may damage the drive controller. Always disconnect the drive controller from the conductors or motor while performing such tests.

### CAUTION

#### **EQUIPMENT DAMAGE HAZARD.**

- **Do not perform high potential dielectric tests on circuits while the circuits are connected to the drive controller.**
- **Any circuit requiring high potential dielectric tests must be disconnected from the drive controller prior to performing the test.**

Failure to observe this precaution can result in equipment damage.

**Table 5 Fault Codes**

| Fault                          | Probable Causes  | Corrective Actions   |
|--------------------------------|--|--|
| Display Off or Partial Display | <ul style="list-style-type: none"> <li>No voltage</li> <li>Voltage too low</li> </ul>  | Check: <ul style="list-style-type: none"> <li>Supply Voltage (Procedure 1 on page 24)</li> <li>Supply fuses or circuit breaker (Procedure 2 on page 26)</li> </ul>   |
| <b>PhF</b>                     | <b>Phase failure</b> <ul style="list-style-type: none"> <li>No supply to terminals L1, L2, (L3)</li> <li>Power fuses blown</li> <li>Brief input line failure (<math>t \geq 200</math> ms)</li> </ul>   | Check: <ul style="list-style-type: none"> <li>Supply Voltage (Procedure 1 on page 24)</li> <li>Supply fuses or circuit breaker (Procedure 2 on page 26)</li> </ul>   |
| <b>USF</b>                     | <b>Undervoltage</b> <ul style="list-style-type: none"> <li>Supply voltage too low</li> <li>For ATV16...M2, <math>V \leq 187</math> V</li> <li>For ATV16...N4, <math>V \leq 340</math> V</li> <li>Temporary voltage drop (<math>t \geq 200</math> ms)</li> </ul>  | Check: <ul style="list-style-type: none"> <li>Supply voltage (Procedure 1 on page 24)</li> <li>Connections</li> </ul>  |
| <b>OSF</b>                     | <b>Overvoltage</b> <ul style="list-style-type: none"> <li>Supply voltage too high</li> <li>For ATV16...M2, <math>V \geq 264</math> V</li> <li>For ATV16...N4, <math>V \geq 529</math> V</li> </ul>   | Check: <ul style="list-style-type: none"> <li>Supply voltage (Procedure 1 on page 24)</li> </ul>   |
| <b>OLF</b>                     | <b>Overload</b><br>Thermal trip due to prolonged motor overload  | Check: <ul style="list-style-type: none"> <li><math>It_h</math> setting and compare with motor rated current</li> <li>Load base speed and power rating and compare with operating speed and drive controller/motor power rating</li> <li>Motor connections (possibility of single phase operation)</li> </ul> Wait approximately 7 minutes before resetting. |
| <b>OBF</b>                     | <b>Overbraking</b><br>due to overvoltage or  | Increase deceleration time, optimize gain by decreasing value of <b>FLG</b> , and optimize <b>UFR</b> . Add braking option if necessary. Refer to Instruction Bulletin 50006-360-04.   |
| <b>OBF.</b>                    | overcurrent<br>due to excessive braking or an overhauling load, even with braking option.  |  |
| <b>drF</b>                     | <b>Transient overcurrent</b> <ul style="list-style-type: none"> <li>Short circuit or phase to ground on the output of the drive controller</li> <li>Overheating of IPM</li> <li>Power supplies to IPM are too low</li> <li>Current too high during transient duty</li> <li>Internal short circuit</li> </ul> | Switch drive off.<br>Disconnect drive controller from motor at U/T1, V/T2 and W/T3.<br>Check connection cables and motor insulation (Procedure 2 on page 26).<br>Increase acceleration or deceleration time. Check the ambient temperature of the drive controller.  |
| <b>crF</b>                     | <b>Capacitor charge relay fault</b><br>Failure of command for capacitor charge relay to close  | Replace drive controller.  |
| <b>InF</b>                     | <b>Internal connection fault</b><br>Drive does not recognize rating  | Disconnect power and wait one minute for capacitors to discharge.<br>Check internal connections in the drive. If fault persists, replace drive controller.   |
| <b>EEF</b>                     | <b>EEPROM memory fault</b>   | Replace drive controller.  |

**Table 5      Fault Codes (Continued)**

| <b>Fault</b> | <b>Probable Causes</b>   | <b>Corrective Actions</b>   |
|--------------|--|---|
| <b>SLF</b>   | <b>Communication fault</b><br>Communication loss between options   | Check display option connection.<br>Reset drive controller.   |
| <b>DPE</b>   | <b>Option Card Fault.</b><br>Switch 2 on option card was moved to On in order to reconfigure the I/O.  | Reconfigure the I/O with the PC connection option (refer to Instruction Bulletin 50006-360-03) or return Switch 2 to Off.   |
| <b>SPF</b>   | <b>Option card fault (VW3-A16201 only)</b><br><b>Speed feedback fault</b><br>Incorrect adjustment of tachogenerator feedback, or machine overload. | Check:<br>• Feedback signal<br>• Load base speed and power rating and compare with operating speed and drive controller/motor power rating<br>• Tachogenerator connection |
| <b>SPF.</b>  | No tachogenerator signal.  |   |



**GROUPE SCHNEIDER**  
■ Merlin Gerin ■ Square D ■ Telemecanique

99647

VD0C01S3

---

© 1994 Schneider S.A. All Rights Reserved